

Manuals.plus / > Russell Hobbs / > Russell Hobbs Sizzle Air RAF8000 1700W 8L Digital Air Fryer Instruction Manual

Russell Hobbs RAF8000

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Russell Hobbs Sizzle Air RAF8000 Digital Air Fryer

Instruction Manual

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Russell Hobbs Sizzle Air RAF8000 Digital Air Fryer. Retain this manual for future reference.

- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not immerse the appliance, cord, or plug in water or any other liquid.
- **Hot Surfaces:** The appliance surfaces become hot during use. Use oven mitts when handling hot components. Do not touch hot surfaces directly.
- **Ventilation:** Do not block any ventilation openings. Allow sufficient space around the appliance for proper air circulation.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls and other appliances, to prevent heat damage.
- **Overfilling:** Do not overfill the basket, as this can impede air circulation and affect cooking performance.
- **Maintenance:** Regular cleaning is essential. Always unplug the appliance and allow it to cool completely before cleaning.

Advertisements

2. PRODUCT OVERVIEW

The Russell Hobbs Sizzle Air RAF8000 is an 8-litre digital air fryer designed for efficient and healthy cooking. It features 1700W power, rapid air circulation technology, and 8 pre-set programs for versatile meal preparation.



Image: The Russell Hobbs Sizzle Air RAF8000 Digital Air Fryer, showcasing its sleek black design and digital control panel.

Key Features:

- **Powerful 1700W Performance:** Ensures quick heat-up and consistent cooking results.
- **Large 8-Litre Capacity:** Ideal for preparing generous portions for families.
- **8-in-1 Pre-Set Programs:** Effortlessly cook a variety of meals with dedicated settings.
- **Rapid Air Circulation:** Cooks food evenly and crisply with minimal oil.
- **Adjustable Temperature Control:** Range from 40°C to 200°C for precise cooking.
- **Timer Function:** Set cooking times from 1 to 60 minutes.
- **Removable Baking Tray:** Facilitates easy cleaning.

3. SETUP AND FIRST USE

Unpacking:

1. Carefully remove the air fryer and all packaging materials from the box.
2. Remove any promotional stickers or labels.
3. Check that all components are present: main unit, removable basket, and baking tray.

Before First Use:

1. Wipe the exterior of the air fryer with a damp cloth.
2. Wash the removable basket and baking tray in hot, soapy water. Rinse thoroughly and dry completely.
3. Place the air fryer on a stable, level, heat-resistant surface. Ensure there is at least 10 cm of clear space around the back and sides of the appliance.
4. Plug the power cord into a grounded electrical outlet.

4. OPERATING INSTRUCTIONS

Control Panel:

The digital control panel allows you to select pre-set programs, adjust temperature, and set the timer.



Image: The Russell Hobbs Sizzle Air RAF8000 Digital Air Fryer in a kitchen setting, highlighting the control panel and observation window.

General Operation:

1. Place the baking tray into the removable basket.
2. Place your food into the basket. Do not exceed the MAX fill line.
3. Slide the basket back into the air fryer until it clicks into place.
4. Press the Power button to turn on the appliance.
5. **Using Pre-Set Programs:** Select one of the 8 pre-set programs by pressing the menu button. The corresponding icon will illuminate, and default time/temperature settings will display.
6. **Manual Settings:** Alternatively, use the temperature control buttons to adjust the temperature (40°C-200°C) and the timer buttons to set the cooking time (1-60 minutes).
7. Press the Start/Pause button to begin cooking.
8. During cooking, you can pull out the basket to shake or turn food. The air fryer will pause automatically and resume when the basket is reinserted.
9. Once the timer reaches zero, the air fryer will beep, indicating cooking is complete.
10. Carefully pull out the basket and empty the cooked food onto a plate. Use tongs for smaller items.



Image: The air fryer basket pulled out, showing crispy fries ready to be served.

5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your air fryer.

Cleaning After Each Use:

- 1. Unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
- 2. Remove the basket and baking tray.
- 3. Wash the basket and baking tray in hot, soapy water using a non-abrasive sponge. They are also dishwasher safe.
- 4. Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.
- 5. Clean the interior of the appliance with a damp cloth. If necessary, use a mild detergent.
- 6. Ensure all parts are thoroughly dry before reassembling and storing the air fryer.

Storage:

Store the air fryer in a cool, dry place. Ensure the power cord is neatly wrapped and secured.

6. TROUBLESHOOTING

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; basket not fully inserted.	Check power cord connection; try a different outlet; ensure basket is securely closed.
Food is not cooked evenly.	Basket overfilled; food not shaken/turned; incorrect temperature/time.	Do not overfill; shake or turn food halfway through cooking; adjust temperature/time as needed.
White smoke coming from appliance.	Grease residue from previous use; fatty food being cooked.	Clean the basket and tray thoroughly; for fatty foods, add a small amount of water to the bottom of the outer pan to prevent smoke.
Food is not crispy.	Too much moisture in food; not enough oil (for some items); basket overfilled.	Pat food dry before air frying; lightly coat with oil if desired; ensure proper air circulation.

7. SPECIFICATIONS

Detailed technical specifications for the Russell Hobbs Sizzle Air RAF8000 Digital Air Fryer.

Feature	Specification
Model Name	RAF8000
Brand	Russell Hobbs
Output Wattage	1700 Watts
Capacity	8 Litres
Control Method	Touch
Min Temperature Setting	40 Degrees Celsius
Max Temperature Setting	200 Degrees Celsius
Air Frying Technology	Rapid Air Circulation
Material	Aluminium
Product Dimensions	5D x 5W x 5H Centimeters

Feature	Specification
Item Weight	1 Kilograms
Special Feature	Programmable
Included Components	Air Fryer
Country of Origin	China

8. WARRANTY AND SUPPORT

The Russell Hobbs Sizzle Air RAF8000 Digital Air Fryer comes with a **2-year warranty** covering any manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please contact Russell Hobbs customer service through their official website or the contact information provided with your purchase documentation.

Advertisements

© 2026 Russell Hobbs. All rights reserved.

Advertisements

Related Documents - RAF8000

	Russell Hobbs 27160 Rapid Digital Air Fryer: User Manual and Cooking Guide Comprehensive user manual and cooking guide for the Russell Hobbs 27160 Rapid Digital Air Fryer, covering setup, operation, safety, cleaning, and cooking times.
	Russell Hobbs 27170AU Air Fryer User Manual and Instructions Comprehensive user manual for the Russell Hobbs 27170AU Air Fryer, detailing safety precautions, operation, cooking functions, time and temperature adjustments, care and maintenance, and warranty information.
	Russell Hobbs 27170-56 Air Fryer User Manual Comprehensive user manual for the Russell Hobbs 27170-56 Air Fryer. Learn about safe operation, setup, cooking functions, times, temperatures, and maintenance for your Russell Hobbs air fryer.
	Russell Hobbs Satisfry Brooklyn 5.7L Air Fryer Instructions and Warranty This document provides instructions, safety precautions, and warranty information for the Russell Hobbs Satisfry Brooklyn 5.7L Air Fryer. It also includes a recipe book with various dishes that can be prepared using the air fryer.