ENDEAVOUR 2 (84 x 84mm)

	TABLE OF CONTENT	• Activity	WHAT'S IN THE BOX	USING NOISEFIT ENDEAVOR PRO SMARTWATCH	POWER ON	WATCH NAVIGATION	APP SET-UP	BT CALLING CONNECTIVITY	FEATURES	Health Snap
	• What's in the Box 01	Workout Workout Records		Before using your NoiseFit Endeavour Pro smartwatch for the first time, charge the battery	Press and hold the side-upper button for a few seconds to turn on the watch.	The NoiseFit Endeavour Pro smartwatch has an AMOLED touchscreen. Navigate the watch by tapping on the screen, swiping side to side, up and down,	Before pairing, make sure that your smartphone and smartwatch are next to each other.	Follow these steps to establish BT calling connectivity:	Activity Check your daily activity progress: steps taken, calories burnt,	Measure your avg heart rate, SpO2, Respiration, Stress & HRV in 90 seconds.
	• Watch Overview	Heart Rate Sleep	NoiseFit Endeavour Pro x 1	to its full capacity. Use the charging cable provided with the watch to charge. NoiseFit Endeavour Pro can last up to 15 days* on a full charge. Note: The battery life and time to fully charge your device may vary as per usage and other factors.	POWER OFF	and pressing the side buttons.	The App will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate and metabolic rate. When you set up your account, your name and profile picture will be visible to other users. Turn on the Bluetooth and location on your mobile device. On your smartphone, download the NoiseFit App from the Play Store or the App Store and install it.	FOR AUTOMATIC CONNECTION After pairing the watch with the NoiseFit App, the watch's calling BT would be activated. Now connect it with your phone's BT to conveniently use the calling feature. MANUAL CONNECTION	total workout time, distance covered, stand hours, floors climbed.	Hydration Mate Set your hydration level from the NoiseFit App. Now, every time you drink a
	Charging the Watch Turning the Watch On or Off	• Stress • Health Snap • Hydration Mate			Press and hold the side-upper button for a few seconds select 'Confirm shut down'.	SIDE-UPPER BUTTON NAVIGATION Press the side-upper button to turn on the watch display.			Workout From indoor walking to hiking, choose from 100+ workouts.	glass of water, click on the 150 ml button and track your hydration level.
	• Watch Navigation 04	Breath Training				Press it again to open the workouts section.			Workout Records	Breath Training
	• App Set up 05	• Agenda • Alarms		CHARGING NOISEFIT ENDEAVOUR PRO SMARTWATCH	WAKING UP THE WATCH	SIDE-LOWER BUTTON NAVIGATION	Create an account or log in using an existing account.	In case the BT calling connectivity has not been established earlier,	Track and see the progress report of your workout sessions.	Set your breath rhythm from slow, moderate, fast and set timer for up to 3 minutes.
	Pairing the Watch BT Call Connectivity and Removal 06	Phone Timer Stopwatch		 Plug the USB cable into a power adaptor and the power adaptor into an electrical socket. (The Power adaptor is not included). 	To preserve the battery, the watch screen turns off when not in use. Turn the screen back on by:	Press the side-lower button to turn on the watch display. Press it again to open for Al Voice Assistance.	Note: Ensure that your smartphone is running on Android 9.0+ or iOS 11 + and is connected to mobile data or a Wi-Fi network.	you'll have to do the same steps manually. Go to settings, search for device and pair your smartphone to attend calls from the watch.	Heart Rate NoiseFit Endeavour Pro supports 24/7 heart rate tracking. You can select the	Agenda You can create and manage events directly from your watch. To schedule a new event,
NoiseFit	• Watch Features 07		•	Place the magnetic charger on the magnetic charging points of the watch. While your watch is charging, the screen will show its progress.	Pressing any of the side buttons Pressing the functional crown button	HOME SCREEN NAVIGATION	PAIRING THE WATCH	BT CALL CONNECTIVITY REMOVAL	measurement frequency in app settings. To measure your heart rate go to 'Heart rate monitor'. Ensure that there is no gap between the back panel	start by entering a title, then choose the start and end date and time for the event. You can also set an alert tone to receive a timely reminder.
		-14 · Altitude & Barometer · Weather		• Once the hattery is fully charged, remove the charger	Pressing the functional crown button Turning on the wrist awake	The home screen is the watch face. From the home screen: Swipe left to access your fitness stats.	Open the NoiseFit app and turn on the Bluetooth and GPS positioning.	Unpair the watch from the phone's BT settings.	of the watch and the wrist. Hold still while it measures your heart rate.	Alarms
Endeavour Pro	Disposal and Recycling Information Decylotoxy Information	Calculator Camera Remote			T T	Swipe right to access shortcut screens. Swipe up to access quick settings.	Feed in your personal information and health goals in the App. Go to the 'Device' section in the App, tap on 'Add Device' then 'Search'.	I I	l Sleep	Select a time to set an alarm on the watch.
	• Regulatory Information 16 • Maintenance Instructions 17	Music World Clock	Charging Cable x 1		Long press the upper side button. POWER ON Long press the upper side button. POWER OFF	Swipe down to access notifications. ← Fitness Stats → Shortcuts ↑ Quick Settings ↓ Messages	Select NoiseFit Endeavour Pro and link the watch. OR YOU CAN FOLLOW THE STEPS BELOW: • Turn on the watch. • Scan the QR code on your watch using the NoiseFit App on your phone. • Select 'Pair with device' and wait for it to pair. • Select 'Add Device'. Choose your device from the range of devices.	 	Tap on 'Sleep' to view your previous sleep records. You can view your most recent sleep records and sleep quality in various sleep stages on the	Phone Access favourites, recents and keypad from here.
	Safety Instructions 17	• Find my Phone • Settings							NoiseFit app.	Timer
	• Customer Support 18	∘ Notifications ∘ Focus							Stress NoiseFit Endeavour Pro supports 24-hour stress level measurement and	You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up.
		GeneralWorkoutHR Broadcast							viewing of all-day measurement data. To measure stress levels in real-time, go to the 'Stress level' feature and check your stress level. Make sure your	Stopwatch
		Display and Brightness Menu Style							arms and wrists are still and there is no space between your watch and the wrist.	A stopwatch can be set on the smartwatch. You can also set lap times on the stopwatch.
		Sounds and Vibration Battery					On iOS: Choose Bluetooth pairing when you receive a pairing prompt. On Android: Connect it directly.		and the wrist.	
Please refer to this manual before using the product		Watch Sensors			· L					
• .	User Manua l for NoiseFit Endeavour Pro	User Manual for NoiseFit Endeavour Pro	01	User Manual for NoiseFit Endeavour Pro 02	User Manual for NoiseFit Endeavour Pro 03	User Manual for NoiseFit Endeavour Pro 04	User Manual for NoiseFit Endeavour Pro 05	User Manual for NoiseFit Endeavour Pro 06	User Manual for NoiseFit Endeavour Pro 07	User Manual for NoiseFit Endeavour Pro 08

blood Oxygen
NoiseFit Endeavour Pro supports viewing the highest and lowest values
of blood annous locals throughout the day. Concert that there is no see

of blood oxygen levels throughout the day. Ensure that there is no gap between the back panel of the watch and the wrist. Tap on 'Blood oxygen' to track. Hold still while it measures your blood oxygen level.

Your current directional heading in real time. It helps you orient yourself accurately whether you're hiking, traveling, or simply navigating through unfamiliar areas.

Check your current altitude above sea level and atmospheric pressure. It's useful for tracking elevation changes during outdoor activities like trekking or climbing.

From the NoiseFit App, go to 'My Device'. Select 'Weather Setting'

and turn on the toggle. Once you do that, you will be able to check real-time weather updates on the watch, weather prediction for the next 4 days. You can also change the temperature unit.

operations directly on your watch. Handy for everyday tasks like splitting bills or quick conversions without needing your phone.

it perfect for hands-free group shots or selfies.

You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected with the

You can play/pause music, go to the next/previous track and World Clock

Use this feature to find your mobile device by making it ring. Just tap on 'Find my phone', from your watch and your phone will start to ring, even if it is on Silent mode.

Notifications

The built-in Calculator allows you to quickly perform basic arithmetic

serial number etc.

Camera Remote Use your watch as a remote shutter for your smartphone camera.

Simply connect via Bluetooth and tap the watch to take photos, making

User Manual for NoiseFit Endeavour Pro

Restore Factory Settings Before handing over your smartwatch, you can erase all its data from here. Shut Down

Choose from different time zones and have a look at world clocks.

Find my Phone

SETTING

Select how you would want your notifications to appear.

Turn on DND. Focus During Workout or Sleep Focus

View device details such as model number, software version, and

09 User Manual for NoiseFit Endeavour Pro

Select your preferred language for the watch interface.

To turn off your device, click 'Shut Down.'

Set reminders, auto detection and voice broadcast for your workouts.

HR Broadcast

Set reminders, auto detection and voice broadcast for your workouts.

Display and Brightness

Choose brightness level, auto lock duration, schedule time for raise to wake. {cover to sleep}, choose to turn on or off the always-on display and select the default theme.

Choose how the Menu section appears on the watch. You can choose from Flow view or list view.

Sounds and Vibration

10 User Manual for NoiseFit Endeavour Pro

Set the ringtone level as per your preference Choose to turn it on or off

Vibration Choose default or enhanced vibration turn it on or off

Choose to turn on or off the vibration that occurs when you scroll the functional crown of the watch.

Choose to turn the battery saver on or off.

Choose to turn on or off the sensor for real-time heart-rate and blood oxygen.

Give your screen a personalised style by changing or customising the watch face

from the NoiseFit app or the watch. Choose and download cloud-based watch faces or create custom watch faces using the NoiseFit app.

Touch and hold the home screen. Swipe and choose from the watch faces

11 User Manual for NoiseFit Endeavour Pro

Go to 'Watch faces', select the watch face of your choice and tap save to change the watch face.

The NoiseFit Endeavour Pro smartwatch stores your activity data for up to 7 days

your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.

Device Information and Tips

1.5" AMOLED display

Blood oxygen monitor

Amoled Display with 1000 NITS Brightness

Heart rate monitor

530mAh battery

• Dual band 5 satellite

• 3W built in flashlight

Strava Integration

12 User Manual for NoiseFit Endeavour Pro

Al Watch faces

• 22mm strap

NoiseFit Endeavour Pro smartwatch contains the following:

How do I update my NoiseFit Endeavour Pro? • Go to 'My Profile' (the icon on the top left corner of the home page) on the NoiseFit App

Select 'About'

Choose 'Check for Updates'

13 User Manual for NoiseFit Endeavour Pro

Update if it's available

How do I find my watch's current firmware version? You can find the watch's current firmware on the watch. Go to 'Settings',

tap on 'General' to view the current firmware version.

On the NoiseFit App, tap on 'Device management' to know your current firmware version

How does the watch estimate how many calories have been burned? NoiseFit Endeavour Pro estimates how many calories you've burned based on the physical activity data and your heart rate.

How do I change my activity goals? You can do it through the NoiseFit App. In the App. select 'My Profile' and How do I log my weight?

You can log in your weight the first time you set up your NoiseFit App. However, you can update the weight later via the NoiseFit App. Go to 'Me', and tap on the section with your name on it to update your weight. You can update your nickname, birthday, sex and height as well.

DISPOSAL AND RECYCLING INFORMATION Electrical and electronic devices may not be disposed off with domestic

waste. Consumers are obliged by law to return the electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this reusing the materials or other forms of utilising old devices, you are

REGULATORY INFORMATION

USA: Federal Communications Commission (FCC) Statement This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: • This device may cause harmful interference, and this device must

accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment guarantee that interference will not occur in a particular installation.

14 User Manual for NoiseFit Endeavour Pro

If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

15 User Manual for NoiseFit Endeavour Pro

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help. The NoiseFit Endeavour Pro Watch is not a toy. The watch contains componer that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not a medical device and are not intended to diagnose, treat, cure or prevent any

disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medal devices or scientific measuremen

In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band dean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.

• Charge the battery in a cool, ventilated room.

16 User Manual for NoiseFit Endeavour Pro

• Keep the device dry and clean regularly and especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin

lightly in contact with your skin and there is a gap of about one finger's width between the wrist strap and your wrist. • Do not use household cleaners to clean the device. Use soap-free cleaners

For stains that are difficult to remove, it is recommended to scrub with

 The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimming pool, shower (cold water) and swimming in shallows. • Keep it away direct sunlight, high temperatures or humid conditions as it

SAFETY INSTRUCTIONS

• Do not disassemble the battery on your own. • Do not expose NoiseFit Diva to extremely high or low temperatures. The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.

• Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYE) or seek medical help.

can occur when a metallic object, such as a coin, causes the direct connection of positive and negative terminals of the battery.

• Keep the batteries out of children's reach and in a safe place to prevent danger. • Do not place the batteries in the water.

 Do not use your product in a sauna or steam room. • Do not dispose off batteries in the fire as that may cause an explosion. Dispose off used batteries in accordance with your local regulations. Do not dispose it as

household waste. • Use only the charging cable supplied to charge the battery. Do not charge for

• Do not attempt to repair or maintain the watch yourself, service and maintenance should be performed by authorised technicians only. Any device failure should be referred to our after-sales service personnel.

• To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at support gonoise, in

17 User Manual for NoiseFit Endeavour Pro

NOISE