

SAMSUNG **Helpline - Call : 1800 4767784 (1800 480 SAMSUNG) / 1800 7278844 (1800 480 SAMSUNG)**

This warranty card gives the key points related to warranty claim. For further details log on to www.samsung.com/suport.

Warranty Card TERMS & CONDITIONS

1. Proof of purchase is a requisite to claim warranty.
2. The product should have been purchased from an authorised Samsung Sales Dealer in India.
3. Warranty can be claimed only if the repair was carried out by the Samsung authorised service center.
4. Carry-in service or In-Home service applicability depends on the product category and Samsung policy.
5. In case of installation or demo of the product is applicable, can be waived only once and within 60 days from the date of purchase. In case of installation, any additional material required over and above the standard installation kit shall be on the chargeable basis.
6. In case of defective accessories, only the replacement will be repaired or replaced.
7. Cosmetics (Aesthetic / Plastic / Glass) damage and/or surface scratches are not covered under warranty.
8. The defective part(s) / product(s) which are occasioned by Samsung under this warranty shall be the property of Samsung.
9. While carrying out repair, Samsung may use accessories or parts that are new or refurbished or reconditioned.
10. Samsung shall not be liable for any losses or consequential losses due to product failure or the installed software.
11. Samsung shall be free to decide on whether or not to provide a software update for its products.
12. Samsung shall not be responsible for any loss or misuse of data, personal information, setting, third party software during product repair or repair of software update.
13. Samsung shall not be liable for any loss, cost, expense, inconvenience or damage that may result from its inability to use the product. In no circumstances shall Samsung be liable for any loss, cost, expense, inconvenience or damage exceeding the purchase price of the product.
14. Defects caused by customer negligence, tampering shall void the product warranty.
15. Any extended/extended warranty offered by Samsung has to be supported by relevant proofs.
16. Usage of power stabilizers or power line regulators is necessary unless explicitly mentioned by Samsung on product literature/installation booklet.
17. In case of defect arising out of installation done by party other than Samsung authorised party, the limited warranty will be applicable as per revised T&C as Samsung shall deem fit.
18. Regular cleaning, maintenance and cleaning of parts are necessary for a commercial solution in lieu of repairs.
19. In the event of any unforeseen circumstances, and spares not being available because of Samsung's prevailing depreciation policy will be under the purview of the purchaser and same shall be considered as a commercial solution in lieu of repairs.
20. Defects arising out of the following are not covered under warranty like Mishandling/Misuse, Improper ventilation, Improper choice of external material, Normal wear and tear, Physical damage and / or electrical damage caused by physical impact.
21. Complaints related to playability, compatibility, compatibility with external accessories, software, file systems, third party applications, signals, network connectivity, etc. shall not be considered as a commercial solution and not covered under warranty.
22. This warranty covers only the defects in products arising out of manufacturing or faulty workmanship.
23. This warranty covers repair/replace of products in place of product to product.
24. Maximum liability out of the warranty is the purchase price of the product less the cash value/RDP.
25. Warranty on certain parts/components/types of product to product.
26. Under certain conditions where warranty obligations cannot met, depreciation will be applicable on the existing product.

CUSTOMER DETAILS / WARRANTY CARD

Customer Serial No. _____		Customer copy (To be retained by customer)	
Model Name / No. _____		Date of Purchase: _____	
Address in Full _____		Mobile No. _____	
Telephone No. _____		Dealer Name & Address _____	

Customer's Signature & Date _____ Dealer's Signature with stamp _____
 (a) the Terms & Conditions of warranty)

The Warranty shall be null and void in any of the following cases, and in such cases Samsung may at its sole discretion repair the equipment on a chargeable basis. The decision of Samsung, whether a complaint falls in any of these categories or not shall be binding on the Purchaser.

- The duly filled warranty card/print of product is not presented to the service engineer in the time of repairs being undertaken / requested.
- The original serial number of the product is removed, altered or obliterated from the product.
- The product purchased is not used as per the rated power conditions or instructions mentioned in the INSTRUCTION MANUAL.
- The product is being used for commercial purpose OR if the product has been used excessively and beyond reasonable usage as permitted within the product instruction manual.
- Site (premises where the product is used keep) conditions that do not conform to the recommended operations of the product.
- Defects caused due to exposure to moisture/dampness/voltage/fume or environmental conditions or rapid changes in such conditions/conditions/conditions/shaking of food/liquids/influence of Chemical substances.
- Defects due to causes beyond control like lightning, abnormal voltage, spikes, external sources (e.g. cable/tap water connections), fire, water logging, natural calamities, corrosion, noise, theft, anti-social acts, acts of God or war or terrorist.
- Defects caused by household pests, rats, cockroaches, ants, pests, fungi, and any other animals/insects/birds.
- Defects caused due to negligence/omission of the Purchaser on account of periodic maintenance(s)/periodic servicing as mentioned in the instruction manual of the product.
- Defects caused due to usage of third party material/Samsung Authorized Consumables.
- Any modifications, including but not limited to, noting alterations, reverse engineering, unplug/breaking etc. of the original firmware(s) or software(s) of the product.
- Repair due to misuse/hard/physical repair alterations are not covered in warranty.
- Warranty does not cover repair due to external factors/external/atastia types.
- Warranty is valid only if the product is used as per its usage specification (e.g. personal, commercial etc.)
- Warranty shall be void if product has failed under certain conditions/types (e.g. water logging, misuse, etc.)

All disputes arising out of this warranty are subject to Delhi jurisdiction only.

Warranty period commences from the date of purchase of the product unless specified otherwise.

Product Group	Product Description	Warranty Period (Months)	Parts/Accessory Warranty (If applicable)
Refrigerator	Refrigerator	12	121 months for Digital Inverter Compressor**

** 15 months from date of purchase or 12 months from installation, whichever ever ends, +121 months from date of commissioning.
 * In case of parts warranty, labour cost and gas charging (collect) applicable will be chargeable as per the applicable rates.

Marking and Labelling Information as per Plastic Waste Management Rules

Brand Owner Name	EPR Registration No.	Thickness of Plastic Packaging (In case of CAT-II)
Samsung India Electronics Private Limited	BO-20-000-05-AAACS5123K-22	> 50 Micron

Contact SAMSUNG WORLD WIDE से संपर्क करें

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

अगर Samsung उत्पादों से संबंधित आपके कोई प्रश्न या टिप्पणियाँ हैं, तो कृपया SAMSUNG ग्राहक सेवा केंद्र से संपर्क करें।

Country देश	Contact Center संपर्क केंद्र	Web Site वेबसाइट
INDIA	1800 5 7267864 (1800 5 SAMSUNG) (Toll-Free) 1800 40 7267864 (800 40 SAMSUNG) (Toll-Free)	www.samsung.com/support
NEPAL	16600172667 (Toll Free for NTC Only) 9801572667	www.samsung.com/support
BANGLADESH	0961 2300300 0800390300 (toll free)	www.samsung.com/bd/support
SRI LANKA	+94115AMSUSUNG (+94117267864) +94117540540 +94115900000	www.samsung.com/support

This Product is RoHS compliant
यह उत्पाद RoHS अनुकूल है।

Contents सामगियाँ	
Safety information सुरक्षा जानकारी	3
Important safety symbols and precautions महत्वपूर्ण सुरक्षा प्रतीक और सावधानियाँ	4
Severe warning signs for installation स्थापना के लिए गंभीर चेतावनी चिह्न	5
Severe warning signs for using उपयोग के लिए गंभीर चेतावनी चिह्न	7
Caution signs for installation स्थापना के लिए सावधानी चिह्न	9
Caution signs for using उपयोग के लिए चेतावनी चिह्न	9
Caution signs for cleaning and maintenance सफाई और रखरखाव के लिए सावधानी चिह्न	11
Severe warning signs for disposal निपटन के लिए गंभीर चेतावनी चिह्न	12
This appliance is intended to be used in household and similar applications such as यह उपकरण केवल घरेलू या इसी प्रकार के स्थानीय पर उपयोग किए जाने के लिए बनाया गया है, जैसे कि:	12
Installation स्थापना	13
Refrigerator at a glance रेफ्रिजरेटर एक नज़र में	14
Step-by-step installation चरण-दर-चरण स्थापना	15
Operations परिचालन	18
Adjusting the temperature control तापमान नियंत्रण समायोजित करना	18
Special features विशेष सुविधाएँ	19
Maintenance रखरखाव	21
Handle and care प्रबंधन और देखभाल	21
Cleaning सफाई	22
Troubleshooting समस्या-निवारण	23
Instructions about the WEEE WEEE के बारे में निर्देश	25
Warranty Card	26

Safety Information सुरक्षा जानकारी

- Before operating the appliance, please read this manual thoroughly and retain it for your reference.
- Use this appliance only for its intended purpose as described in this instruction manual.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Warnings and Important Safety Instructions in this manual do not cover all the possible conditions that may occur. It is your responsibility to use common sense, caution, and care when installing, maintaining, and operating your appliance.
- Because these following operating instructions cover various models, the characteristics of your refrigerator may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service center or find help and information online at www.samsung.com.

Check the compressor label on the rear of the appliance to see which refrigerant is used for your refrigerator.

- It is hazardous for anyone other than an Authorised Service Person to service this appliance.
- Do not drink the liquid which is inside the cool pack although it is not toxic to human body.
- Do not install the appliance near a water stabilizer.

उपकरण के संभालने से पूर्व, कृपया इस मालिशिका को धीरे तरह पढ़ें और इसे अपने सदस्य के लिए रखें।

- इस उपकरण का उपयोग इस निर्देश पुस्तिका में वर्णित नियत उद्देश्य के लिए ही किया जाना चाहिए।

- इस उपकरण का उपयोग 8 साल या उससे ऊँचे बच्चों तथा किशोर शरीरक, संवेदक या मानसिक क्षमता या कम अनुभव एवं ज्ञान वाले व्यक्तिगणों द्वारा किया जा सकता है बशर्त कि उन्हें उपकरण को सुरक्षित तरीके से उपयोग से जुड़े पर्यवेक्षण को निर्देश प्रदान किए गए हैं और वे इससे उपकरण खराब को समझते हैं। बच्चों को उपकरण के साथ नहीं खेलने देना चाहिए।
- पर्यवेक्षण के बिना बच्चों को सफाई और उपयोगकर्ता रखरखाव नहीं करना चाहिए।

- इस निम्नलिखित-पुस्तिका में बतायी गई महत्वपूर्ण सुरक्षा निर्देशों में पठित हो सुनने वाले सभी समस्त पर्यवेक्षितगणों तथा व्यक्तिगणों नहीं शामिल हैं। यह आपकी जिम्मेदारी है कि आप स्थानित, रखरखाव, तथा अपने उपकरण का संचालन करते समय सहज ज्ञान, सर्तकता एवं सावधानी का प्रयोग करें।

● बिजली के तार को अधिक न मोड़ें या इस पर कोई भारी चीज़ न रख दें।

● रेफ्रिजरेटर के पास प्यूलरीसोना का उपयोग करने से बिजली ओत सकता है या आग लग सकती है।

● फ़िक्स के पास जलनशील सामान न रखें।

● तार को भीखे लटकक बिजली के पन्ना को उचित स्थिति में कनेक्ट करें।

● अगर आप बिजली के पन्ना को उन्ट लगाते हैं, तो तार कट सकता है और आग या बिजली का झटका लग सकता है।

● रेफ्रिजरेटर के पिछले हिस्से दूबारा बिजली के पन्ना का कुचलना या क्षतिग्रस्त न होना सुनिश्चित करें।

● रेफ्रिजरेटर का स्थान बदलने के दौरान, बिजली के तार को क्षतिग्रस्त न होने दें, इससे आग का जोखिम हो सकता है।

● इस उपकरण को कुछ इस प्रकार लगाया जाना चाहिए कि यह बिजली के पन्ना की पहुँच में हो।

● इसा करने में बिजनेस रूले पर बिजली के रिसाके के कारण बिजली का झटका या आग लग सकती है।

● सीधे बिजली के खंभे से तार पकस कर उपकरण को न घुसायें।

● This appliance must be properly grounded

● Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.

● You must ground the refrigerator to prevent any power leakages or electric shocks caused by current leakage from the refrigerator.

● This may result in an electric shock, fire, explosion, or problems with the product.

● Never plug the power cord into a socket that is not grounded correctly and make sure that it is in accordance with local and national codes.

● यह उपकरण ठीक प्रकार डाइरेक्ट किया गया जाना चाहिए।

● उपकरण को न मीस पाइप, प्लास्टिक के पाानी के पाइप या टेलीफोन लाइन से याउंट न करें।

● बिजली लोडक रोकने या रेफ्रिजरेटर से दर्रमाना लोडक के कारण बिजली के झटके से बिजली के लिए आपको रेफ्रिजरेटर को बाइक कर देना चाहिए।

● इससे बिजली का झटका, आग लग सकती है, बिस्फोट हो सकता है या उत्पाद में समस्याएँ हो सकती हैं।

● बिजली के पन्ना को कभी भी ऐसे सॉकेट में न लगाएँ जिसे ठीक प्रकार याउंट नहीं किया गया है और सुनिश्चित करें कि यह स्थानीय और राष्ट्रीय संहिताओं के अनुपालन में है।

● If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

● The fuse on the refrigerator must be changed by a qualified technician or service company.

● Failing to do so may result in an electric shock or personal injury.

● यह बिजली की तार खराब हो, तो जोखिम से बचने के लिए इसे निर्माता, इसके सेवा एजेंट या समान रूप से योग्य व्यक्ति द्वारा बदल जाना चाहिए।

● रेफ्रिजरेटर पर लगा प्यूलरी योग्य तम्बनीशियन या सर्विस कंपनी द्वारा ही बदला जाना चाहिए।

● ऐसा करने में सहूल रहने पर बिजली का झटका या निजी घोट लग सकती है।

Safety information सुरक्षा जानकारी

Severe warning signs for using उपयोग के लिए गंभीर चेतावनी चिह्न

⚠ WARNING चेतावनी

- Do not touch the power plug with wet hands.
- This may result in an electric shock.
- Do not store articles on the top of the appliance.
- When you open or close the door, the articles may fall and cause a personal injury and/or material damage.
- Do not put a container of water on the refrigerator.
- If spilled, there is a risk of fire or electric shock.
- Do not let children hang on the door, if not, a serious injury may occur.
- There is a Risk of choking and entrapment.
- Do not let children enter inside the refrigerator.
- Do not keep volatile or inflammable objects or substances (benzene, ether, propane gas, alcohol, ether, LP gas and other such products etc.) in the refrigerator.
- This may result in fire or explosion.
- Do not place a lighted candle in the refrigerator for removing bad odours.
- This may result in an electric shock or fire.
- Do not use a candle on top of the appliance when a blackout.
- Do not touch the inside walls of the freezer or products stored in the freezer with wet hands.
- This may cause frostbite.
- Do not use electrical, mechanical devices or any other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerator circuit.
- Use the water tank, ice tray water cubes only with potable water.
- Do not keep the keys of the refrigerator within the reach of children as there is a possibility of children being locked inside.

❗ गीले हाथों से बिजली के तारों को स्पर्श न करें।

- इसका कारण बिजली का झटका लग सकता है।
- उपकरण के शीर्ष पर सामान न रखें।
- जब आप दरवाजा खोलते या बंद करते हैं, तो सामान गिर सकता है तथा उससे व्यक्तिगत या वस्तु को चोट लग सकती है और/या उपकरण क्षतिग्रस्त हो सकता है।
- पानी से भरे पात्र को उपकरण पर न रखें।
- इससे धक्कने से आग या बिजली के झटके का खतरा हो सकता है।
- बच्चों को दर पर लटकने न दें। ऐसा नहीं करने पर, गंभीर चोट लग सकती है।
- फ्रिज में अस्थिर या ज्वलनशील वस्तुओं या पदार्थों (बेन्जीन, थिना, प्रोपेन गैस, अल्कोहल ईंथर, LP गैस और ऐसे अन्य उत्पादों) न रखें।
- इससे आग लग सकती है या विस्फोट हो सकता है।
- रीफ्रिजरेटर के अंदरूनी हिस्से को सूखाने के लिए हेयर ड्रायर का उपयोग न करें।
- दुर्घट्ट हारने के लिए रीफ्रिजरेटर के अंदर जलती मोमबत्ती न रखें।
- इसका कारण बिजली का झटका या आग लग सकता है।
- इससे हानि पर उपकरण के, उपरो हिस्से में मोमबत्ती लग सकती है।
- रीफ्रिजरेटर की यांत्रिक बच्चों की पहुँच के भीतर न रखें क्योंकि इससे बच्चों के अंदर बंद होने की आशंका रहती है।

Refrigerator

User manual उपयोगकर्ता

RR19/20/21/22/23/24**

Free Standing Appliance फ्री स्टैंडिंग उपकरण

चूँकि ये निम्नलिखित संचालन निर्देश विभिन्न मॉडल पर लागू होते हैं, इसलिए आपके रेफ्रिजरेटर की विशेषताएँ इस मार्गदर्शिका में वर्णित विशेषताओं से थोड़ी भिन्न हो सकती हैं और हो सकती हैं सभी चेतावनी पढ़ें लागू न हो।

अगर आपके कोई प्रश्न या शंकाएँ हैं, तो अपने निकटतम सेवा केंद्र से संपर्क करें या www.samsung.com पर ऑनलाइन सहायता और जानकारी प्राप्त करें।

रेफ्रिजरेटर के रूप में R-600a या R-134a का उपयोग किया जाता है। आपके रेफ्रिजरेटर के लिए उपयोग किए गए प्रशीतक का पता लगाने के लिए उपकरण के पिछले हिस्से में कंप्रेसर लेबल देखें।

अधिकृत सेवा कर्मचारी के अलावा अन्य व्यक्तियों के लिए इस उपकरण की मरम्मत करना जोखिमपूर्ण हो सकता है।

कूल पैक अंदर मौजूद तरल पदार्थ को न पीएं हालाँकि यह मानव शरीर के लिए विषाक्त नहीं होता है।

इस उपकरण को वोल्टेज स्टेबलाइज़र के पास स्थापित न करें।

Warning; Risk of fire / flammable materials

चेतावनी: आग लग सकती है/ज्वलनशील सामग्रियाँ

Important safety symbols and precautions

सुरक्षित रूप से सुरक्षा प्रतीक और सावधानियाँ

WARNING चेतावनी

Hazards or unsafe practices that may result in **severe personal injury or death** खतरा या असुरक्षित व्यवहार जिससे गंभीर निजी घोट लग सकती है या मृत्यु हो सकती है।

CAUTION सावधान

Hazards or unsafe practices that may result in **minor personal injury or property damage** खतरा या असुरक्षित व्यवहार जिससे हल्की निजी घोट लग सकती है या संपत्ति की क्षति हो सकती है।

NOTE नोट

Do NOT attempt. इसका प्रयास न करें।

Do NOT disassemble. इसे खोलें नहीं।

Do NOT touch. इसे स्पर्श न करें।

Follow directions carefully. निर्देशों का सावधानीपूर्वक पालन करें।

गोले हाथों से फ्रीजर के अंदरूनी दीवारों या फ्रीजर में रखे उत्पादों को न छुएँ।

इससे शीतल हो सकता है।

विद्युत्करण प्रक्रिया को तेज करने के लिए निर्माता द्वारा अनुशंसित मशीनी उपकरण या किसी दूसरे उपाय के अलावा किसी अन्य उपकरण या उपाय का उपयोग न करें।

प्रशीतक सफ़ाई को क्षति न पहुँचाएँ।

पानी के टैंक, बर्फ की ट्रे, पानी के क्यूब को केवल पीने योग्य पानी से ही भरें।

★ This product is intended only for the storage of food in a domestic environment.

Bottles should be stored tightly together so that they do not fall out.

Do not insert hands, feet or metal objects (such as chopsticks, etc.) into the bottom or the back of the refrigerator.

This may result in an electric shock or injury.

Any sharp edges may cause a personal injury.

★ यह उत्पाद घरेलू परिवेश में केवल खाद्य पदार्थ के भंडारण के लिए नियत है।

बोतलों को एकदम सटाकर रखना चाहिए ताकि वे गिर न जाएँ।

हाथों, पैरों या धातु की वस्तुओं (जैसे चाँपस्टिक, आदि) को रेफ्रिजरेटर के निचले या पिछले भाग में न डालें।

इसके कारण बिजली का झटका या चोट लग सकती है।

किसी भी नुक़ीले किनारे से व्यक्तिगत रूप से चोट लग सकती है।

Do not attempt to repair, disassemble, or modify the appliance yourself.

Do not use any fuse (such as copper, steel wire, etc.) other than the standard fuse.

When repairing or reinstalling the appliance is required, contact your nearest service center.

Failing to do so may result in an electric shock, fire, problems with the product, or injury.

स्वयं उपकरण की मरम्मत, उसे खोलने या संशोधित करने का प्रयास न करें।

मानक फ्यूज के अलावा किसी अन्य फ्यूज (जैसे तंबे, स्टील के तार, आदि) का उपयोग न करें।

जब उपकरण की मरम्मत या पुनः स्थापना की आवश्यकता हो, तो अपने निकटतम सेवा केंद्र से संपर्क करें।

एखा कपड़ों में विकरल खरोंच पर बिजली का झटका, आग लग सकती है, उत्पाद में मरम्मतपूर्ण हो सकती है या चोट लग सकती है।

★ If the appliance generates a strange noise, a burning or smell or smoke, unplug the power plug immediately and contact your nearest service center.

Failing to do so may result in an electric or fire hazards.

If any dust or water is in the refrigerator, pull out power plug and contact your Samsung Electronics service center.

Otherwise there is a risk of fire.

रेफ्रिजरेटर

मार्गदर्शिका

SAMSUNG

Safety information सुरक्षा जानकारी

- ❗ Unplug the power plug from the wall socket.
दीवार के सॉकेट से बिजली के प्लग को निकाल दें।
- ⚡ Make sure the machine is grounded to prevent electric shock.
बिजली के झटके से बचने के लिए सुनिश्चित करें की मशीन स्थिर है।
- 📞 Call the contact center for help. सहायता के लिए संपर्क केंद्र पर कॉल करें।

These warning signs are here to prevent injury to you and others. Please follow them carefully.
After reading this section, keep it in a safe place for future reference.
ये चेतावनी संकेत आपको और दूसरों को घोट लगने से बचाने के लिए यहाँ मौजूद हैं। कृपया उनका सावधानी से पालन करें।

इन खंड को पढ़ने के बाद, भविष्य संदर्भ के लिए उसे किसी सुरक्षित जगह पर रखें।

Severe warning signs for installation

स्थापना के लिए गंभीर चेतावनी चिह्न

- ⚠ **WARNING चेतावनी**
- ❗ Do not plug several appliances into the same multiple power board.
The refrigerator should always be plugged into its own individual electrical outlet which has a voltage rating that matched the rating plate.
• This provides the best performance and also prevents overloading house wiring circuits, which could cause a fire hazard from overheated wires.
• If the wall socket is loose, do not insert the power plug.
- There is a risk of electric shock or fire.
• Do not use a cord that shows cracks or abrasion damage along its length or at either end.
• Do not bend the power cord excessively or place heavy articles on it.
• Do not use aerosols near the refrigerator, it may cause an explosion or fire.
• Do not store flammable stuff near the refrigerator.
• Connect the power plug in proper position with the cord hanging down.
- If you connect the power plug upside down, wire can get cut off and cause a fire or electric shock.
• When moving the refrigerator, be careful not to roll over or damage the power cord.
- This constitutes a fire hazard.
• This appliance should be positioned in such a way that it is accessible to the power plug.
- Failing to do so may result in an electric shock or fire due to electric
• Do not use a hooking power by direct tapping from the electric line leakage.
- ❗ एकत्रीकृत पावर बोर्ड में अनेक उपकरणों के प्लग न लगाएं।
रेफ्रिजरेटर का प्लग हमेशा अपने अलग बिजली के आउटलेट में लगा होना चाहिए जिसकी वोल्टेज रेटिंग, रेटिंग प्लेट से मेल खाती हो।
• इससे सर्वोत्कृष्ट कार्य-निष्पादन मिलता है और इससे घर का वायरिंग सर्किट ओवरलोड होने से भी बचाव है, जिससे अत्यधिक गर्म ताप से आग का खतरा हो सकता है।
• यदि दीवार का सॉकेट ढीला हो, तो उसमें पावर प्लग न लगाएं।
• इससे बिजली के झटके या आग का जोखिम होता है।
• ऐसे किसी तार का उपयोग न करें जिसकी पूरी लंबाई या किसी छोर में दरारें या घर्षण क्षति नज़र आ रही हो।

5

Safety information सुरक्षा जानकारी

- ❗ अगर उपकरण अजीब आवाज़, जलन या गंध या धुआँ पैदा करता है, तो तत्काल बिजली प्लग निकालें और अपने निकटतम सेवा केंद्र से संपर्क करें।
- ऐसा करने में विफल रहने पर बिजली या आग के जोखिम हो सकते हैं।
- अगर रेफ्रिजरेटर में धूल या पानी है, तो बिजली के प्लग को निकाल दें और अपने Samsung Electronics सेवा केंद्र से संपर्क करें।
- अन्यथा, आग लगने का जोखिम बना रहता है।

Caution signs for installation

स्थापना के लिए सावधानी चिह्न

- ⚠ **CAUTION सावधान**
- ❗ Keep ventilation opening in the appliance enclosure or mounting structure clear of obstruction.
• The installation or any service of this appliance is recommended by a qualified technician or service company.
- Failing to do so may result in an electric shock, fire, explosion, problems with the product, or injury.
• Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops)
- Deteriorated insulation on electrical parts may cause an electric shock or fire.
- ❗ उपकरण की अंदरूनी जगह या आधार संरचना में मौजूद वायुसंचार छिद्र में किसी भी तरह की रुकावट न आने दें।
• इस उपकरण की स्थापना या कोई भी सर्विस, योग्य तकनीशियन या सर्विस कंपनी से करने की अनुमति की जाती है।
- ऐसा करने में विफल रहने पर बिजली का झटका लग सकता है, आग लग सकती है, विस्फोट हो सकता है, उत्पाद में समस्याएँ हो सकती हैं या घोट लग सकती है।

Caution signs for using उपयोग के लिए चेतावनी चिह्न

- ⚠ **CAUTION सावधान**
- ❗ Do not place glass or bottles or carbonated beverages into the freezer.
• The container may freeze and break, and this may result in injury.
• There is no need to disconnect the refrigerator from the power supply if you will be away for less than three weeks. But, remove all the food if you are going away for the three weeks or more. Unplug the refrigerator and clean it, rinse and dry.
• Be careful that your fingers are not caught in.
• सावधान रहें कि यह आपकी उंगलियों पर न लगे।

9

[illegible]

