





# AIRDOPES LOOP SMART GUIDE


## PACKAGE CONTENTS



## PRODUCT LABELLING




CTC  
(CAPACITIVE TOUCH CONTROL)



PLEASE WEAR THE EARBUD MARKED "L" IN YOUR LEFT EAR AND "R" IN YOUR RIGHT EAR TO ENSURE CLEAR COMMUNICATION OVER CALLS.



## SMART POWER ON/OFF




ON OFF

Insta Wake N'Pair (IWP™)



## MANUAL POWER ON/OFF




ON  
Long Touch  
3 Seconds

OFF  
Long Touch  
5 Seconds



## BLUETOOTH PAIRING



1

2


Choose "Airdopes Loop" to Connect



## FUNCTIONS (CALL/MUSIC)

- Tap Once
- Tap Twice
- L Left Earbud
- R Right Earbud

### TOUCH FUNCTIONS




Note: The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.




## FUNCTIONS (VOICE ASSISTANT/ BEAST™ MODE / PRIVATE MODE)

- Long Touch (3s)
- L Left Earbud
- R Right Earbud
- Tap 3 Times



ACTIVATE  
GOOGLE VOICE  
ASSISTANT/SIRI



ACTIVATE/DEACTIVATE  
PRIVATE MODE

ACTIVATE/DEACTIVATE  
GAMING BEAST™ MODE

Note: The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.



## RESET AIRDOPES

### FORGET DEVICE



### PRESS RESET BUTTON FOR 5 SECONDS



Reset Button

CLOSE THE LID AND WAIT FOR A FEW SECONDS. OPEN CASE & PERFORM A FRESH CONNECTION.



Note: All four case LEDs flash 5 times to indicate successful reset.



## LED STATUS GUIDE

<10% : ONE LED BLINKS 4 TIMES QUICKLY AND THEN TURNS OFF	LOW BATTERY
LED BLINKS 1 TIME EVERY SECOND	CHARGING
100% : ALL LEDS REMAIN SOLID ON	FULLY CHARGED



<20% : RED LED FLASHES 3 TIMES EVERY 30 SECONDS WITH A TONE PROMPT EVERY 5 MINUTES	LOW BATTERY
SOLID RED LED	CHARGING
100% : LED TURNS OFF	FULLY CHARGED



## SPECIFICATIONS

Headphone Type	OWS Earbuds
Bluetooth Version	5.3
Music Playtime	Up to 50 hours (at 60% volume)
Number of ENx™ Equipped Mics	4
IWP™ Tech	Yes
BEAST™ Mode	Yes; 40ms Low Latency
Transmission Range	10 m
Driver Size	12 mm*2
Supported Codec	MP2, MP3, WMA, APE, FLAC, AAC, MP4, M4A, WAV, AIF, AIFC
Frequency	20 Hz-20 kHz
Battery	480 mAh (Case); 50 mAh*2 (Earbuds)
ASAP™ Charge	Yes; 10 mins charge = 200 mins playtime
Charging Time	Up to 2 hrs (Case); 40 mins (Earbuds)
Charging Interface	USB Type-C
Water Resistance	IPX4



## CHARGING GUIDELINES

### Charging norms & Precautionary Guidelines: -

- 1) Charger/Brick/Adapter : 5V/2A
- 2) Cable/Wire : Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be used to charge the product as long as the above-mentioned norms are followed.



USB-C PORT

Note: (1) Before using the earbuds for the first time, it is recommended to fully charge them. (2) Please note that the earbuds cannot be used / switched on while charging.



## LEARN MORE ABOUT YOUR PRODUCT



Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information

