


GX Charge

User Manual

BOULT

Know your Gx Charge



What's in the box ?

Neckband
USB Charging Cable
User Manual
Warranty Card

Product specification

Product Name – Bluetooth Wireless Earphones
Model – Boult Audio ProBass
Bluetooth Version – V5.2
Speaker – 10mm
Bluetooth Range – ~10m/33ft (without any obstacles)
Neckband Charging Time – 45 mins
Frequency Range – 20Hz – 20KHz
Input – 5V 1A

How to connect your GX Charge

Turn on the Bluetooth function on your phone.

While in power-off state, press and hold the multifunction button (MFB) on your neckband for 5 seconds till the red and blue light flashes alternatively with the “Pairing” sound.

In your phone, select the Bluetooth name “Boult Audio ProBass” for connecting.

When the pairing is successful, you will hear the “Connected” sound.

How to use your GX Charge

(A). Power ON/OFF:

Power ON: Press and hold the multifunction button (MFB) for 3 seconds until the blue light flashes.

Power OFF: Press and hold the multifunction button (MFB) for 5 seconds until the red light is on for 2 seconds.

(B). Call Answer

Answer by phone or press the MFB.

(C). Call End

End by your phone or press the MFB.

(D). Call Reject

Reject your phone or press and hold the MFB for 2 seconds.

(E). Last Number Redial

Quickly tap the MFB twice to redial the last dialed phone number.

(F). Play Music

Press the MFB to play/pause music while the music is playing.

Biggest Drivers
in this Segment

14mm



(G). Volume Adjust

Tap the Volume+ or Volume- button to increase or decrease the volume.

(H). Track Control

Press and hold the Volume+ button to skip to the next song.
Press and hold the Volume- button to play the previous song.

(H). Voice Assistant

Press and hold the MFB button for 2 seconds to activate and talk to your phone's voice assistant.

Do's and Don'ts

Don't expose the device to extreme temperatures. Use a USB charger of DC 5V to charge the headset if necessary.

Don't disassemble, repair, or alter the headset yourself or through third party vendors.

Don't clean the headset with chemical solvent

Don't discard the headset or put it in a fire or high-temperature environment in case of danger

Voice Prompts

You will hear "power on" when the headset powers on.

You will hear "power off" when the headset powers off.

You will hear "connected" when the headset is paired.

You will hear "low battery" when the headset is in low power status

Maintenance Instructions

Warranty is valid/invalid only basis of the below criteria:

The product should be purchased through legal and formal channels to be applicable for warranty.

Damaging the product intentionally/unintentionally, or due to natural disasters, etc. is not covered in the warranty.

Sky's Choice

