Manuals+

Manuals.plus / › Samsung / › Samsung Galaxy S24 S-View Wallet Case Instruction Manual (Model EF-ZS921CVEGUS)

Samsung EF-ZS921CVEGUS

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Samsung Galaxy S24 S-View Wallet Case Instruction Manual

Model: EF-ZS921CVEGUS

Introduction

This manual provides instructions for the proper use and care of your Samsung Galaxy S24 S-View Wallet Case. This protective cover is designed to enhance your device experience with smart screen view functionality and a convenient card holder. The case is made with eco-conscious materials, containing a minimum of 27% post-consumer recycled content in the plastic portion and a minimum of 4% bio-based content in the outer frame.



Image: The Samsung Galaxy S24 S-View Wallet Case in Violet, closed and ready for use.

Advertisements

Setup

Installing Your Phone

To install your Samsung Galaxy S24 into the S-View Wallet Case, align the phone with the case's frame. Gently press the phone into the case, ensuring all corners are securely seated. The case is designed for a snug fit to provide optimal protection.



Image: A hand gently pressing the Samsung Galaxy S24 into the open S-View Wallet Case.

Using the Card Holder Pocket

The S-View Wallet Case features a hidden pocket on the inside flap. This pocket is designed to hold one standard-sized card, such as an ID or credit card. Insert the card into the slot with the case open. Ensure the card is fully seated within the pocket before closing the case.



Image: A hand inserting a credit card into the designated slot on the inner flap of the S-View Wallet Case.

Operating Instructions

Small Screen View

The S-View Wallet Case allows you to view important information without opening the cover. The small screen window displays notifications, incoming calls, and music controls. This feature is active when the case is closed.

- **Notifications:** Glance at new messages, alerts, and other notifications.
- **Incoming Calls:** See who is calling and manage calls directly from the small screen.
- **Music Control:** Play, pause, skip tracks, and adjust volume for your music playback.




Image: The small screen window of the S-View Wallet Case showing various notifications and time.

Advertisements

Finger Tap Control

Interact with the small screen view using simple finger taps. You can answer or reject calls, pause or resume music, and dismiss notifications with a single tap on the visible screen area, without needing to open the case.



Image: A hand tapping on the small screen window of the S-View Wallet Case to control phone functions.

Maintenance

To maintain the appearance and functionality of your S-View Wallet Case, follow these guidelines:

Advertisements

- **Cleaning:** Wipe the case gently with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the polyurethane material.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Material Care:** The case is constructed from polyurethane and contains recycled and bio-based content. Handle with care to preserve its integrity.

Troubleshooting

Small Screen View Not Functioning

- Ensure your Samsung Galaxy S24 is correctly seated within the case.
- Verify that the case is fully closed.
- Check your phone's settings for S-View cover functionality. Navigate to **Settings > Advanced features > Accessories** and ensure the 'Smart cover' or 'S-View cover' option is enabled.
- Restart your phone to resolve potential software glitches.

Card Not Fitting in Pocket

- The card slot is designed for a single standard-sized card. Attempting to insert multiple cards may cause damage to the case or prevent proper closure.
- Ensure the card is inserted correctly and not obstructed.

Advertisements

Specifications

Feature	Detail
Brand	Samsung
Model Number	EF-ZS921CVEGUS
Compatible Phone Models	Samsung Galaxy S24
Material	Polyurethane
Color	Violet
Form Factor	Basic Case, Flip & Wallet Case
Product Features	Smart Small Screen View, Finger Tap Control, Card Holder Pocket, Anti-Slip
Water Resistance Level	Not Water Resistant
UPC	887276815787

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official Samsung support website. Specific warranty terms may vary by region and purchase date.
Samsung Support: www.samsung.com/support/

© 2026 Samsung. All rights reserved.

Advertisements

Advertisements

Related Documents - EF-ZS921CVEGUS

	Samsung SMART LED View Cover User Manual User manual for the Samsung SMART LED View Cover (EF-NG980, EF-NG985, EF-NG988). Learn about setup, device layout, call handling, screen unlocking, and LED image settings. Visit Samsung.com for support.
	Samsung Book Cover Keyboard - AI Key User Guide Comprehensive user guide for the Samsung Book Cover Keyboard - AI Key and Book Cover Keyboard Slim - AI Key, detailing device layout, attaching the keyboard, using keys and touchpad, storing and replacing the S Pen, and important usage notices. Includes model numbers EF-DX720, EF-DX725, EF-DX820, EF-DX825, EF-DX920, EF-DX925.
	Samsung Book Cover Keyboard User Manual User manual for Samsung Book Cover Keyboard and Slim models (EF-DX710, EF-DX810, EF-DX910, EF-DX715, EF-DX815, EF-DX915). Includes setup, usage, and maintenance instructions.
	Samsung Book Cover Keyboard AI Key User Guide Official user guide for Samsung Book Cover Keyboard AI Key and Book Cover Keyboard Slim AI Key, detailing setup, features, and usage for models EF-DX720, EF-DX725, EF-DX820, EF-DX825, EF-DX920, and EF-DX925.
	Samsung Book Cover Keyboard AI Key User Guide This user guide provides comprehensive instructions for the Samsung Book Cover Keyboard AI Key and Book Cover Keyboard Slim AI Key. It covers device setup, key and touchpad usage, S Pen storage, and important safety precautions for models EF-DX720, EF-DX725, EF-DX820, EF-DX825, EF-DX920, and EF-DX925.
	Samsung Book Cover Keyboard Slim AI Key User Guide User guide for the Samsung Book Cover Keyboard Slim and Book Cover Keyboard with AI Key (EF-DX620, EF-DX625), detailing setup, usage, features, and precautions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

SAMSUNG EF-ZS921CVEGUS

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Samsung EF-ZS921CVEGL

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

Privacy Policy · DMCA