

[Manuals.plus](#) /

› [Samsung](#) /

› Samsung IC050 Type-C Earphone User Manual

Samsung IC050

Samsung IC050 Type-C Earphone User Manual

INTRODUCTION

Thank you for choosing the Samsung IC050 Type-C Earphones. These earphones are designed to provide high-quality audio with a secure and comfortable canal-type fit. They feature a convenient Type-C interface for broad compatibility and ergonomic 3-button controls for managing calls and media playback. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earphones.

WHAT'S INCLUDED

Please check the package contents to ensure all items are present:

- Samsung IC050 Type-C Earphones
- Ear Tips (Sizes S/M/L)
- Leaflet (Quick Start Guide/Warranty Information)



Figure 1: Contents of the Samsung IC050 Type-C Earphone package, including the earphones, various ear tip sizes, and documentation.

SETUP GUIDE

Connecting Your Earphones

1. Locate the USB Type-C port on your smartphone or compatible device.
2. Insert the Type-C connector of the earphones firmly into the device's Type-C port. Ensure it is fully seated for a stable connection.
3. Your device should automatically detect the earphones. If not, check your device's audio settings.

Wearing Your Earphones

For optimal sound quality and comfort, select the ear tips that best fit your ears. The package includes Small (S), Medium (M), and Large (L) ear tips.

1. Gently insert each earbud into your ear canal.
2. Adjust the position until you achieve a snug and comfortable fit. A good seal is crucial for bass response and noise isolation.



Figure 2: The Samsung IC050 Type-C Earphones with their cable and Type-C connector, illustrating the design for proper ear placement.

OPERATING YOUR EARPHONES

Call and Media Controls

The Samsung IC050 earphones feature an inline remote with three buttons for easy control of your audio and calls:

- **Volume Up (+) Button:** Press to increase volume.
- **Volume Down (-) Button:** Press to decrease volume.
- **Multi-function Button (Center):**
 - **Single Press:** Play/Pause music; Answer/End a call.
 - **Double Press:** Skip to the next track during music playback.
 - **Triple Press:** Go back to the previous track during music playback.
 - **Press and Hold:** Reject an incoming call; Activate voice assistant (if supported by your device).



Figure 3: Close-up view of the inline remote control, highlighting the volume up, volume down, and multi-function buttons.

CARE AND MAINTENANCE

Cleaning

- Regularly clean the ear tips with a soft, dry cloth to remove earwax and debris.
- If necessary, remove the ear tips and wash them with mild soap and water. Ensure they are completely dry before reattaching.
- Wipe the earbud bodies and cable with a soft, slightly damp cloth. Avoid using harsh chemicals or abrasive materials.

Storage

- Store your earphones in a clean, dry place when not in use.
- Avoid extreme temperatures and direct sunlight.
- While the cable is designed to be tangle-free, avoid tightly coiling or bending it sharply to prevent internal damage.

TROUBLESHOOTING

No Sound

- Ensure the Type-C connector is fully inserted into your device.
- Check the volume level on your device and using the inline controls.
- Verify that the correct audio output device is selected in your device's sound settings.
- Test the earphones with another compatible device to rule out a device-specific issue.

Poor Sound Quality

- Ensure the ear tips provide a good seal in your ear canal. Try different sized ear tips.
- Clean the ear tips and earbud grilles to remove any obstructions.
- Check if the audio source (music file, streaming service) is of high quality.
- Avoid excessive volume, which can distort sound.

Microphone Not Working

- Ensure the earphones are securely connected to your device.
- Check your device's microphone settings to ensure the earphone microphone is selected.
- Ensure the microphone on the inline remote is not covered or obstructed.

PRODUCT SPECIFICATIONS

Brand	Samsung
Model Name	IC050
Color	Black
Ear Placement	In Ear
Form Factor	In Ear
Impedance	30 Ohms
Headphone Jack	USB-C
Control Type	Media Control
Control Method	Touch
Cable Features	Tangle Free
Material	Plastic
Item Weight	15.8 Grams

WARRANTY INFORMATION

The Samsung IC050 Type-C Earphones come with a**6-month manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the leaflet included in your product package.

CUSTOMER SUPPORT

For any assistance, technical support, or warranty inquiries regarding your Samsung IC050 Type-C Earphones, please contact Samsung customer service:

- **Importer:** Samsung India Electronics Pvt Ltd
- **Address:** 6th Floor, DLF Centre, Sansad Marg, New Delhi - 110001
- **Email:** support.india@samsung.com
- **Toll-Free Number:** 1800 40 7267864