

HAMMER Bash 2.0

HAMMER Bash 2.0 Wireless Bluetooth Headphones User Manual

Model: Bash 2.0

INTRODUCTION

Thank you for choosing the HAMMER Bash 2.0 Wireless Bluetooth Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read these instructions carefully before use.

BOX CONTENTS

The HAMMER Bash 2.0 package includes the following items:


- 1 x HAMMER Bash 2.0 Over-Ear Headphone
- 1 x Aux Cable with Mic
- 1 x User Manual
- 1 x Warranty Card

PRODUCT FEATURES

The HAMMER Bash 2.0 headphones are designed for a superior audio experience with convenience and comfort.

- **Wired & Wireless Connectivity:** Seamlessly switch between Bluetooth 5.0 and 3.5mm AUX connection.
- **Extended Playtime:** Enjoy up to 8 hours of music and calls on a single charge with the 300 mAh battery.
- **Comfortable Design:** Equipped with super-soft cushions for prolonged listening comfort.
- **Advanced Bluetooth 5.0:** Provides a strong and stable connection up to 10 meters.

- **Deep Bass & HD Sound:** Powered by 40mm dynamic sound drivers for rich audio quality.
- **Built-in Microphone:** Ensures clear communication during calls.
- **Foldable Design:** For easy portability and storage.
- **Water Resistant:** Features IPX4 water resistance, suitable for workouts and travel.



Stronger Bass

That shuts out the rest

Image: Key features of the HAMMER Bash 2.0 headphones, including 40mm sound drivers, 8 hours playtime, deep bass, soft cushions, Bluetooth 5.0, and IPX4 water resistance.

CONTROLS AND FUNCTIONS

The HAMMER Bash 2.0 headphones feature intuitive controls located on the earcup for easy access to various functions.



Noise Isolation

Isolate yourself from noise

Image: Diagram illustrating the control buttons on the HAMMER Bash 2.0 headphones.

- **Power On/Off Button:** Press and hold to power the headphones on or off.
- **Multi-function Button (Play/Pause/Call):**
 - Press once to Play/Pause music.
 - Press once to Answer/End a call.
 - Press and hold to Reject an incoming call.
- **Volume Up / Next Track Button:**
 - Press once to increase volume.
 - Press and hold to skip to the next track.
- **Volume Down / Previous Track Button:**
 - Press once to decrease volume.
 - Press and hold to go to the previous track.

SETUP

Bluetooth Pairing

1. Ensure the headphones are fully charged before first use.
2. Press and hold the Power On/Off button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "HAMMER Bash 2.0" from the list of found devices.
5. Once connected, the LED indicator will show a steady blue light or flash blue slowly.
6. The headphones will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

Wired Connection (AUX Mode)

To use the headphones in wired mode:

1. Connect one end of the provided 3.5mm AUX cable to the audio jack on the headphones.
2. Connect the other end of the AUX cable to the 3.5mm audio output on your device.
3. The headphones will automatically switch to wired mode, and Bluetooth functionality will be disabled.

Your Best Calling Partner



Image: HAMMER Bash 2.0 headphones demonstrating the wired AUX connection.

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Volume Control:** Press the Volume Up or Volume Down buttons briefly.

Phone Calls

- **Answer Call:** Press the Multi-function button once.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.

CHARGING

To charge your HAMMER Bash 2.0 headphones:

1. Connect the charging cable (not specified in box contents, typically Micro USB or USB-C) to the charging port on the headphones.

2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator will typically show a red light during charging and turn off or change color when fully charged.
4. A full charge provides approximately 8 hours of playtime.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your headphones.

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. Utilize the foldable design for compact storage.
- **Water Exposure:** While water-resistant (IPX4), avoid submerging the headphones in water or exposing them to heavy rain. Dry thoroughly if they get wet.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.

TROUBLESHOOTING

If you encounter issues with your HAMMER Bash 2.0 headphones, refer to the following common solutions:

- **Headphones not powering on:**
 - Ensure the headphones are charged. Connect them to a power source and try again.
 - Press and hold the Power On/Off button for a longer duration (5-7 seconds).
- **Cannot pair with device:**
 - Ensure the headphones are in pairing mode (LED flashing blue and red).
 - Make sure Bluetooth is enabled on your device and it is within 10 meters of the headphones.
 - Forget/remove "HAMMER Bash 2.0" from your device's Bluetooth list and try pairing again.
 - Restart both your device and the headphones.
- **No sound or low volume:**
 - Check the volume levels on both the headphones and your connected device.
 - Ensure the headphones are properly connected via Bluetooth or AUX cable.
 - If using AUX, ensure the cable is fully inserted and not damaged.
 - Try playing audio from a different source or application.
- **Microphone not working:**
 - Ensure the headphones are connected via Bluetooth for microphone functionality. The microphone on the AUX cable must be used if in wired mode.
 - Check microphone settings on your connected device.

SPECIFICATIONS

Feature	Specification
---------	---------------

Model Name	Bash 2.0
Bluetooth Version	5.0
Bluetooth Range	Up to 10 meters
Audio Driver Size	40 mm
Battery Capacity	300 mAh
Playtime	Up to 8 hours
Headphone Jack	3.5 mm
Water Resistance	IPX4 (Water Resistant)
Weight	190 Grams
Control Type	Media Control, Touch
Compatible Devices	Laptops, Mobile Phones, Tablets, PC, Smart TVs, All Bluetooth Devices, iOS, Android

WARRANTY AND SUPPORT

Warranty Information

The HAMMER Bash 2.0 headphones come with a **6 Months Brand Warranty** from the date of purchase. Please retain your purchase receipt and the warranty card for any warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any queries, technical assistance, or warranty claims, please contact HAMMER customer support:

- **Email:** Info@hammeronline.in
- **Phone:** 0180-4008081, 99911-08081