

[Manuals.plus](#) /

› [Hungama HiLife](#) /

› Hungama HiLife Buzz 101 Bluetooth Wireless Over Ear Headphones User Manual

Hungama HiLife Buzz 101

Hungama HiLife Buzz 101 Bluetooth Wireless Over Ear Headphones User Manual

INTRODUCTION

Thank you for choosing the Hungama HiLife Buzz 101 Bluetooth Wireless Over Ear Headphones. These headphones are designed to provide a high-quality audio experience with versatile connectivity options and comfortable wear. Please read this manual carefully to ensure proper use and to maximize your listening enjoyment.



Image: Hungama HiLife Buzz 101 Headphones, showcasing the sleek black design and over-ear cups.

PACKAGE CONTENTS

Please check the package for the following items:

- 1N Hungama HiLife Buzz 101 Headphones
- 1N Charging Cable
- 1N Aux-in Cable

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your headphones.



Image: Close-up view of the headphone earcup, highlighting the control buttons for media playback and mode selection.

Controls and Ports:

- **Power Button:** Press and hold to power on/off.
- **Play/Pause Button:** Play or pause audio, answer/end calls.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Mode (M/EQ) Button:** Switch between Bluetooth, FM Radio, TF Card, and USB modes.
- **Microphone:** For hands-free calls.
- **3.5mm Audio Jack:** For wired connection using the Aux-in cable.
- **USB Charging Port:** For charging the headphones.
- **TF Card Slot:** For playing music directly from a MicroSD/TF card.
- **USB Port:** For playing music directly from a USB drive.

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the charging cable to the USB charging port on the headphones and the other end to a USB power adapter (not included) or a computer's USB port. The LED indicator will show charging status and turn off when fully charged.



Image: Graphic illustrating the headphones' battery life, indicating up to 9 hours of continuous playtime.

2. Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns off.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for about 5-7 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Hungama HiLife Buzz 101" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.

The headphones will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

1. Bluetooth Mode

- **Play/Pause:** Press the Play/Pause button.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.

- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.

2. Aux-in Mode (Wired Connection)

Connect one end of the 3.5mm Aux-in cable to the headphone's 3.5mm audio jack and the other end to your audio source. The headphones will automatically switch to Aux-in mode. Controls on the headphones may be limited in this mode, and playback will be controlled by your connected device.

3. TF Card Mode

Insert a MicroSD/TF card (up to 32GB, not included) with MP3 audio files into the TF card slot. Press the Mode (M/EQ) button to switch to TF Card mode. The headphones will automatically begin playing music from the card.

4. USB Playback Mode

Insert a USB drive with MP3 audio files into the USB port. Press the Mode (M/EQ) button to switch to USB Playback mode. The headphones will automatically begin playing music from the USB drive.



Image: Graphic displaying the multiple connectivity options of the headphones, including Bluetooth, USB, TF Card, and FM Radio.

5. FM Radio Mode

Press the Mode (M/EQ) button to switch to FM Radio mode. To auto-scan and save stations, press and hold the Play/Pause button. Use the Volume Up/Down buttons to navigate between saved stations.

6. Call Functions

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.
- **Redial Last Number:** Double-press the Play/Pause button.

MAINTENANCE

Cleaning

- Wipe the headphones with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep the charging port and audio jack free of dust and debris.

Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in humid environments.

Battery Care

- Charge the headphones regularly, even if not in use, to maintain battery health.
- Avoid fully discharging the battery frequently.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on	Low battery	Charge the headphones fully.
Cannot pair via Bluetooth	Headphones not in pairing mode; Bluetooth off on device; device too far	Ensure headphones are in pairing mode (flashing blue/red). Turn on Bluetooth on your device. Move device closer to headphones.
No sound	Volume too low; incorrect mode; device not connected	Increase volume on headphones and device. Ensure correct mode (Bluetooth, Aux, TF, USB, FM) is selected. Verify Bluetooth connection or Aux cable.
Poor sound quality	Weak Bluetooth signal; audio source quality; dirty audio jack	Move closer to the Bluetooth device. Try a different audio source. Clean the 3.5mm audio jack if using Aux mode.
FM radio not working	Poor signal; no stations scanned	Move to an area with better signal. Perform an auto-scan for stations by long-pressing the Play/Pause button in FM mode.

SPECIFICATIONS

- **Brand:** Hungama HiLife
- **Model:** Buzz 101
- **Color:** Black
- **Ear Placement:** Over Ear
- **Form Factor:** Over Ear
- **Noise Control:** Sound Isolation (Passive Noise Cancellation)
- **Bluetooth Version:** 5.0

- **Battery Average Life:** Up to 9 Hours (at 50% volume)
- **Audio Driver Type:** Dynamic Driver
- **Speaker Power:** 30mW
- **Enclosure Material:** Leather (Earmuffs)
- **Connectivity:** Bluetooth, 3.5mm Aux-in, TF Card, USB, FM Radio
- **Compatible Devices:** Smartphones, Tablets, Laptops, Desktops, Cars with Bluetooth or Auxiliary Input
- **Headphone Jack:** 3.5 mm Jack
- **Control Type:** Media Control
- **Control Method:** Buttons
- **Item Weight:** 240 Grams
- **Country of Origin:** China



Image: Visual representation of the passive noise cancellation feature of the headphones.



Image: Close-up of the headphone's leather earmuffs, emphasizing comfort.

WARRANTY AND SUPPORT

Warranty Information

The Hungama HiLife Buzz 101 Headphones come with a **1-year manufacturer warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt for warranty claims.

Contact Support

For any product-related queries, technical support, or warranty claims, please contact:

- **Manufacturer:** Hungama Digital Media Entertainment Pvt. Ltd.
- **Manufacturer Address:** SF-B-07, Art Guild house Phoenix Market City, Lal Bahadur Shastri Rd, Kurla West, Mumbai, Maharashtra 400070
- **Importer:** Alpha Digital Corp.
- **Importer Address:** C1 Khira Nagar Santacruz W Mumbai 400009