

[Manuals.plus](#) /

› [truke](#) /

› truke BTG X1 True Gaming Earbuds User Manual

truke BTG X1

truke BTG X1 True Gaming Earbuds User Manual

1. PRODUCT OVERVIEW

The truke BTG X1 True Gaming Earbuds are designed for an immersive audio experience, featuring 12mm Titanium Drivers for cinematic sound and a dedicated gaming mode with ultra-low latency. These earbuds offer extended playtime, fast charging capabilities, and clear communication through Quad-Mic Environmental Noise Cancellation (ENC).




Image 1.1: Overview of truke BTG X1 Earbuds highlighting key features.

2. SETUP

2.1. What's in the Box

- truke BTG X1 True Gaming Earbuds
- Wireless Charging Case
- USB Charging Cable
- User Manual

2.2. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Connect the charging case to a USB power source using the provided cable. The case features blazing fast charging, providing up to 10 hours of playtime with just 10 minutes of case charge. A full charge of the case offers up to 48 hours of total playtime for the earbuds.

BLAZING FAST ⚡
48Hours Playtime



Image 2.1: Charging the truke BTG X1 Earbuds and case.

2.3. Initial Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, laptop, tablet), enable Bluetooth.
3. Search for 'truke BTG X1' in the list of available Bluetooth devices.
4. Select 'truke BTG X1' to connect. Once connected, you will hear a confirmation tone.

The earbuds support instant pairing technology, automatically connecting to the last paired device when the case is opened.

3. OPERATING INSTRUCTIONS

3.1. Touch Controls

The truke BTG X1 earbuds feature high-quality touch panels for easy control of music, calls, and modes. Avoid accidental touches by using a gentle tap.

- **Volume Control:** Single tap on either earbud to adjust volume.
- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Voice Assistant:** Tap 2 times on the left earbud to activate Google Assistant or Apple Siri.

3.2. Gaming Mode

For an optimized gaming experience, activate the dedicated Gaming Mode. This mode provides an ultra-low latency of up to 40ms.

- **Activate Gaming Mode:** Tap 3 times on the right earbud.
- **Deactivate Gaming Mode:** Tap 3 times on the right earbud again to return to normal mode.



Image 3.1: truke BTG X1 Earbuds in Gaming Mode.

3.3. Music Experience

Enjoy a cinematic music experience with powerful deep bass, delivered by 12mm Titanium Speaker drivers. The earbuds support both SBC and AAC codecs for high-quality audio streaming.



Image 3.2: truke BTG X1 Earbuds for Music Experience.

3.4. Clear Calling with Quad-Mic ENC

The BTG X1 earbuds feature Quad-Mics (dual mic on each earbud) with Environmental Noise Cancellation (ENC) to minimize background noise, ensuring clear and crisp call quality.

CLEAR CALLING EXPERIENCE

Quad-Mic Environmental Noise Cancellation(ENC)



Image 3.3: Clear Calling with Quad-Mic ENC.

4. MAINTENANCE

4.1. Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.

- Gently wipe the earbuds, especially the ear tips and charging contacts.
- Clean the charging contacts inside the case.

4.2. Water Resistance

The truke BTG X1 earbuds are water-resistant (IPX4 rated). This means they are protected against splashing water from any direction. They are not designed for submersion in water or exposure to heavy rain. Avoid using them in saunas or steam rooms.

4.3. Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.

5. TROUBLESHOOTING

5.1. Earbuds Not Pairing

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device, then turn it back on.
- Forget 'truke BTG X1' from your device's Bluetooth list and attempt to pair again.
- Place earbuds back in the case, close the lid, wait a few seconds, then open to re-initiate pairing mode.

5.2. No Sound or Low Volume

- Check the volume levels on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speaker mesh.

5.3. Charging Issues

- Verify the charging cable and adapter are working correctly.
- Ensure the charging contacts on both the earbuds and case are clean and free of obstruction.
- Try a different USB port or power source.

5.4. Call Quality Issues

- Ensure the earbuds are properly seated in your ears.
- Check for strong Bluetooth signal; move closer to your connected device.
- Avoid noisy environments if possible, though ENC helps reduce background noise.

6. SPECIFICATIONS

Brand	truke
Model Name	BTG X1
Model Number	F111
Ear Placement	In Ear
Audio Driver Type	12mm Titanium Dynamic Driver
Bluetooth Version	5.3
Latency	Up to 40ms (Gaming Mode)
Playtime	Up to 48 hours (with charging case)
Fast Charging	10 minutes charge for 10 hours playtime
Microphones	Quad-Mic (Dual mic on each earbud) with ENC
Water Resistance	IPX4

Compatible Devices	Smartphones, Laptops, Tablets
Control Method	Touch
Weight	42 Grams

7. WARRANTY AND SUPPORT

7.1. Warranty Information

The truke BTG X1 Truly Wireless Earphones come with a **1-Year Warranty** from the date of purchase. This warranty is valid across 250+ active service centers. Mandatory registration is required on the truke website within 10 days of purchase to activate your warranty.

7.2. Customer Support

For any queries, technical assistance, or warranty claims, please refer to the official truke website or contact their customer support. Ensure you have your proof of purchase and product registration details ready.