

[Manuals.plus](#) /

› [GIZMORE](#) /

› GIZMORE TWS 809 Pro Wireless Earbuds User Manual

## GIZMORE 809 Pro

# GIZMORE TWS 809 Pro Wireless Earbuds User Manual

Model: 809 Pro | Brand: GIZMORE

## 1. INTRODUCTION

Thank you for choosing the GIZMORE TWS 809 Pro Bluetooth 5.3 Wireless Earbuds. These featherlite, sung-fit in-ear earbuds are designed to provide a superior audio experience with advanced features like Bluetooth 5.3 connectivity, AAC codec support, and up to 20 hours of playtime with the charging case. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

## 2. PACKAGE CONTENTS

- GIZMORE TWS 809 Pro Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- User Manual

## 3. PRODUCT OVERVIEW

The GIZMORE TWS 809 Pro earbuds feature a sleek design and are housed in a compact charging case. Each earbud is equipped with touch controls for easy management of music and calls.



Image: GIZMORE TWS 809 Pro Earbuds in their charging case.


The charging case not only protects your earbuds but also provides additional battery life, extending your listening time significantly.

## 4. SETUP

### 4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB Type-C cable to the charging port on the case and a power source. The indicator light on the case will show charging status.

## Single Touch Voice Assistant



## ENC Noise Reduction

Image: The GIZMORE TWS 809 Pro charging case connected via a Type-C cable, illustrating rapid charge capability.

A 15-minute charge can provide up to 100 minutes of playback.

### 4.2 Initial Pairing

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "GIZMORE 809 Pro" in the list of available Bluetooth devices.
4. Select "GIZMORE 809 Pro" to connect. Once connected, you will hear a confirmation tone.

# Type-C Rapid Charge

15 Mins  
Charge = 100 Mins  
Playback



Image: GIZMORE TWS 809 Pro earbuds outside their case, indicating readiness for instant pairing via Bluetooth 5.3.

The earbuds support instant pairing, allowing for quick connection to previously paired devices.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- **Power On:** Open the charging case, or long-press the touch area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds for 5 seconds.

### 5.2 Music Playback

The earbuds feature 13mm high-fidelity composite drivers and AAC codec support for immersive sound and deep bass.




Image: Diagram illustrating the internal components of the GIZMORE TWS 809 Pro earbud, highlighting the 13mm Hi-Fidelity Sound Drivers and AAC Codec for immersive sound.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.

### 5.3 Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long-press on either earbud for 2 seconds.

### 5.4 Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant, etc.) with a single touch.

# GIZMORE

## 809 PRO

Ultra-Light SnugFit



Image: A person interacting with their device's voice assistant using the GIZMORE TWS 809 Pro earbuds, demonstrating the single-touch voice assistant feature and ENC Noise Reduction.

- **Activate Voice Assistant:** Long-press on either earbud for 2 seconds (when not on a call).

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your GIZMORE TWS 809 Pro earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Resistance:** The earbuds are IPX5 water resistant, meaning they can withstand splashes of water. Do not submerge them in water or expose them to heavy rain.

# IPX5

## Water Resistant



Image: GIZMORE TWS 809 Pro earbuds with water droplets, illustrating their IPX5 water-resistant rating.

- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) as this can affect battery life and performance.

## 7. TROUBLESHOOTING

### **Earbuds not pairing with device:**

Ensure Bluetooth is enabled on your device. Make sure the earbuds are charged and in pairing mode. Try forgetting the device on your phone and re-pairing.

### **Only one earbud working:**

Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid again. This often re-syncs them. Check if both earbuds are charged.

### **Low volume or poor sound quality:**

Check the volume level on both your device and the earbuds. Ensure the earbuds are clean and free of

debris. Try different ear tip sizes for a better seal.

**Charging issues:**

Ensure the charging cable is securely connected. Try a different USB port or power adapter. Clean the charging contacts on both the earbuds and the case.

8. SPECIFICATIONS

| Feature                 | Detail                                      |
|-------------------------|---------------------------------------------|
| Model Name              | GIZMORE TWS 809 Pro                         |
| Connectivity Technology | Wireless (Bluetooth 5.3)                    |
| Ear Placement           | In Ear                                      |
| Driver Size             | 13mm High FID Composite Drivers             |
| Audio Codec             | ACC                                         |
| Playtime                | Up to 20 hours (with charging case)         |
| Charging Time           | Approx. 15 minutes for 100 minutes playback |
| Charging Port           | USB Type-C                                  |
| Water Resistance        | IPX5                                        |
| Control Type            | Touch Control, Voice Control                |
| Item Weight             | 30 Grams                                    |
| Product Dimensions      | 5.2 x 2.3 x 4.6 cm                          |

9. WARRANTY & SUPPORT

The GIZMORE TWS 809 Pro earbuds come with a **6-month warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty.

For any product-related queries, technical support, or warranty claims, please contact GIZMORE customer service through their official website or the retailer where you purchased the product. Refer to the contact information provided in your product packaging or on the GIZMORE official website.

For more information, visit the [GIZMORE Store on Amazon](#).

