

Foxin Supreme 325

Foxin Supreme 325 Bluetooth Over-Ear Wireless Headphones User Manual

INTRODUCTION

Thank you for choosing the Foxin Supreme 325 Bluetooth Over-Ear Wireless Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual carefully before using the product.



Image: Foxin Supreme 325 Wireless Headphones, showcasing the sleek design and Foxin branding.

WHAT'S IN THE BOX

The Foxin Supreme 325 package includes the following items:

- 1 Unit Foxin Supreme 325 Wireless Headphones
- 1 Unit USB Charging Cable
- 1 Unit AUX Cable with Mic (1.2 meters)
- 1 User Manual

foxin

SUPREME 325
Wireless Headphones

 Smart Power Saving Mode



Image: The Foxin Supreme 325 headphones along with the included USB charging cable and AUX cable.

SETUP

Charging the Headphones

Before first use, fully charge your Foxin Supreme 325 headphones.

1. Connect the small end of the provided USB charging cable to the charging port on the headphones.
2. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will typically show a red light while charging and turn off when fully charged.
4. A full charge provides up to 12 hours of playtime.

Note: The headphones feature a standby time of up to 120 hours.



Image: Visual representation of the headphones' battery life, highlighting 12 hours of playtime and 120 hours of standby time.

Bluetooth Pairing

Follow these steps to pair your headphones with a Bluetooth-enabled device:

1. Ensure the headphones are turned off.
2. Press and hold the Power button on the headphones for approximately 5 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Foxin Supreme 325" from the list of found devices.
5. Once connected, the LED indicator on the headphones will flash blue slowly or remain solid blue.
6. If prompted for a password, enter "0000".

The headphones support Bluetooth 5.0 for a stable wireless connection up to 30 feet.

Wired Connection (AUX Mode)

You can use the headphones in wired mode even if the battery is depleted.

1. Connect one end of the provided 1.2-meter AUX cable to the AUX port on the headphones.
2. Connect the other end of the AUX cable to the 3.5mm audio jack of your device.
3. The headphones will automatically switch to wired mode.



Image: The Foxin Supreme 325 headphones illustrating both wireless (Bluetooth 5.0) and wired (AUX) connectivity options.

OPERATING THE HEADPHONES

Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns off.

Music Playback Control

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

Voice Assistant

The Foxin Supreme 325 supports voice assistant activation (Siri, Google Assistant).

- **Activate Voice Assistant:** Press the dedicated Voice Assistant button (if available) or triple-press the Multi-function button.

foxin

Adjustable
Metallic Headband

Siri and Google
Voice Command

Built-In Mic



Image: Close-up of the Foxin Supreme 325 headphones, highlighting the adjustable metallic headband, built-in microphone, and voice assistant functionality.

Smart Power Save Mode

The headphones feature a smart power-saving mode. If not connected via Bluetooth for 5 minutes, the headset will automatically turn off to conserve battery.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Foxin Supreme 325 headphones, follow these guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** Avoid exposing the headphones to water or excessive moisture. They are not waterproof.
- **Charging:** Use only the provided USB charging cable. Avoid overcharging the battery.
- **Handling:** Do not drop, disassemble, or attempt to repair the headphones yourself. This may void the warranty.

TROUBLESHOOTING

If you encounter issues with your Foxin Supreme 325 headphones, refer to the following common solutions:

No Power / Not Turning On

- Ensure the headphones are fully charged. Connect them to a power source using the USB cable and allow them to charge for at least 30 minutes before attempting to power on again.

Cannot Pair via Bluetooth

- Ensure the headphones are in pairing mode (LED flashing blue and red alternately).
- Make sure Bluetooth is enabled on your device and it is within 30 feet of the headphones.
- Turn off Bluetooth on your device, then turn it back on.
- Forget "Foxin Supreme 325" from your device's Bluetooth list and attempt to pair again.
- Restart both your device and the headphones.

No Sound or Low Volume

- Check the volume levels on both the headphones and your connected device.
- Ensure the headphones are properly paired via Bluetooth or connected via the AUX cable.
- If using Bluetooth, try disconnecting and reconnecting.
- If using the AUX cable, ensure it is fully inserted into both the headphones and your device.
- Test with a different audio source or device.

Poor Sound Quality

- Ensure there are no obstructions between the headphones and your Bluetooth device.
- Move closer to your Bluetooth device to reduce interference.
- Check if the audio source quality is high.

Microphone Not Working

- Ensure the headphones are properly connected to your device.
- Check your device's audio settings to ensure the headphone microphone is selected as the input device.
- If using the AUX cable, ensure it is the provided cable with an in-built mic.

SPECIFICATIONS

Feature	Detail
Model Name	Supreme 325
Brand	Foxin
Connectivity	Bluetooth 5.0, AUX
Driver Size	40mm Dynamic Driver
Playtime	Up to 12 hours
Standby Time	Up to 120 hours
Wireless Range	Up to 30 feet
Microphone	Built-in mic (also on AUX cable)
Voice Assistant Support	Yes (Siri, Google Voice Command)
Control Type	Media Control, Voice
Ear Placement	Over Ear

Material	Stainless Steel (headband)
Weight	190 Grams
Compatible Devices	Android Devices, iOS Devices



Image: Diagram illustrating the 40mm dynamic drivers responsible for the headphones' super extra bass audio quality.

WARRANTY INFORMATION

The Foxin Supreme 325 headphones come with a **180-day warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt for warranty claims. For warranty service, contact Foxin customer support.

CUSTOMER SUPPORT

For any queries, technical assistance, or warranty claims, please contact Foxin customer support. Refer to the official Foxin website or your purchase documentation for contact details.

Manufacturer: BALAJI SOLUTIONS PRIVATE LIMITED