LUMIFORD XploriaHD XP25

LUMIFORD XploriaHD XP25 Bluetooth Neckband Earphones User Manual

Introduction

This manual provides essential instructions for the safe and efficient use of your LUMIFORD XploriaHD XP25 Bluetooth Neckband Earphones. Please read this manual thoroughly before using the product and retain it for future reference.

What's in the Box

Verify that all items listed below are present in your product packaging:

- 1 x LUMIFORD XploriaHD XP25 Wireless Earphone
- 1 x Type-C Charging Cable
- 3 x Pairs of Ear Tips (Sizes S, M, L)
- 1 x User Manual & Warranty Card

Product Overview

Earphone Components



Image: The LUMIFORD XploriaHD XP25 neckband earphones, showcasing the in-ear design and flexible neckband in Gun Grey.

The LUMIFORD XploriaHD XP25 features a flexible neckband design with in-ear earbuds. The control panel is integrated into the neckband for easy access to functions.

Image: Close-up view highlighting the 10mm extra bass drivers within the earbud design.

Control Button Functions

Button/Action	Function
Power Button (Long Press)	Power On/Off
Power Button (Short Press)	Play/Pause Music, Answer/End Call
Volume + (Short Press)	Increase Volume
Volume - (Short Press)	Decrease Volume
Volume + (Long Press)	Next Track
Volume - (Long Press)	Previous Track

Button/Action	Function
Power Button (Double Press)	Activate Voice Assistant
Power Button (Long Press during incoming call)	Reject Call

Setup

Charging the Earphones



Image: Visual representation of 16 hours playtime and the Type-C charging port on the neckband.

1. Connect the provided Type-C charging cable to the charging port on the neckband.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge typically takes approximately 1.5 hours.
4. Once fully charged, the earphones provide up to 16 hours of music playback.

Bluetooth Pairing



Image: Graphic highlighting the Advanced Bluetooth V5.3 connectivity of the earphones.

1. Ensure the earphones are fully charged.
2. Press and hold the Power button until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "LUMIFORD XploriaHD XP25" from the list of found devices.
5. Once connected, the LED indicator will flash blue slowly, and you will hear a confirmation tone.

Operating the Earphones

Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the LED flashes blue.
- **Power Off:** Press and hold the Power button for approximately 5 seconds until the LED flashes red and then turns off.

Music Playback

- **Play/Pause:** Short press the Power button.
- **Next Track:** Long press the Volume + button.
- **Previous Track:** Long press the Volume - button.

Call Management

- **Answer/End Call:** Short press the Power button during an incoming call or during an active call.
- **Reject Call:** Long press the Power button during an incoming call.

Voice Assistant

- **Activate Voice Assistant:** Double press the Power button. This will activate your device's default

voice assistant (e.g., Google Assistant, Siri).

Water Resistance (IPX4)

Image: Graphic indicating the IPX4 splash-proof rating of the earphones.

The LUMIFORD XploriaHD XP25 earphones are rated IPX4 water resistant. This means they are protected against splashing water from any direction. They are suitable for use during workouts or light rain, but should not be submerged in water or exposed to heavy water jets.

Maintenance

Cleaning

- Gently wipe the earphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

Storage

- Store the earphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing with sharp objects that could damage the cables or earbuds.

Troubleshooting

Problem	Solution
Earphones do not power on.	Ensure the earphones are fully charged. Connect to a power source and check the charging indicator.
Cannot pair with device.	Ensure earphones are in pairing mode (flashing red/blue). Turn off and on Bluetooth on your device. Delete previous pairings and try again. Ensure earphones are within 10 meters of the device.
No sound or low volume.	Check volume levels on both earphones and your connected device. Ensure earphones are properly connected. Try playing different audio.
Sound cuts out or disconnects.	Ensure no obstacles are between the earphones and your device. Move closer to your device. Avoid strong electromagnetic interference. Recharge earphones if battery is low.
Voice Assistant not responding.	Ensure your device's voice assistant is enabled and configured. Double-check the button press sequence for activation.

Specifications

Feature	Detail

Feature	Detail
Model Name	XploriaHD XP25
Brand	LUMIFORD
Colour	Gun Grey
Bluetooth Version	5.3
Ear Placement	In Ear
Driver Size	10mm
Impedance	32 Ohms
Frequency Range	20 Hz - 20 KHz
Playback Time	Up to 16 Hours
Battery Charge Time	Approx. 1.5 Hours
Water Resistance	IPX4 (Splash Resistant)
Control Type	Voice Control, Button Control
Material	Acrylonitrile Butadiene Styrene (ABS), Plastic
Item Weight	68 Grams

Warranty and Support

Your LUMIFORD XploriaHD XP25 earphones come with a**12-month warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical support, warranty claims, or product inquiries, please contact LUMIFORD customer service:

- **Email:** info@lumiford.com
- **Manufacturer Address:** Lumiford Pvt Ltd, No. 489 “Planet Plaza” 4th Floor, Amruthahalli Main Road, Talacauvery Layout, Byatrayanapura, Bangalore - 560092, India.

Safety Information

Please observe the following safety guidelines to prevent damage to the product or injury to yourself:

- Do not disassemble, repair, or modify the product.
- Keep the earphones away from extreme temperatures, humidity, and corrosive substances.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Do not use the earphones in situations where inability to hear ambient sounds could be dangerous (e.g., driving, cycling, walking in traffic).
- Dispose of the product responsibly according to local regulations.