

Noise Three

Please refer to this manual before using the product



SPECIFICATIONS

- Weight: 205 grams
- Speaker driver size: 40 mm
- Supported profile: A2DP/AVRCP/HFP/SPP/AVDTP
- Bluetooth version: 5.3
- Charging time: Up to 1 hour
- Working voltage: 5v
- Standby time: 500 hours
- Bluetooth range: 10m
- Working temperature: 0-45°C
- Playtime: Up to 70 hours

PACKAGE CONTENTS



Noise Three Headphone x 1



USB charging cable x 1



3.5mm aux cable x 1

POWER ON

Long press the power button for 3 seconds.

POWER OFF


Long press the power button for 3 seconds.

PAIRING

Before pairing, make sure that your Noise Three and the device are next to each other.

- Long press the power button for 3 seconds to turn on the headphones.
- The LED will flash blue and red indicating that the headphones are in pairing mode.
- Turn on the Bluetooth of your device and go to the Bluetooth menu.
- Search and select Noise Three to pair.
- The LED will turn blue once paired.
Your Noise Three Bluetooth headphones are now ready to use.

Note: The headphones will automatically connect to the last paired devices.



MODES

AUXILIARY MODE

Connect the included 3.5mm auxiliary cable to the 3.5mm jack on your headphones and device.

TF CARD MODE

Insert the micro SD card in the SD card slot and press the Mode (M) button.



CONTROLS



Play/Pause

Short press power button once



● Short press once



Previous Song

Long press -



— Long Press -



Next Song

Long press +



— Long Press +



Volume Up

Short press +



● Short press +



Volume Down

Short press -



● Short press -

CONTROLS



Answer/End Call

Press the Power Button Once



● Press once



Reject Call

Long press the Power Button



▬ Long press the Power Button



Gaming Mode

Long press the Mode Button



▬ Long press M



Voice Assistance

Press the Power Button Twice



●● Press Twice

CHARGING

Plug the included TYPE-C cable to the charging port of headphones and plug the other end to main power adapter or into your laptop or PC

● Red LED



● Blue LED



Plug the included TYPE-C cable to the charging port of headphones and plug the other end to main power adapter or into your laptop or PC.



WARRANTY

The warranty covers your Noise product, including accessories, against manufacturing defects (if any) for 1 year from the date of purchase.

Things that are not covered in the warranty are listed below:

- Unauthorized tampering, modifications or repairs of the product.
- Physical damage of the product on the account of abuse, handling, storage, installation or testing including any use that is not by the product manual or documentation, or any other instruction provided along with the Noise product.

For further information on product replacement/refund-related queries, please refer to the terms and conditions mentioned in our online return policy section on **www.gonoise.com**.

REGISTER YOUR WARRANTY

www.gonoise.com/pages/warranty-registration



SCAN ME

CUSTOMER QUERY

For any assistance, please reach out to us at support.gonoise.in

SAFETY FOR YOU AND YOUR NOISE THREE

Follow these tips to get the best out of your new Noise Three:

-  Do not expose the earbuds to liquids, moisture or humidity as they have electronics and batteries inside.
-  Don't use abrasive cleaning solvents to clean your new earbuds. Wipe them down with a slightly damp cloth if and when necessary.
-  Remove and clean the earbud tips regularly to ensure that you always enjoy the best sound possible.
-  Do not expose the earbuds to extremely high or low temperatures as this may damage the battery or even deform the plastic parts.
-  Do not throw the earbuds in a fire to dispose them. The internal battery may explode.
-  Do not try to disassemble your earbuds. There are no user-serviceable parts inside it.
-  Try not to drop the earbuds and keep them away from sharp objects such as keys in your pockets.
-  Only charge your earbuds from 5V USB ports such as phone chargers and laptops or PC chargers.
-  Never listen to music at a high volume or you may permanently damage your hearing.
-  Pay attention to your surroundings and never wear any earbuds while riding, driving or walking in traffic.

