Noise AUD-HDPHN-TWO-BLU

Noise Two Wireless On-Ear Headphones User Manual

Model: AUD-HDPHN-TWO-BLU

Introduction

This manual provides detailed instructions for the Noise Two Wireless On-Ear Headphones. Please read this guide thoroughly before using your headphones to ensure proper operation and to maximize your listening experience. Keep this manual for future reference.

What's in the Box

Verify that all items are present in the package:

- 1x Noise Two Bluetooth Headphone
- 1x Charging Cable
- 1x User Manual
- 1x Warranty Registration Card

Product Features Overview

The Noise Two headphones offer a range of features designed for an enhanced audio experience:

- Up to 50 hours of playtime on a single charge.
- Low latency (up to 40ms) for synchronized audio during gaming and streaming.
- Tru Bass™ technology for powerful, bass-driven sound.
- 40mm audio drivers for rich and captivating audio.
- Dual pairing capability to connect to two devices simultaneously.
- Four versatile play modes: Bluetooth, AUX, SD card, and FM radio.
- IPX5 water resistance for protection against splashes and moisture.
- Bluetooth 5.3 for stable and consistent wireless connectivity.



Image: Overview of Noise Two headphones showcasing features such as low latency, lightweight design, 4 play modes, up to 50-hour playtime, dual pairing, and Bluetooth v5.3.

Setup and Pairing

Initial Bluetooth Pairing

1. Ensure the headphones are fully charged before first use.
2. Press and hold the Power button on the headphones until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, laptop, tablet), navigate to the Bluetooth settings.
4. Search for available devices and select "Noise Two" from the list.
5. Once connected, the LED indicator will show a solid blue light or flash blue slowly.

Dual Pairing

The Noise Two headphones support dual pairing, allowing connection to two devices simultaneously.

1. Pair the headphones with the first device as described above.
2. Disable Bluetooth on the first device. The headphones will re-enter pairing mode.
3. Pair the headphones with the second device.
4. Re-enable Bluetooth on the first device. The headphones should automatically connect to both devices.
5. You can now switch audio playback between the two connected devices.




Image: Noise Two headphones demonstrating dual pairing, connected to both a smartphone and a laptop for seamless switching between audio sources.

Operating Instructions

Basic Controls

- **Power On/Off:** Press and hold the Power button.

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.
- **Answer/End Call:** Press the Play/Pause button once.
- **Reject Call:** Press and hold the Play/Pause button.
- **Activate Voice Assistant:** Press the M button (Mode button) once.

Play Modes

The Noise Two headphones support four distinct play modes:

1. **Bluetooth Mode:** Connect wirelessly to your devices for audio playback and calls.
2. **AUX Mode:** Use the included 3.5mm audio cable to connect to devices without Bluetooth, or when the headphone battery is low.
3. **SD Card Mode:** Insert a microSD card with audio files into the designated slot for direct playback without a connected device.
4. **FM Radio Mode:** Switch to FM mode to listen to local radio stations. Use the control buttons to scan and select stations.



Image: Diagram showing the Noise Two headphones' versatility with four play modes: SD card for smartphone-free music, AUX for wired connection, FM for radio, and Bluetooth for wireless connectivity.

Charging

To charge your Noise Two headphones:

1. Connect the provided USB charging cable to the Type-C charging port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will illuminate during charging and turn off or change color when fully charged.

A full charge takes approximately 2 hours and provides up to 50 hours of playtime.



Image: Noise Two headphones highlighting the Type-C charging port and the impressive 50-hour playtime capability.

Maintenance

- Clean the headphones regularly with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Avoid exposing the headphones to extreme temperatures, direct sunlight, or excessive humidity.
- Store the headphones in a cool, dry place when not in use.
- The headphones are IPX5 water resistant, meaning they are protected against splashes. Do not submerge them in water.



Image: Noise Two headphones emphasizing their IPX5 water resistance, suitable for protection against splashes and light moisture.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Bluetooth is off on device; headphones not in pairing mode; too far from device.	Ensure Bluetooth is enabled on your device. Put headphones in pairing mode. Move headphones closer to the device (within 10 meters).
No sound or low volume.	Volume too low; incorrect audio source; headphones not connected.	Increase volume on both headphones and device. Check if headphones are properly connected. Ensure correct play mode is selected.

Problem	Possible Cause	Solution
Audio lag during gaming/streaming.	Standard Bluetooth latency.	The headphones feature low latency (up to 40ms) for optimal performance. Ensure your device supports and utilizes this feature.



Image: A user wearing Noise Two headphones while gaming, illustrating the benefit of low latency for an immersive experience.

Specifications

Feature	Detail
Model Name	Noise Two
Connectivity Technology	Bluetooth 5.3

Feature	Detail
Wireless Communication Technology	Bluetooth
Audio Driver Type	Dynamic Driver (40mm)
Battery Life	Up to 50 Hours
Charging Time	Approximately 2 Hours
Water Resistance Level	IPX5 (Water Resistant)
Bluetooth Range	10 Metres
Control Method	Push Button
Material	Plastic
Item Weight	35 Grams
Product Dimensions (LxWxH)	35 x 2 x 1 cm
Compatible Devices	Cellphones, Laptops, Tablets
Earpiece Shape	Oval



Image: An exploded diagram of the Noise Two headphone's internal components, showcasing the 40mm driver and Tru Bass™ sound technology.

Warranty and Support

Your Noise Two Wireless On-Ear Headphones come with a warranty. Please refer to the included Warranty Registration Card for details on warranty terms and conditions, and how to register your product.
For technical support or further assistance, please contact Noise customer service. Contact information can typically be found on the warranty card or the official Noise website.
Manufacturer: Nexxbase Marketing Pvt. Ltd, Khasra No-146/25/2/1, Jail Road Badshahpur, Gurugram Haryana-122101.
Customer Service: 8882-132-132

© 2024 Noise. All rights reserved.