

[Manuals.plus](#) /

› [ONIKUMA](#) /

› ONIKUMA K5 Pro Wired Gaming Headset User Manual

ONIKUMA K5 Pro

ONIKUMA K5 Pro Wired Gaming Headset User Manual

Model: K5 Pro | Brand: ONIKUMA

INTRODUCTION

The ONIKUMA K5 Pro Wired Gaming Headset is engineered to deliver an immersive audio experience for gamers across various platforms. Equipped with high-quality 50mm large aperture driver units, it provides clear, pure bass sound and HiFi audio for both gaming and music listening. The headset features an adjustable, noise-cancelling microphone designed to capture your voice with clarity and precision, ensuring effective communication during gameplay. Its ergonomic design incorporates soft memory protein ear cushions and an adjustable headband, offering exceptional comfort for extended periods of use.



Image: The ONIKUMA K5 Pro Gaming Headset, showcasing its over-ear design, adjustable microphone, and red LED lighting on the earcups.

PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- ONIKUMA K5 Pro Wired Gaming Headset (Red)
- User Manual (This document)

SETUP GUIDE

Connecting the Headset

Follow these steps to connect your ONIKUMA K5 Pro headset to your device:

1. **Audio Connection:** Locate the 3.5mm audio jack on your gaming console controller (e.g., Xbox One, PS4), PC, or other compatible device. Insert the 3.5mm plug from the headset firmly into this audio jack. Ensure it clicks into place for a secure connection.
2. **LED Power (Optional):** For the headset's LED lights to illuminate, connect the USB plug of the headset to an available USB port on your device or a USB power adapter. The LED lights are purely for aesthetic enhancement and do not affect the audio functionality of the headset.

Adjusting Fit

For optimal comfort and sound performance:

- Extend or retract the adjustable headband until the earcups sit comfortably and securely over your ears.
- Ensure the soft memory protein ear cushions fully enclose your ears. This provides the best sound isolation and comfort during extended gaming sessions.

OPERATING INSTRUCTIONS

Volume Control

The headset features an inline volume control for convenient audio adjustments:

- Locate the volume control wheel on the headset cable.
- Rotate the wheel upwards to increase the audio volume.
- Rotate the wheel downwards to decrease the audio volume.

Microphone Usage

The adjustable microphone allows for clear voice communication:

- Position the flexible microphone boom approximately 2-3 centimeters from your mouth for optimal voice pickup.
- To mute the microphone, slide the inline microphone mute switch to the 'OFF' position. Slide it back to 'ON' to unmute.

LED Lighting

The LED lights enhance the aesthetic appeal of your headset:

- The LED lights on the earcups will automatically illuminate when the headset's USB plug is connected to a powered USB port.




Image: A side view of the ONIKUMA K5 Pro headset, highlighting the adjustable microphone and the detailed design of the earcup.

MAINTENANCE

Proper care will extend the lifespan of your headset:

- **Cleaning:** Use a soft, dry, lint-free cloth to gently wipe the surfaces of the headset. Avoid using liquid cleaners, aerosols, or solvents, as these can damage the finish or internal components.
- **Storage:** Store the headset in a cool, dry environment, away from direct sunlight, excessive heat, or extreme cold. Avoid placing heavy objects on the headset.
- **Cable Care:** Do not pull on the cable to disconnect the headset. Always grasp the plug. Avoid sharp bends or kinks in the cable, which can damage the internal wiring.

TROUBLESHOOTING

If you encounter issues with your headset, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Sound from Headset	Incorrect connection, low volume, muted device/headset	Ensure the 3.5mm jack is fully inserted into the audio port. Check the headset's inline volume wheel and increase volume. Verify your device's audio output settings and ensure it is not muted.
Microphone Not Working	Microphone muted, incorrect input device selected, software settings	Ensure the inline microphone mute switch is in the 'ON' position. In your device's sound settings, confirm the headset microphone is selected as the default input device. Adjust microphone sensitivity if necessary.
LED Lights Not Illuminating	USB not connected, faulty USB port, insufficient power	Ensure the USB plug is securely connected to a powered USB port. Try connecting to a different USB port or a different power source.
Sound Distortion or Static	Volume too high, loose connection, interference	Lower the volume on both the headset and your device. Re-insert the 3.5mm jack firmly. Ensure the cable is not near sources of electromagnetic interference.

TECHNICAL SPECIFICATIONS

Key specifications for the ONIKUMA K5 Pro Gaming Headset:

- **Brand:** ONIKUMA
- **Model Name:** K5 Pro (Red)
- **Connectivity Technology:** Wired
- **Headphone Jack:** 3.5mm Jack
- **Ear Placement:** Over Ear
- **Form Factor:** Over Ear
- **Noise Control:** Active Noise Cancellation (for microphone)
- **Sensitivity:** 99 dB
- **Included Components:** Headband, Ear Cushions
- **Color:** Red

WARRANTY AND SUPPORT

For detailed warranty information, technical assistance, or customer support regarding your ONIKUMA K5 Pro Gaming Headset, please refer to the official ONIKUMA website or contact the retailer from whom you purchased the product. It is recommended to retain your purchase receipt as proof of purchase for any warranty claims.