



[Manuals.plus](#) /

› [pTron](#) /

› pTron Bassbuds Air TWS Earbuds User Manual

pTron Bassbuds Air

pTron Bassbuds Air TWS Earbuds User Manual

Model: Bassbuds Air

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your pTron Bassbuds Air True Wireless Stereo (TWS) Earbuds. Please read this guide thoroughly before operating the device and retain it for future reference.



Image: pTron Bassbuds Air TWS Earbuds and their charging case in dark blue.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- 1 x pTron Bassbuds Air Earbuds (Left and Right)
- 1 x Charging Case
- 1 x Extra Ear Tips (S/M/L sizes)
- 1 x USB Type-C Charging Cable
- 1 x User Manual (this document)
- 1 x Warranty Card

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case provides extended playtime for the earbuds.

- Insert the earbuds into their respective slots in the charging case. Ensure the charging contacts align.
- Connect the provided USB Type-C charging cable to the charging port on the case and to a DC5V-1A power adapter (not included).
- The indicator light on the case will show charging status. Once fully charged, the indicator light may change or turn off.
- **Caution:** Using incompatible USB cables or high voltage chargers can damage the product and void the warranty. Always use DC5V-1A chargers.



Image: The pTron Bassbuds Air charging case with earbuds inside, connected to a Type-C charging cable.

2. Pairing with a Device

The earbuds feature 1-step pairing for quick and easy connection.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices and select "**pTron Bassbuds Air**" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
6. The earbuds will automatically re-connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.



13mm
Dynamic Driver



32 Hrs
Playtime



Advance
bluetooth 5.1



Built in HD Mic



Passive Noise
cancellation



Ultra
lightweight



Voice Assistant
Support



Snug-fit
In-ear design



IPX4 Water/
Sweat Proof



Smart touch
controls - Call & Music

Available in **3** colours



Image: pTron Bassbuds Air earbuds shown next to a smartphone, illustrating Bluetooth connectivity.

OPERATING THE EARBUDS

Touch Controls

The pTron Bassbuds Air feature intuitive touch controls on each earbud for managing music playback, calls, and voice assistant activation.

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud
Activate Voice Assistant	Triple tap on either earbud



Image: A close-up view of a pTron Bassbuds Air earbud, indicating the location of the touch sensor for controls.

Voice Assistant

Your pTron Bassbuds Air earbuds support instant access to your device's voice assistant (e.g., Google Assistant, Siri). Triple tap either earbud to activate it.

Mono Bud Capability

You can use either the left or right earbud independently for calls or music playback. Simply take one earbud out of the case, and it will connect to your device.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips periodically. Ensure they are completely dry before reattaching.
- **Charging Contacts:** Keep the charging contacts on both the earbuds and inside the case clean and free of debris to ensure proper charging.
- **Water Resistance:** The earbuds are IPX4 water/sweat resistant, meaning they are protected against splashing water from any direction. They are not designed for submersion in water. Do not expose them to heavy rain or immerse them in liquids.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.



Image: pTron Bassbuds Air earbuds with water droplets, demonstrating their IPX4 water and sweat resistance.

TROUBLESHOOTING

If you encounter issues with your pTron Bassbuds Air, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing/connecting	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "pTron Bassbuds Air" from your device's Bluetooth list and try pairing again. ◦ Place earbuds back in the case, close it, wait a few seconds, then open to re-enter pairing mode.
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid, then open it again. ◦ Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, forgetting and re-pairing often works).
Earbuds not charging	◦ Ensure the charging cable is securely connected to both the case and the power adapter. ◦ Verify the power adapter is DC5V-1A. ◦ Clean the charging contacts on the earbuds and inside the case with a dry cotton swab. ◦ Try a different USB Type-C cable or power adapter.

Problem	Possible Solution
Low volume or poor sound quality	◦ Adjust the volume on both your device and the earbuds. ◦ Ensure ear tips are properly seated in your ear canal for a good seal. ◦ Clean any earwax or debris from the earbud speakers. ◦ Try different sized ear tips for a better fit.
Call quality issues	◦ Ensure the microphone on the earbuds is not obstructed. ◦ Move closer to your connected device to improve Bluetooth signal. ◦ Test call quality in a quieter environment.

SPECIFICATIONS

Key technical specifications for the pTron Bassbuds Air TWS Earbuds:

- **Model Name:** Bassbuds Air
- **Ear Placement:** In Ear
- **Form Factor:** In Ear
- **Driver Size:** 13mm Dynamic Driver
- **Impedance:** 32 Ohms
- **Bluetooth Version:** 5.1
- **Wireless Range:** Up to 10 meters (33 feet)
- **Battery Life (Earbuds):** Up to 32 hours (with charging case)
- **Charging Port:** USB Type-C
- **Water Resistance:** IPX4 (Water/Sweat Resistant)
- **Noise Control:** Passive Noise Cancellation
- **Control Method:** Touch
- **Frequency Range:** 20Hz - 20kHz
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Item Weight:** 43 Grams (total, likely case + earbuds)
- **Compatible Devices:** All Bluetooth Devices, Laptops, Mobile Phones, Tablets, PC, Smart TVs, iOS, Android



Bassbuds Air

Truly Wireless
Stereo Earbuds




Image: An exploded view of the pTron Bassbuds Air earbud, highlighting the 13mm dynamic driver for immersive sound.

WARRANTY AND SUPPORT

Your pTron Bassbuds Air TWS Earbuds come with a manufacturer's warranty and dedicated customer support.

- **Warranty:** 1-Year Manufacturer Warranty from the date of purchase, covering manufacturing defects only.
- **Manufacturer:** PALRED ELECTRONICS PVT. LTD.
- **Customer Care Details:**
 - Phone: 040-67138888
 - Email: Support@pTron.in
- **Manufacturer Address:** SY.NO. 56, 1ST FLOOR, GUNDLAPOCHAMPALLY VILLAGE, TECH PARK MTP, TSIC-IALA NACHARAM, HYDERABAD - 500076, TELANGANA, INDIA.