

[Manuals.plus](#) /

› [Xiaomi](#) /

› Xiaomi Redmi Buds 5 Wireless Earphone User Manual

Xiaomi BHR7628GL

Xiaomi Redmi Buds 5 Wireless Earphone User Manual

Model: BHR7628GL

INTRODUCTION

The Xiaomi Redmi Buds 5 are advanced wireless earphones designed for an immersive audio experience. Featuring 46dB wideband active noise cancellation, a long-lasting 40-hour battery life, and Bluetooth 5.3 connectivity, these earbuds provide superior sound quality and comfort. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your Redmi Buds 5.

PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- Xiaomi Redmi Buds 5 Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual
- Ear Tips (various sizes)



Image: The Xiaomi Redmi Buds 5 earbuds are shown inside their open white charging case. The case has a USB-C charging port at the front base.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the Redmi Buds 5 and their charging case. Connect the USB Type-C cable to the charging port on the case and the other end to a power source. The indicator light on the case will show the charging status. A full charge for the case takes approximately 2 hours.

- **Earbud Battery Capacity:** 54mAh (each)
- **Charging Case Battery Capacity:** 480mAh
- **Charging Port:** Type-C
- **Fast Charging:** Charge for 5 minutes, listen for 2 hours.



Image: A close-up view of the white Redmi Buds 5 charging case, showing the Redmi logo on the lid and the USB-C charging port at the front.

2. Pairing with a Device

1. Ensure the earbuds are in the charging case and the case has sufficient battery.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing light on the case.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Redmi Buds 5" from the list of found devices to connect.
5. Once connected, the indicator light on the case will turn solid or off, depending on the model.

The Redmi Buds 5 utilize **Bluetooth 5.3** for stable and efficient wireless connection, with a communication range of up to **10 meters** in open, obstacle-free spaces.

3. Wearing the Earbuds

The Redmi Buds 5 feature a comfortable rod design. Choose the ear tips that provide the best seal and comfort for your ears. Insert the earbuds gently into your ear canal and rotate them slightly until they fit snugly and securely.



Image: Left: Front view of the white Redmi Buds 5 earbuds, showing the 'R' and 'L' markings for right and left ears. Right: Side view of the white Redmi Buds 5 earbuds, highlighting their ergonomic shape.

OPERATING INSTRUCTIONS

Active Noise Cancellation (ANC) and Transparency Modes

The Redmi Buds 5 offer advanced noise cancellation and transparency features:

- **Active Noise Cancellation (ANC):** Provides up to 46dB noise reduction, effectively blocking out background noise, especially low-frequency sounds like those from aircraft or subways.
- **Transparency Modes:** Allows you to hear your surroundings clearly without removing the earbuds. There are three available pass-through modes to suit different environments.

Switch between ANC, Transparency, and Standard modes using the touch controls on the earbuds.

Touch Controls

The Redmi Buds 5 feature intuitive touch controls on the earbud stems. Specific functions can typically be customized via the companion app (if available in your region). Common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold on either earbud.
- **Switch ANC/Transparency Mode:** Press and hold on either earbud (duration may vary).

Refer to the specific touch control settings within the Xiaomi Earbuds app for detailed customization options.

Battery Life

The Redmi Buds 5 offer extended battery performance:

- **Single Earbud Playtime:** Up to 10 hours on a single charge.
- **Total Playtime with Charging Case:** Up to 40 hours.

Battery life may vary based on volume level, ANC usage, and other factors.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Redmi Buds 5.

Cleaning

- Regularly clean the ear tips and mesh grilles of the earbuds to prevent wax buildup, which can affect sound quality. Use a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid getting liquid into the earbud openings.
- Clean the charging contacts on both the earbuds and inside the charging case with a dry cotton swab.
- Wipe the charging case exterior with a soft, dry cloth.

Storage

- Always store the earbuds in their charging case when not in use to protect them from damage and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Redmi Buds 5, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Bluetooth is off on device; earbuds not in pairing mode; interference.	Ensure Bluetooth is enabled on your device. Place earbuds in case, close lid, then open to re-enter pairing mode. Forget "Redmi Buds 5" from your device's Bluetooth list and re-pair. Move closer to your device.
No sound or low volume.	Volume too low; earbuds dirty; improper fit; connection issue.	Increase volume on your device and earbuds. Clean earbud mesh and ear tips. Adjust earbuds for a secure fit. Reconnect the earbuds to your device.
Earbuds not charging.	Charging cable/port issue; dirty charging contacts; case battery empty.	Ensure charging cable is securely connected. Clean charging contacts on earbuds and case. Charge the charging case. Try a different USB-C cable or power adapter.

Problem	Possible Cause	Solution
Active Noise Cancellation not effective.	Improper fit; wrong mode selected; environmental noise type.	Ensure earbuds are properly seated in your ears for a good seal. Confirm ANC mode is activated via touch controls or app. ANC is most effective against low-frequency, constant noise.

SPECIFICATIONS

Feature	Detail
Model Name	Buds 5 White
Model Number	BHR7628GL
Brand	Xiaomi
Color	White
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Protocols	HSP, HFP, A2DP, AVRCP
Communication Range	10m (open space free of obstacles)
Noise Control	Active Noise Cancellation (46dB)
Form Factor	In Ear
Earbud Battery Capacity	54mAh (each)
Charging Case Battery Capacity	480mAh
Earbud Battery Life	Up to 10 hours (single charge)
Total Battery Life	Up to 40 hours (with charging case)
Charging Port	Type-C
Charging Time (Case)	Approx. 2 hours
Control Method	Touch
Weight of a single earbud	5.3g
Dimensions of a single earbud	29.5 × 21.4 × 23.5mm
Weight of charging case	31.4g
Dimensions of charging case	61 × 50 × 24.6mm
Total Weight (Earbuds + Case)	42g

Feature	Detail
Speaker Impedance	32Ω

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Xiaomi website or contact Xiaomi customer service in your region. Keep your proof of purchase for warranty claims.

You can visit the official Xiaomi store for more information and support:

[Xiaomi Official Store](#)