

[Manuals.plus](#) /

› [Sennheiser](#) /

› Sennheiser ACCENTUM True Wireless Earbuds - Instruction Manual

Sennheiser 700262

Sennheiser ACCENTUM True Wireless Earbuds

Model: 700262

INTRODUCTION

The Sennheiser ACCENTUM True Wireless Earbuds deliver crystal-clear sound with Hybrid Active Noise Cancellation (ANC) and an ergonomic design for extended comfort. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity.

WHAT'S IN THE BOX

Upon unboxing your Sennheiser ACCENTUM True Wireless Earbuds, you will find the following components:

- ACCENTUM Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Adapter Sets (various sizes for optimal fit)



Figure 1: Sennheiser ACCENTUM True Wireless Earbuds in their charging case, showcasing the compact design and included USB-C charging port.
 Video 1: A brief overview of the Sennheiser ACCENTUM True Wireless Earbuds and their packaging contents, including the charging case, earbuds, and various ear tips.

DESIGN AND COMFORT

The ACCENTUM earbuds feature a sleek, ergonomic design crafted for all-day listening comfort and a secure fit. Their smooth, pebble-like shape is designed to minimize irritation, making them suitable for extended wear.




Figure 2: The Sennheiser ACCENTUM True Wireless Earbuds and their charging case displayed on a patterned surface, highlighting their compact and smooth form factor.




Figure 3: A close-up of a person wearing one of the Sennheiser ACCENTUM True Wireless Earbuds, illustrating how the earbud sits securely and comfortably within the ear's concha.

SETUP AND PAIRING

Setting up and pairing your Sennheiser ACCENTUM earbuds with your device is a straightforward process. The earbuds are designed to enter pairing mode automatically upon first use. Simply open your device's Bluetooth menu and select the ACCENTUM earbuds to connect instantly.

ACTIVE NOISE CANCELLATION (ANC)

The ACCENTUM earbuds feature Hybrid Active Noise Cancellation (ANC), which utilizes microphones on both the outside and inside of the earbuds to effectively block out ambient noise. This creates a quiet listening environment, allowing you to immerse yourself in your audio without distractions. You can activate ANC by triple-tapping the left earbud or by adjusting the settings within the Sennheiser Smart Control app.



Figure 4: The earbuds in their charging case, illustrating the Hybrid ANC capability that allows for effective noise cancellation.

SOUND QUALITY

Sennheiser is renowned for its audio quality, and the ACCENTUM True Wireless Earbuds uphold this reputation. They deliver a rich and detailed sound experience, with clear intricacies in the music and a deep, impactful bass. The higher frequencies are delicate and clear, free from any harshness often found in lower-quality earbuds.



Figure 5: A user experiencing immersive sound with the Sennheiser ACCENTUM True Wireless Earbuds, highlighting the superior audio performance.

CONTROLS

Both earbuds feature touch-sensitive surfaces, providing intuitive control over your audio and calls. Various functions can be accessed by tapping the earbuds a specific number of times, offering a responsive and convenient user experience.

BATTERY LIFE AND CHARGING

The Sennheiser ACCENTUM earbuds offer up to 8 hours of music playback on a single charge, or 6 hours with ANC activated. The compact charging case provides an additional 20 hours of battery life, extending your listening time significantly. The case supports both USB-C charging (approximately 90 minutes for a full charge) and Qi wireless charging for added convenience.




Figure 6: The charging case connected via USB-C, showing the green indicator light that signifies charging status.

SPECIFICATIONS

Feature	Specification
---------	---------------

Model Name	ACCENTUM True Wireless
Connectivity Technology	Wireless (Bluetooth 5.3)
Noise Control	Active Noise Cancellation (Hybrid)
Battery Life (Earbuds)	8 Hours
Charging Case Battery Life	20 Hours (additional)
Charging Time (Case)	Approx. 90 minutes (USB-C)
Wireless Charging	Yes (Qi compatible)
Control Method	Touch
Item Weight	1.83 ounces (52 grams)
Water Resistance Level	Not Water Resistant

TROUBLESHOOTING

If you encounter any issues with your Sennheiser ACCENTUM True Wireless Earbuds, please refer to the following common troubleshooting steps:

- **No Sound:** Ensure the earbuds are charged, properly paired with your device, and the volume is turned up. Check if the earbuds are correctly seated in your ears.
- **Pairing Issues:** Turn off and on your device's Bluetooth. Place the earbuds back in the charging case, close the lid, wait a few seconds, then open it again to re-enter pairing mode.
- **Charging Problems:** Verify the USB-C cable is securely connected to both the case and a power source. If using wireless charging, ensure the case is correctly placed on a Qi-compatible charging pad.
- **ANC Not Working:** Ensure ANC is activated via the touch controls or the Sennheiser Smart Control app. Check for a secure fit of the ear tips, as a proper seal is crucial for effective noise cancellation.

WARRANTY AND SUPPORT

Your Sennheiser ACCENTUM True Wireless Earbuds are covered by a manufacturer's warranty. For detailed warranty information, product support, or service inquiries, please visit the official Sennheiser website or contact their customer support directly. Keep your proof of purchase for warranty claims.