

Spigen S520

Spigen Velo S520 Bluetooth Selfie Stick User Manual

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your Spigen Velo S520 Bluetooth Selfie Stick. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Spigen Velo S520 is a compact and extendable Bluetooth-enabled selfie stick designed for capturing photos and videos with your smartphone. It features an integrated remote shutter and an adjustable phone holder.

Components:

- Extendable Monopod Stick
- Adjustable Phone Holder
- Bluetooth Remote Shutter Button
- Micro USB Charging Port
- Wrist Strap



Figure 1: Spigen Velo S520 Bluetooth Selfie Stick (folded)



Figure 2: Front view of the folded selfie stick with Bluetooth indicator

SETUP

1. Charging the Device

Before initial use, fully charge the Spigen Velo S520. Connect the provided Micro USB cable to the charging port located at the bottom of the handle and plug the other end into a USB power source. A full charge typically takes approximately 30 minutes. The indicator light will change to show charging status.

2. Bluetooth Pairing

1. Ensure your smartphone's Bluetooth is enabled.
2. Press and hold the shutter button on the selfie stick until the indicator light begins to flash, indicating

pairing mode.

3. On your smartphone, search for Bluetooth devices and select "Spigen S520" from the list.
4. Once paired, the indicator light on the selfie stick will stop flashing and remain solid.

3. Attaching Your Smartphone

Gently pull open the adjustable phone holder. Insert your smartphone into the holder, ensuring it is securely gripped by the rubberized pads. The holder accommodates smartphones between 2 and 3 inches in width.



Figure 3: Inserting a smartphone into the holder

OPERATING INSTRUCTIONS

1. Power On/Off

- **To Power On:** Press and hold the shutter button for a few seconds until the indicator light illuminates.
- **To Power Off:** Press and hold the shutter button for a few seconds until the indicator light turns off.

2. Extending and Adjusting the Stick

Gently pull the telescoping sections of the stick to extend it to your desired length. The stick can extend up to 31.5 inches. To collapse, push the sections back into the handle. The phone holder can be rotated up to 270 degrees to achieve various shooting angles.

LENGTH-WISE

Selfie stick extends to a comfortable length of 31.5 inches and collapses to 7.3 inches for versatile usability.



Figure 4: Selfie stick dimensions (collapsed and extended)

3. Taking Photos/Videos

Once your smartphone is paired and securely mounted, open your phone's camera application. Press the shutter button on the selfie stick to capture a photo or start/stop video recording.



Figure 5: User operating the selfie stick with a smartphone

HANDS-ON COMFORT

Stick handle comes with a rubber coating for extra comfort and grip in the hands.



Figure 6: Ergonomic handle design

MAINTENANCE

- Keep the device clean by wiping it with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures, moisture, or direct sunlight.
- Do not use abrasive cleaners or solvents.
- Store the selfie stick in a cool, dry place when not in use.

TROUBLESHOOTING

Device Not Pairing

- Ensure the selfie stick is charged and powered on.
- Verify Bluetooth is enabled on your smartphone.
- Try unpairing and re-pairing the device from your smartphone's Bluetooth settings.
- Restart both the selfie stick and your smartphone.

Shutter Button Not Working

- Confirm the selfie stick is successfully paired with your smartphone.
- Ensure your smartphone's camera application is open and active.
- Some phone models may require specific camera settings or a third-party camera app to function correctly with Bluetooth shutters.

Charging Issues

- Verify the Micro USB cable is securely connected to both the selfie stick and the power source.
- Try using a different Micro USB cable or power adapter.
- Ensure the charging port on the selfie stick is free of debris.

SPECIFICATIONS

Model Number	SGP11721
Product Dimensions (Collapsed)	0.59 x 0.31 x 0.39 inches (7.3 inches length)
Extended Length	Up to 31.5 inches
Item Weight	4.2 ounces
Battery Type	1 Lithium Polymer battery (required)
Standby Time	72 hours
Usage Duration	20 hours
Charging Time	Approximately 30 minutes
Compatible Devices	Smartphones (2" to 3" width), Bluetooth-enabled devices
Connectivity	Bluetooth

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Spigen website or contact Spigen customer service directly. Keep your purchase receipt for warranty claims.