

[Manuals.plus](#) /

› [VIVO](#) /

› Vivo V40 5G Smartphone User Manual

VIVO V2348

Vivo V40 5G Smartphone User Manual

Model: V2348 | Brand: VIVO

INTRODUCTION

Welcome to the user manual for your new Vivo V40 5G Smartphone. This guide provides detailed instructions on setting up, operating, maintaining, and troubleshooting your device. The Vivo V40 5G features a seamless 6.78-inch 2800x1260 AMOLED display with a 120Hz refresh rate, powered by a Qualcomm Snapdragon 7 Gen 3 processor. It boasts a versatile dual-camera system with 50MP AF front and 50MP AF+OIS (Zeiss) rear cameras, and a 50MP AF (Zeiss) wide-angle lens. With a 5500mAh battery and 80W fast charging, your device is designed for efficient functionality and captivating captures.



Image: Front and back view of the Vivo V40 5G Smartphone in Ganges Blue. The front displays a vibrant screen, and the back shows the camera module and Vivo branding.

1. SETUP

1.1 Unboxing and Initial Inspection

Carefully open the packaging and ensure all components are present. The box should contain:

- Vivo V40 5G Smartphone
- Charger (80W USB Type-C)
- SIM Ejector Tool
- Quick Start Guide and Warranty Card



Image: Angled view of the Vivo V40 5G Smartphone, highlighting its slim profile and curved display.

1.2 Charging the Device

Before first use, it is recommended to fully charge your Vivo V40 5G.

1. Connect the USB Type-C end of the charging cable to the phone's charging port.
2. Connect the other end of the cable to the 80W charger.
3. Plug the charger into a power outlet.
4. The charging indicator will appear on the screen. The 5500mAh battery supports 80W fast charging for quick power-ups.

India's Slimmest Smartphone in the 5500 mAh battery category*

80W
Flashcharge**

0.758 cm
Slim

5500 mAh



*The vivo V40 and V40Pro are the slimmest (0.758 cm in thickness) smartphones in the 5500mAh battery category, according to internal research as of July 12, 2024.

**V40 Series is equipped with vivo standard charger, and supports upto 80W of charging power

***The typical battery capacity is 5500 mAh, and the rated battery capacity is 5380 mAh

Image: Visual representation of the Vivo V40 5G's 5500 mAh battery capacity and 80W Flashcharge capability, emphasizing its slim design.

1.3 SIM Card Installation

To use cellular services, you need to install a SIM card.

1. Locate the SIM card tray on the side of the phone.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. Ensure proper orientation.

- Carefully push the tray back into the slot until it clicks into place.

1.4 Initial Power On and Setup Wizard

Press and hold the Power button until the Vivo logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account setup, and security settings.

2. OPERATING YOUR VIVO V40 5G

2.1 Display and Navigation

The Vivo V40 5G features a 6.78-inch 2800x1260 AMOLED display with a 120Hz refresh rate for smooth visuals.

- **Touchscreen Gestures:** Navigate using taps, swipes, pinches, and long presses.
- **Navigation Bar:** Use the on-screen navigation buttons (Back, Home, Recent Apps) or enable gesture navigation in settings.
- **Quick Settings:** Swipe down from the top of the screen to access quick settings toggles and notifications.




Image: Highlights of the Vivo V40 5G's Ultra-Slim 3D Curved Display, Power Packed Performance with Snapdragon 7 Gen 3, AI Object

Eraser feature, and ZEISS Cinematic Portrait Video capabilities.

2.2 Performance and Storage

Powered by the Qualcomm Snapdragon 7 Gen 3 processor and 8GB RAM, the V40 5G ensures seamless multitasking and smooth app performance.

- **App Management:** Close background apps to optimize performance.
- **Storage:** The device comes with 128GB of internal storage, providing ample space for apps, photos, and videos.

2.3 Camera Features

The Vivo V40 5G features an advanced dual-camera system for high-quality photography.

- **Rear Cameras:** 50MP AF+OIS (Zeiss) main camera and a 50MP AF (Zeiss) wide-angle camera.
- **Front Camera:** 50MP AF front camera for high-resolution selfies.
- **Zeiss Integration:** Benefit from Zeiss-tuned optics and features like Zeiss Style Portrait and Cinematic Portrait Video for enhanced image quality and creative effects.



Image: Detailed breakdown of the Vivo V40 5G's ZEISS camera system, including the 50MP ZEISS Group Selfie Camera, 50MP ZEISS

ZEISS Style Portrait

Dynamic Ambience Portraits with
7-Zeiss Style Portrait




Image: Illustration of ZEISS Style Portrait features, showcasing dynamic ambience portraits with various Zeiss-inspired bokeh styles like Biotar, B-speed, Sonnar, Distagon, Cine-flare, Cinematic, and Planar.

2.4 Connectivity

The device supports various connectivity options:

- **5G:** For high-speed mobile data.
- **Wi-Fi:** Connect to wireless networks for internet access.
- **Bluetooth:** Pair with wireless headphones, speakers, and other devices.
- **USB Type-C:** For charging, data transfer, and connecting accessories.

3. MAINTENANCE

3.1 Cleaning Your Device

To keep your phone in optimal condition:

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.
- Do not expose the phone to excessive moisture.

3.2 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to *Settings > System > System update*

3.3 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery drain completely frequently.
- Use the original charger provided with the device.

4. TROUBLESHOOTING

4.1 Common Issues and Solutions

Issue	Possible Solution
Phone not turning on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds to force restart.
Apps crashing or freezing	Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the phone. Update the app.
Overheating	Avoid using the phone while charging. Close background apps. Reduce screen brightness. If persistent, contact support.
Poor network signal	Check SIM card insertion. Restart the phone. Try resetting network settings (Settings > System > Reset options > Reset Wi-Fi, mobile & Bluetooth).

4.2 Factory Reset

If issues persist, a factory reset may be necessary. **Warning: This will erase all data on your phone. Back up important data before proceeding.** Go to *Settings > System > Reset options > Erase all data (factory reset)*

5. SPECIFICATIONS

Feature	Detail
Model Number	V2348
Operating System	Android 14
RAM	8 GB

Feature	Detail
Storage	128 GB (internal)
Display	6.78-inch AMOLED, 2800x1260 Resolution, 120Hz Refresh Rate
Processor	Qualcomm Snapdragon 7 Gen 3
Rear Camera	50MP AF+OIS (Zeiss) + 50MP AF (Zeiss) Wide-angle
Front Camera	50MP AF
Battery Capacity	5500 mAh
Charging	80W USB Type-C Fast Charging
Dimensions	16.42 x 7.49 x 0.76 cm
Weight	190 g
Connectivity	5G, Wi-Fi, Bluetooth, USB
Color	Ganges Blue

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Your Vivo V40 5G Smartphone comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for detailed terms and conditions, including coverage period and what is covered. Keep your proof of purchase for warranty claims.

6.2 Customer Support

For further assistance, technical support, or service inquiries, please contact Vivo customer support through their official website or the contact information provided in your warranty documentation.

You can also visit the official Vivo store on Amazon for product information and support:[Vivo Store on Amazon](#).

