

Google Pixel 8 Pro

Google Pixel 8 Pro Smartphone User Manual

Model: Pixel 8 Pro

INTRODUCTION

Welcome to the user manual for your new Google Pixel 8 Pro smartphone. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and user experience.

Box Contents

Upon unboxing your Google Pixel 8 Pro, please verify that the following items are included:

- Handset (Google Pixel 8 Pro)
- 1 meter USB-C to USB-C Cable (USB 2.0)
- Quick Switch Adaptor
- SIM Tool

Note: A power adapter is not included and must be purchased separately. For optimal fast charging, use a Google 30W USB-C Charger with USB-PD 3.0 (PPS).

SETUP

1. Initial Charging

Before first use, it is recommended to fully charge your Pixel 8 Pro. Connect the provided USB-C cable to the phone's USB-C port and to a compatible USB-C power adapter (sold separately). The device supports fast charging and wireless charging.



Image: The Google Pixel 8 Pro in Obsidian color, showing its sleek design and camera module. This image illustrates the device for initial setup and handling.

2. SIM Card Installation

The Pixel 8 Pro supports Dual SIM functionality (Nano SIM + eSIM).

1. Locate the SIM tray on the side of your device.
2. Insert the provided SIM tool into the small hole on the SIM tray to eject it.
3. Place your Nano SIM card into the tray with the gold contacts facing down.
4. Carefully reinsert the SIM tray into the phone.
5. For eSIM activation, follow the on-screen instructions during initial setup or navigate to Settings > Network & internet > SIMs.

3. Powering On/Off

- **To Power On:** Press and hold the Power button (located on the right side) until the Google logo appears.
- **To Power Off:** Press and hold the Power button and Volume Up button simultaneously, then tap "Power off" on the screen. Alternatively, swipe down from the top of the screen twice to open Quick Settings, tap the power icon, and select "Power off".

4. Initial Device Setup

Follow the on-screen prompts to complete the initial setup process. This includes connecting to Wi-Fi, signing in with your Google account, setting up security features (fingerprint, face unlock, PIN/pattern), and transferring data from an old device using the Quick Switch Adaptor.

OPERATING YOUR GOOGLE PIXEL 8 PRO

1. Basic Navigation

The Pixel 8 Pro features a 6.7-inch Full HD+ AMOLED LTPO display with a smooth display refresh rate (1-120 Hz). Navigate using touch gestures:

- **Tap:** Select items or open apps.
- **Swipe:** Scroll through screens or content.
- **Pinch:** Zoom in or out on photos and web pages.
- **Long Press:** Access contextual menus or move app icons.

2. Calls and Messaging

Use the Phone app for making and receiving calls. The Messages app handles SMS and MMS. Google Assistant can help screen calls and provide real-time translation.

3. Camera Features

The Pixel 8 Pro is equipped with an advanced camera system:

- **Rear Camera:** Triple camera setup (50MP + 48MP Ultrawide + 48MP Telephoto) with up to 20x Super Res Zoom.
- **Front Camera:** 10.5MP for high-quality selfies and video calls.
- **Key Features:** Pro Controls, Ultra HDR, Magic Editor, Best Take, Macro Focus, Magic Eraser, Photo Unblur, Night Sight, Astrophotography, Portrait Mode, Cinematic Blur, Cinematic Pan, Audio Magic Eraser for videos.

Amazing photos, every time.

Pro controls

Unlocks advanced settings and supports full-resolution images.⁵

Low-light photos

The camera delivers amazing photo quality from dusk until dawn.

Best Take

Combines similar photos into one where everyone looks their best.¹²




Image: A close-up of the Google Pixel 8 Pro's rear camera module, highlighting the triple lens setup. This illustrates the advanced camera hardware.

4. Connectivity

Your device supports a range of connectivity options:

- **Network:** 5G, 4G LTE, 3G, 2G.
- **Wi-Fi:** Wi-Fi 6 (802.11ax) with Wi-Fi Hotspot capability.
- **Bluetooth:** Version 5.3.
- **NFC:** For contactless payments and quick pairing.

5. Security Features

Protect your device and data using:

- **Fingerprint Recognition:** In-display fingerprint sensor for secure unlocking.
- **Face Unlock:** Securely unlock your phone using facial recognition.
- **PIN/Pattern/Password:** Standard Android security options.
- **Anti-Malware and Anti-Phishing Protection:** Enhanced security features including support for passkeys.

MAINTENANCE

1. Software Updates

Your Pixel 8 Pro runs on Android 14 and receives regular software and security updates directly from Google. Ensure your device is connected to Wi-Fi and has sufficient battery life before performing updates. To check for updates, go to Settings > System > Software updates.

2. Cleaning Your Device

To clean your phone, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials, as these can damage the screen and finish. The device has a water-resistant rating, but it is not waterproof; avoid submerging it in liquids.

3. Battery Care

The Pixel 8 Pro is equipped with a 5050 mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Use the provided USB-C cable and a compatible charger.
- Utilize battery-saving modes when needed.
- The device supports fast charging (up to 50% charge in about 30 minutes with a Google 30W USB-C Charger) and fast wireless charging. It also features Battery Share for reverse wireless charging.

TROUBLESHOOTING

Common Issues and Solutions

- **Device Not Responding:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **Battery Draining Quickly:** Check app usage in Settings > Battery. Reduce screen brightness, disable unnecessary features like GPS or Bluetooth when not in use. Ensure all apps are updated.
- **Connectivity Problems (Wi-Fi/Bluetooth/Cellular):**
 - Toggle Wi-Fi/Bluetooth/Cellular off and on.
 - Restart your phone.
 - Forget and reconnect to Wi-Fi networks or Bluetooth devices.
 - Reset network settings (Settings > System > Reset options > Reset Wi-Fi, mobile & Bluetooth).
- **Apps Crashing or Freezing:** Clear the app's cache and data (Settings > Apps > See all apps > [App Name] > Storage & cache). If the issue persists, uninstall and reinstall the app.
- **Overheating:** Close background apps, reduce screen brightness, avoid using the phone while charging, and ensure it's not exposed to direct sunlight. If overheating persists, contact support.

Factory Reset

If you encounter persistent software issues, a factory reset may resolve them. **Warning: This will erase all data on your phone. Back up important data before proceeding.**

1. Go to Settings > System > Reset options.
2. Tap "Erase all data (factory reset)".
3. Confirm your decision and follow the on-screen instructions.

SPECIFICATIONS

Brand	Google
Model Name	Pixel 8 Pro
Operating System	Android 14
Processor	Google Tensor G3
RAM	12 GB
Internal Storage	128 GB
Display Size	17.02 cm (6.7 inch)
Display Type	Full HD+ LTPO OLED, 1-120 Hz Smooth Display
Resolution	2992 x 1344 Pixels
Rear Camera	50MP + 48MP (Ultrawide) + 48MP (Telephoto)
Front Camera	10.5MP
Battery Capacity	5050 mAh
SIM Type	Dual SIM (Nano + eSIM)
Connectivity	5G, Wi-Fi 6 (802.11ax), Bluetooth v5.3, NFC
Sensors	Proximity, Ambient Light, Accelerometer, Gyrometer, Magnetometer, Barometer, Temperature Sensor, Fingerprint Recognition
Dimensions (H x W x D)	162.6 mm x 76.5 mm x 8.8 mm
Weight	213 g
Water Resistance	Water Resistant

WARRANTY AND SUPPORT

Warranty Information

Your Google Pixel 8 Pro comes with a **1 Year Domestic Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For further assistance, technical support, or warranty claims, please visit the official Google Support website or contact Google customer service. You can find detailed support resources, FAQs, and contact options on their website.

For online support, search for "Google Pixel Support" on your web browser.

