

[Manuals.plus](#) /

› [Nothing](#) /

› Nothing Phone (3a) Pro 5G User Manual

Nothing Phone (3a) Pro 5G

Nothing Phone (3a) Pro 5G User Manual

Model: Phone (3a) Pro 5G

1. INTRODUCTION

Welcome to the user manual for your Nothing Phone (3a) Pro 5G. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure optimal performance and longevity of your smartphone.



Figure 1: Nothing Phone (3a) Pro 5G. This image displays the front and back of the Nothing Phone (3a) Pro 5G, highlighting its design and camera module.

2. SETUP

2.1 Unboxing and Package Contents

Upon opening the package, verify that all components are present. Typically, the box contains:

- Nothing Phone (3a) Pro 5G device
- USB-C Cable
- SIM Ejector Tool
- Quick Start Guide (refer to this manual for detailed instructions)

2.2 SIM Card Installation

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. The Nothing Phone (3a) Pro 5G supports Dual SIM.
4. Carefully reinsert the tray into the phone.

2.3 Initial Power On and Configuration

1. Press and hold the Power button until the Nothing logo appears.

2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and sign in with your Google account.
3. Complete the setup process, including setting up fingerprint recognition for enhanced security.

2.4 Charging the Device

Connect the provided USB-C cable to the phone's charging port and the other end to a compatible power adapter. The device supports fast charging. Ensure the phone is adequately charged before first use.

3. OPERATING INSTRUCTIONS

3.1 Basic Operations

- **Power On/Off:** Press and hold the Power button. Select "Power off" or "Restart" from the options.
- **Volume Control:** Use the Volume Up and Volume Down buttons located on the side of the device.
- **Screen Lock/Unlock:** Press the Power button briefly to lock or unlock the screen.
- **Navigation:** Utilize gestures or the traditional navigation bar (Back, Home, Recent Apps) as configured in settings.

3.2 Display Features

Your Nothing Phone (3a) Pro 5G features a 17.2 cm (6.77 inch) Full HD+ Flexible AMOLED Display with a resolution of 1080 x 2392 pixels and a 120Hz refresh rate. This provides vibrant colors and smooth scrolling. Adjust display settings such as brightness, dark mode, and refresh rate in the Settings menu.

3.3 Camera Usage

The device is equipped with a versatile camera system:

- **Rear Cameras:** 50MP Main, 50MP 3X Periscope, and 8MP Ultra-Wide lenses.
- **Front Camera:** 50MP for high-quality selfies and video calls.

To capture photos or videos, open the Camera application. Select desired modes (Photo, Video, Portrait, Night, etc.) and adjust settings as needed. The phone supports video recording up to 3840 x 2160 pixels (4K) at various frame rates (30, 60, 120 fps).

3.4 Connectivity

The Nothing Phone (3a) Pro 5G supports a range of connectivity options:

- **Cellular:** 2G, 3G, 4G, and 5G networks.
- **Wireless:** Wi-Fi (GSM, LTE, UMTS) for internet access and Bluetooth for connecting accessories.
- **Wired:** USB-C port for charging and data transfer.

3.5 Security Features

Enhance your device security using the integrated Fingerprint Recognition. You can set up and manage your fingerprints in the Security settings.

3.6 Battery Management

The device is powered by a 5000 mAh battery. To optimize battery life:

- Adjust screen brightness.
- Close unused applications running in the background.

- Utilize power-saving modes when necessary.
- Avoid extreme temperatures.

Average battery life is approximately 13.5 hours, with up to 38 hours of talk time.

4. MAINTENANCE

4.1 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials, which can damage the display or finish.

4.2 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Navigate to **Settings > System > System update** to check for updates.

4.3 Water Resistance

The Nothing Phone (3a) Pro 5G is water resistant. However, this is not a permanent condition and resistance might decrease as a result of normal wear. Avoid intentional submersion and exposure to high-pressure water.

5. TROUBLESHOOTING

If you encounter issues with your Nothing Phone (3a) Pro 5G, refer to the following common solutions:

- **Device Not Responding:** Press and hold the Power button for approximately 10-15 seconds to force a restart.
- **Battery Draining Quickly:** Review battery usage in Settings to identify apps consuming excessive power. Reduce screen brightness or enable power-saving mode.
- **Connectivity Issues (Wi-Fi/Cellular):** Toggle Wi-Fi or cellular data off and on. Restart your device. Ensure SIM card is properly inserted.
- **Camera Malfunction:** Clear the cache and data of the Camera app (Settings > Apps > Camera > Storage). Restart the phone.
- **Performance Lag:** Close unnecessary background applications. Clear temporary files and cache. Ensure sufficient storage space is available.

For persistent issues, consider performing a factory reset (backup your data first) or contacting customer support.

6. SPECIFICATIONS

Feature	Specification
Brand	Nothing
Model	Phone (3a) Pro 5G
Operating System	Android 15
RAM	8 GB
Storage Capacity	256 GB

Feature	Specification
Processor	Snapdragon chipset 7s Gen3 Processor (1.8, 2.4, 2.5 GHz)
Display Size	17.2 cm (6.77 inch)
Display Type	Full HD+ Flexible AMOLED
Resolution	1080 x 2392 pixels
Refresh Rate	120 Hz
Rear Camera	50MP (Main) + 50MP (3X Periscope) + 8MP (Ultra-Wide)
Front Camera	50MP
Video Capture Resolution	3840 x 2160 pixels (4K)
Battery Capacity	5000 mAh
Average Battery Life	13.5 Hours
Talk Time	38 Hours
SIM Card Slot Count	Dual SIM (Nano)
Cellular Technology	2G, 3G, 4G, 5G
Biometric Security	Fingerprint Recognition
Water Resistance Level	Water Resistant
Dimensions (LxWxH)	16.4 x 7.7 x 0.8 Centimeters

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Your Nothing Phone (3a) Pro 5G comes with a domestic warranty of **1 year for the handset** and **6 months for accessories** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

7.2 Customer Support

For technical assistance, service, or further inquiries, please visit the official Nothing support website or contact their customer service helpline. Refer to the packaging or the official Nothing website for up-to-date contact information.