

[Manuals.plus](#) /

› [vivo](#) /

› VIVO T4 5G Smartphone User Manual

vivo T4 5G

VIVO T4 5G Smartphone User Manual

Model: T4 5G

PRODUCT OVERVIEW

The VIVO T4 5G is a high-performance smartphone designed for seamless multitasking, advanced photography, and robust connectivity. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Figure 1: Rear view of the VIVO T4 5G smartphone.

1. SETUP GUIDE

1.1 Unboxing and Initial Inspection

Upon opening the package, verify that all components are present and undamaged. The box contents typically include:

- VIVO T4 5G Handset
- Quick Start Guide
- USB Cable (Type-C)
- 90W Charger
- SIM Eject Tool
- Phone Case
- Protective Film (pre-applied or separate)
- Warranty Card

1.2 SIM Card Installation

1. Locate the SIM card tray on the side of your VIVO T4 5G.
2. Insert the SIM eject tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) into the designated slots on the tray. Ensure the gold contacts face downwards. The device supports Dual SIM functionality.

4. Carefully reinsert the tray into the phone until it clicks into place.

1.3 Initial Charging and Power On

1. Connect the 90W charger to the USB Type-C port at the bottom of the phone. Plug the charger into a power outlet.
2. Allow the phone to charge for a few minutes before powering it on.
3. Press and hold the Power button (located on the right side) until the VIVO logo appears on the screen.
4. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account login.



Figure 2: VIVO T4 5G showcasing its slim design and large battery capacity.

2. OPERATING INSTRUCTIONS

2.1 Basic Navigation and User Interface

The VIVO T4 5G runs on Android 15 with Funtouch OS 15, offering an intuitive user experience. Use gestures or navigation buttons to move between apps, access recent tasks, and return to the home screen.



Figure 3: Funtouch OS 15 interface.

2.2 Display Features

The device features a 6.77-inch AMOLED display with a 120Hz refresh rate and 2392x1080 resolution. Adjust display settings such as brightness, dark mode, and refresh rate in the 'Settings' menu under 'Display & Brightness'.

2.3 Camera Usage

The VIVO T4 5G is equipped with a versatile camera system:

- **Rear Camera:** 50MP Sony IMX882 AI Camera
- **Front Camera:** 32MP Wide-Angle Camera
- **Additional:** 2MP Bokeh Camera

Open the Camera app to access various modes like Photo, Portrait, Video, Night, and Pro. Tap on the screen to focus and press the shutter button to capture images or start recording videos.



Figure 4: Detailed view of the VIVO T4 5G camera system.

2.4 Performance and Gaming

Powered by the Snapdragon 7s Gen 3 processor and 12GB RAM, the VIVO T4 5G delivers smooth performance. For an enhanced gaming experience, activate the 'New Ultra Game Mode' through the settings or quick panel. This mode optimizes system resources for gaming.



Figure 5: Ultra Game Mode interface on the VIVO T4 5G.

2.5 Battery Management

The device features a 7300 mAh battery with 90W FlashCharge support. To optimize battery life, manage background app usage, reduce screen brightness, and enable power-saving modes when needed. The 90W FlashCharge allows for rapid recharging.



Figure 6: VIVO T4 5G battery and charging capabilities.

2.6 Security Features

Unlock your phone using the in-display fingerprint sensor or facial recognition. Set up these features in 'Settings' under 'Security & Privacy'.

2.7 Connectivity

The VIVO T4 5G supports 5G cellular technology, Wi-Fi, Bluetooth, and USB Type-C connectivity. Manage these connections through the quick settings panel or the 'Network & Internet' section in 'Settings'.

3. MAINTENANCE

3.1 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.

3.2 Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to 'Settings' > 'System' > 'System update' to check for available updates.

3.3 Storage Management

The VIVO T4 5G comes with 256GB of internal storage. To maintain performance, periodically clear unnecessary files, uninstall unused apps, and back up important data to cloud storage or an external device.

3.4 Battery Care

To prolong battery lifespan, avoid extreme temperatures, do not leave the phone fully charged or fully discharged for extended periods, and use the official 90W charger.

3.5 Durability

The VIVO T4 5G features MIL-STD-810H military-grade certification, indicating enhanced durability against drops and environmental factors. While robust, it is not indestructible. Avoid exposing the device to excessive force, water, or dust beyond its specified resistance levels.



Figure 7: VIVO T4 5G highlighting its military-grade durability.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your VIVO T4 5G.

4.1 Device Not Powering On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

4.2 Charging Issues

- Verify that the charger and USB cable are securely connected to both the phone and the power outlet.
- Try using a different power outlet.
- Inspect the charging port for any debris or damage.
- Use only the official VIVO 90W charger and cable for optimal charging.

4.3 Network Connectivity Problems

- **No Signal/Poor Signal:** Check if your SIM card is properly inserted. Try restarting the phone. Ensure you are

in an area with network coverage.

- **Wi-Fi Issues:** Restart your Wi-Fi router. Forget the network on your phone and reconnect.
- **Bluetooth Issues:** Ensure both devices are in pairing mode and within range. Clear Bluetooth cache if problems persist.

4.4 Camera Not Working

- Restart the Camera app.
- Clear the cache and data of the Camera app in 'Settings' > 'Apps'.
- Ensure no physical obstruction is blocking the camera lens.

4.5 Device Freezing/Unresponsive

- Force restart the device by pressing and holding the Power button for 10-15 seconds.
- If the issue persists, consider performing a factory reset **Note:** This will erase all data on your phone. Back up your data before proceeding).

5. SPECIFICATIONS

Feature	Specification
Brand	vivo
Model	T4 5G
Operating System	Android 15, Funtouch OS 15
RAM	12 GB
Storage	256 GB
Processor	Snapdragon 7s Gen 3 (1.8, 2.4, 2.5 GHz)
Display Size	6.77 Inches
Display Type	AMOLED
Display Resolution	2392x1080
Refresh Rate	120 Hz
Rear Camera	50 MP (Main), 2 MP (Bokeh)
Front Camera	32 MP
Battery Capacity	7300 Milliamp Hours
Charging	90W FlashCharge
Cellular Technology	5G
SIM Card Slot Count	Dual SIM (Nano)
Connector Type	USB Type C
Biometric Security	Fingerprint Recognition

Durability	Military-Grade (MIL-STD-810H)
Item Weight	190 Grams
Item Dimensions	16.4 x 7.5 x 0.8 Centimeters

6. WARRANTY INFORMATION

Your VIVO T4 5G comes with a manufacturer's warranty. Please refer to the Warranty Card included in your product packaging for detailed terms, conditions, and duration of the warranty. Keep your proof of purchase for warranty claims.

7. CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries, please contact VIVO customer support. You can find contact details on the official VIVO website or refer to the Quick Start Guide.

Manufacturer Contact Information:

Vivo Mobile India Private Limited
Plot No. 8, Sector 24, Yamuna Expressway Area,
Gautam Buddha Nagar, UP India-201310

You may also visit the official [vivo Store on Amazon](#) for more product information and support resources.