

[Manuals.plus](#) /

› [Nothing](#) /

› Nothing Phone (3) User Manual

Nothing A024

Nothing Phone (3) User Manual

Model: A024

INTRODUCTION TO NOTHING PHONE (3)

Welcome to the user manual for your new Nothing Phone (3). This guide provides essential information to help you set up, operate, and maintain your device. The Nothing Phone (3) is a 2025 5G unlocked smartphone, featuring a Snapdragon 8s Gen4 processor, advanced AI capabilities, a quad 50MP camera system, and an AMOLED display. It is designed to offer a unique and intuitive user experience with its distinctive Glyph Interface.



Image: Front and back view of the Nothing Phone (3), highlighting its unique transparent design and Glyph Interface on the rear, alongside the vibrant AMOLED display on the front.

GETTING STARTED: SETUP

What's in the Box

- Nothing Phone (3) device
- USB Cable
- Phone Case
- Stylus

Initial Setup

1. **Power On:** Press and hold the power button on the side of the device until the Nothing logo appears.
2. **Language and Region:** Follow the on-screen prompts to select your preferred language and region.
3. **Network Connection:** Connect to a Wi-Fi network or insert your SIM card to establish a mobile network connection. The Nothing Phone (3) supports Dual SIM functionality.
4. **Google Account:** Sign in with your Google account or create a new one to access Google services and the Play Store.
5. **Data Transfer:** If you are upgrading from another device, follow the instructions to transfer your data.
6. **Security Setup:** Set up your preferred security method, such as a PIN, pattern, password, or fingerprint unlock.

OPERATING YOUR NOTHING PHONE (3)

Display and Interaction

The Nothing Phone (3) features a 6.77-inch FHD+ 1.5K AMOLED flexible screen with 1.07 billion colors and a 120Hz adaptive refresh rate for smooth visuals. It offers up to 4500 nits peak brightness and a 1000Hz touch response rate.

Glyph Interface

The Glyph Interface on the rear of the phone uses smart animations to provide visual cues for notifications, tools, and games.

- **NFC Animation:** An animation illuminates when NFC is triggered for payments or data transfer.
- **Glyph Button:** Quick-tap to browse Glyph Toys (mini-experiences like Mirror, Spin the Bottle, Digital Clock, Rock, Paper, Scissors). Long-press to launch utilities or games.
- **Smarter Alerts:** Notifications are accompanied by unique light and sound patterns.

GLYPH MATRIX

A new way to communicate



Image: A detailed view of the Glyph Matrix on the back of the Nothing Phone (3), illustrating its illuminated patterns.

Essential Key and AI-Powered Organization

The Essential Key is a new button on the side of your device designed for quick access to key functions and AI features.

- **Single Press:** Capture your screen.
- **Long Press:** Record voice notes and ideas.
- **Double Press:** Access Essential Space.

Essential Space: This feature organizes your captures, generates suggestions, and helps you manage important information.

Essential Search: Swipe up from the bottom of your screen to access Essential Search, allowing you to quickly find contacts, content, and real-time answers to questions.

Camera System

The Nothing Phone (3) is equipped with a revolutionary quad 50MP camera system, including a Main Camera, Periscope Camera, Ultra-wide Camera, and a Front Camera.

- **Main Camera:** 50MP with Optical Image Stabilization (OIS).
- **Periscope Camera:** 50MP with OIS, for enhanced zoom capabilities.
- **Ultra-wide Camera:** 50MP for expansive shots.
- **Front Camera:** 50MP for high-resolution selfies and video calls.

Supported features include Ultra XDR 4K video, Auto Tone, Portrait Optimizer, Motion Capture Mode, and Night Mode. The TrueLens Engine 4 enhances photos and videos with advanced computational algorithms and AI processing.




Image: An illustration detailing the 50MP 3-camera system, TrueLens Engine 4, 50MP Front Camera, and Action Mode capabilities of the Nothing Phone (3).

Battery and Charging

The device features a 5150mAh battery. It supports 65W wired fast charging, capable of reaching 50% charge in under 19 minutes. Wireless charging at 15W is also supported, along with 5W reverse wireless charging to power accessories like Nothing Ear.

NOTHING OS 3.5 (Powered by Android 15)

Experience an intuitive and customizable operating system.

- **Customization:** Personalize quick settings, home screen, and lock screen with custom shortcuts and widgets.
- **Smart Drawer:** Automatically sorts apps by category, placing frequently used apps at the top for quick access.

CARE AND MAINTENANCE

Cleaning Your Device

To clean your Nothing Phone (3), use a soft, lint-free cloth. Avoid using abrasive materials, solvents, or aerosol sprays. For stubborn marks, slightly dampen the cloth with water. Ensure all ports are dry before charging.

Protection

The Nothing Phone (3) features Corning Gorilla Glass on both the front and back for enhanced durability. It is also IP68-rated for dust and water resistance, providing protection against splashes and submersion in shallow water. Despite these features, avoid exposing the phone to excessive moisture or extreme temperatures. The included phone case offers additional protection.

TROUBLESHOOTING COMMON ISSUES

Issue	Possible Solution
Device not powering on	Ensure the battery is charged. Connect the phone to its charger for at least 30 minutes. If it still doesn't power on, perform a force restart by holding the power button and volume down button simultaneously for 10-15 seconds.
Apps crashing or freezing	Close and reopen the app. Clear the app's cache and data in Settings > Apps. Ensure the app and your phone's OS are updated to the latest versions. If the issue persists, uninstall and reinstall the app.
Poor battery life	Check battery usage in Settings > Battery to identify power-hungry apps. Reduce screen brightness, disable unnecessary features like Bluetooth/GPS when not in use, and enable battery saver mode. Limit background app refresh.

Issue	Possible Solution
Network connectivity issues (Wi-Fi/Cellular)	Toggle Wi-Fi/Cellular data off and on. Restart your phone. For Wi-Fi, forget the network and reconnect. For cellular, ensure your SIM card is properly inserted and your plan is active. Reset network settings in Settings > System > Reset options.
Glyph Interface not responding	Ensure the Glyph Interface is enabled in settings. Restart the device. Check for any system updates that might resolve software glitches.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Name	Phone 3 (Item model number: A024)
Operating System	Android 15 (NOTHING OS 3.5)
Processor	Snapdragon 8s Gen 4 (4nm technology, 3.2GHz CPU)
Memory (RAM)	12 GB (LPDDR5X)
Storage (ROM)	256 GB (UFS 4.0)
Display	6.77 Inches FHD+ 1.5K AMOLED Flex Screen, 1260x2800 Resolution, 120Hz Refresh Rate, 4500 nits peak brightness, 460 PPI
Rear Camera System	Quad 50MP (Main with OIS, Periscope with OIS, Ultra-wide)
Front Camera	50MP
Battery Capacity	5150mAh
Charging	65W Wired Fast Charging, 15W Wireless Charging, 5W Reverse Wireless Charging
Connectivity	5G, Bluetooth, NFC, USB, Wi-Fi, Built-In GPS
SIM Support	Dual SIM
Durability	IP68 Dust & Water Resistant, Corning Gorilla Glass (Front & Back)
Dimensions	7.29 x 7.25 x 0.95 inches (Package)

Feature	Detail
Weight	1.09 pounds (Item)
Color	Black
First Available	July 4, 2025

WARRANTY AND SUPPORT

Warranty Information

Your Nothing Phone (3) is covered by a standard return policy, typically allowing for refund or replacement within 30 days of purchase when sold by Amazon. For specific warranty details and duration, please refer to the documentation included with your purchase or visit the official Nothing support website.

Protection Plans

Extended protection plans may be available for your device, such as a 2-Year Protection Plan or a Complete Protect plan. These plans offer additional coverage beyond the standard warranty. Please check with your retailer for availability and terms.

Customer Support

For further assistance, technical support, or service inquiries, please visit the official Nothing support website or contact their customer service.

Official Nothing Store: [Visit the Nothing Store on Amazon](#)

Transparency Verification: Each item has a unique code that is verified before shipping, ensuring product authenticity.

