

[Manuals.plus](#) /

› [Nothing](#) /

› Nothing Phone (4a) 5G User Manual

Nothing Nothing Phone (4a)

Nothing Phone (4a) 5G User Manual

Model: Nothing Phone (4a)

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Nothing Phone (4a) 5G. Please read it carefully to ensure optimal performance and longevity of your device.



Image: Rear view of the Nothing Phone (4a) 5G in blue, showcasing its design.

PACKAGE CONTENTS

Upon unboxing, verify that all items are present:

- Nothing Phone (4a) 5G
- USB Type-C Cable
- SIM Ejector Tool
- Quick Start Guide (may vary by region)



Image: Contents of the Nothing Phone (4a) 5G retail box, including the phone, cable, and documentation.

SETUP

1. Insert SIM Card

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. This device supports Dual SIM.
4. Carefully reinsert the tray into the phone.

2. Charge the Device

- Connect the USB Type-C cable to the phone's charging port.
- Connect the other end of the cable to a compatible power adapter (sold separately) and plug it into a power outlet.
- Allow the phone to charge until the battery indicator shows a sufficient charge, or fully charged.

3. Power On and Initial Setup

- Press and hold the Power button until the Nothing logo appears.
- Follow the on-screen instructions to select your language, connect to Wi-Fi, and set up your Google account.
- Configure security features such as Fingerprint & Face Unlock during the setup process.

OPERATING YOUR DEVICE

Display and Navigation

The Nothing Phone (4a) features a 6.78" FHD+ AMOLED Display with vibrant colors and deep contrast. Navigate using touch gestures.

Camera Usage

Your device is equipped with a versatile camera system:

- **Rear Cameras:** 50MP Main, 50MP Telephoto, and 8MP Ultra-wide.
- **Front Camera:** 32MP for selfies and video calls.

Open the Camera app to access various shooting modes, including High Dynamic Range (HDR).




Image: Overview of the phone's camera system, Snapdragon processor, AMOLED display, and Nothing OS interface.

Performance and Storage

Powered by the Snapdragon 7s Gen 4 Processor, the phone offers smooth performance. With 12GB RAM and 256GB internal storage, you have ample space for applications and media.

Connectivity

The Nothing Phone (4a) supports 5G connectivity for fast internet speeds. It also includes GPS for navigation.

Security Features

Utilize Fingerprint & Face Unlock for secure and convenient access to your device.

Designed in London. Made in India.

High grade tempered
glass front and back



Essential Space

Your second memory, helps you
organise thoughts and
inspirations while staying on
track with daily tasks.

AI powered

Built-in Google Gemini
ChatGPT integration
Essential AI

Built to last

68 quality control protocols and over
95,000+ tests

32 MP Front Camera

The super-wide front camera is designed
to capture larger groups with a wider
field of view.*



Image: Details on the phone's AI capabilities, 32MP front camera, design origin, and durability testing.

MAINTENANCE

Battery Care

- The device features a 5400mAh battery. For optimal battery life, avoid extreme temperatures.
- Use the provided USB Type-C cable and a compatible fast charger for efficient charging.
- Avoid completely draining the battery frequently.

Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials.
- Do not expose the phone to excessive moisture.

TROUBLESHOOTING

Issue	Possible Solution
Device not powering on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds to force restart.
Apps crashing or freezing	Close and reopen the app. Clear the app's cache. Restart the phone.
Poor network connectivity	Check SIM card insertion. Toggle Airplane Mode on/off. Restart the phone. Contact your service provider.
Fingerprint scanner not working	Ensure your finger is clean and dry. Re-register your fingerprint in settings.

For more complex issues, refer to the official Nothing support website or contact customer service.

SPECIFICATIONS

Feature	Detail
Model	Nothing Phone (4a)
Operating System	Android
Processor	Snapdragon 7s Gen 4 (2.5 GHz)
RAM	12 GB
Storage	256 GB
Display	6.78" FHD+ AMOLED, 2392 × 1080 Pixels, 4500 Nits Peak Brightness
Rear Camera	50MP + 50MP + 8MP Triple Camera
Front Camera	32MP
Battery Capacity	5400 mAh
Connectivity	5G, LTE, GPS
Biometric Security	Fingerprint & Face Unlock
Dimensions	16.4 x 7.6 x 0.8 Centimeters
Weight	190 Grams

WARRANTY INFORMATION

The Nothing Phone (4a) 5G comes with a **1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in your package or visit the official Nothing website.

SUPPORT

For technical assistance, service, or general inquiries, please contact Nothing Support:

- **Toll-free number:** 18002021232
- **Email:** support.india@nothing.tech
- **Manufacturer:** SMARTBEE
- **Packer Contact Information:** Nothing Technology India Pvt. Ltd., Bengaluru, Karnataka, India

Additional support resources, including FAQs and service center locations, can be found on the official Nothing website.

Nothing Support

Toll-free number: 18002021232 | Email: support.india@nothing.tech

📍 350+

SERVICE CENTRES,
INCLUDING NOTHING
EXCLUSIVE CENTRES

🔄 360°

CUSTOMER SUPPORT
OVER MULTIPLE
CHANNELS

👤 95%

CUSTOMER
SATISFACTION

★ 4.8+

GOOGLE RATING FOR
ALL EXCLUSIVE
SERVICE CENTRES

📍 18K+

PIN CODES COVERED
UNDER PICK UP AND
DROP SERVICES

📁 98%

CASES CLOSED ON
THE SAME DAY

Image: Information on Nothing's customer support, including contact details and service network statistics.



