
[Manuals.plus](#) /

› [Xiaomi](#) /

› Xiaomi Pocket Power Bank Pro 10000mAh 33W User Manual

Xiaomi PB1030IN

Xiaomi Pocket Power Bank Pro 10000mAh 33W User Manual

Model: PB1030IN

INTRODUCTION

Thank you for choosing the Xiaomi Pocket Power Bank Pro 10000mAh 33W. This compact and powerful device is designed to provide reliable and fast charging for your electronic devices on the go. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your power bank.



Image: The Xiaomi Pocket Power Bank Pro, a compact black device, is shown held comfortably in a hand, highlighting its portable design.

WHAT'S IN THE BOX

- Xiaomi Pocket Power Bank Pro 10000mAh 33W
- Charging Cable (Type-C)
- User Manual

PRODUCT OVERVIEW

The Xiaomi Pocket Power Bank Pro features a sleek, compact design with multiple ports for versatile charging. It includes a built-in USB Type-C cable for convenience.

Pocket-friendly
Design



Two-way
Fast Charge



Triple Device
Charging



Low Power
Discharge Mode



12-layer
Safety Protection



33W
Sonic Charge

Image: A front view of the Xiaomi Pocket Power Bank Pro, showcasing its textured black finish and minimalist design.

Key Features:

- **33W Fast Charging:** Supports up to 33W two-way fast charging via the Type-C port.
- **Dual Output:** Includes a USB-A port and a Type-C port to charge two devices simultaneously.
- **10000mAh High-Capacity Battery:** Provides efficient power delivery for multiple charges.
- **Built-in USB Type-C Cable:** Integrated cable for convenience.
- **Pocket-Friendly Design:** Lightweight and compact with a premium matte finish.
- **Smart Protection:** Equipped with 12-layer advanced circuit protection.

Top selling Powerbanks on **amazon.in***



*As per Amazon bestseller rankings available at
<https://www.amazon.in/gp/bestsellers/electronics/4612025031/>

Image: A visual summary of the power bank's features, including pocket-friendly design, two-way fast charge, triple device charging, low power discharge mode, 12-layer safety protection, and 33W sonic charge.

SETUP

Initial Charging:

1. Before first use, fully charge your Xiaomi Pocket Power Bank Pro.
2. Connect the power bank to a compatible wall charger (not included) using the built-in Type-C cable or an external Type-C cable.
3. The indicator lights will illuminate to show charging progress. All lights will be solid when fully charged.

OPERATING INSTRUCTIONS

Charging Devices:

The power bank supports charging via its built-in Type-C cable, the external Type-C port, and the USB-A port.

1. Connect your device to the power bank using the appropriate cable (built-in Type-C, external Type-C, or USB-A).
2. The power bank will automatically begin charging your device.
3. You can charge up to three devices simultaneously using all available ports.



Image: The Xiaomi Pocket Power Bank Pro is shown simultaneously charging three different mobile devices, demonstrating its triple output capability.


Low Power Discharge Mode:

This mode is ideal for charging low-current devices such as Bluetooth earbuds, smartwatches, or fitness bands.

1. Double-tap the power button on the power bank to activate low power discharge mode.
2. Connect your low-current device.
3. The power bank will provide a stable, low-current output to safely charge your device.

Low Power Discharge Mode

Charge your low power devices with safety.



Double-tap
to enable

Image: A close-up view of the Xiaomi Pocket Power Bank Pro's ports, highlighting the power button which can be double-tapped to enable low power discharge mode.

MAINTENANCE

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- If the power bank will not be used for an extended period, charge it to approximately 50% every three months to preserve battery health.

TROUBLESHOOTING

Power Bank Not Charging:

- Ensure the charging cable is securely connected to both the power bank and the wall adapter.
- Verify that the wall adapter is functioning correctly and plugged into a live power outlet.
- Try a different charging cable or wall adapter.

Device Not Charging from Power Bank:

- Check if the power bank has sufficient charge.
- Ensure the cable connecting your device to the power bank is fully inserted and not damaged.
- Try a different charging cable.
- If charging a low-current device, ensure Low Power Discharge Mode is activated.
- Restart the power bank by disconnecting and reconnecting the device.

Slow Charging:

- Ensure you are using a fast-charging compatible cable and wall adapter for charging the power bank itself.
- For device charging, ensure your device supports fast charging and you are using a compatible cable.
- Charging multiple devices simultaneously may reduce individual charging speeds.

SPECIFICATIONS

Feature	Detail
Model Number	PB1030IN
Battery Capacity	10000 Milliamp Hours
Charging Power	33W Fast Charging (Two-way)
Output Ports	USB Type A, USB Type C (Triple Output)
Input Ports	USB Type C
Special Features	Short Circuit Protection, Compatible with All Smartphones
Item Weight	199 g
Dimensions	13.2 x 8.4 x 3.4 cm
Country of Origin	India

SAFETY INFORMATION

The Xiaomi Pocket Power Bank Pro is equipped with 12-layer advanced circuit protection to ensure safe operation. However, please observe the following safety guidelines:

12-layers Security Protection

Tested for Indian Standards



Temperature protection



Short circuit protection



Reset protection



Input overvoltage protection



Input overcurrent protection



Output overcurrent protection



Output overvoltage protection



Overcharge and over-discharge protection



Hardware-level overvoltage short circuit protection



Metal foreign object detection



Electrostatic Protection



Chip Thermal Shutdown

Image: Icons representing the 12-layers of security protection, including temperature, short circuit, reset, input overvoltage, input overcurrent, output overcurrent, output overvoltage, overcharge and over-discharge, hardware-level overvoltage short circuit, metal foreign object detection, electrostatic, and chip thermal shutdown protection.

- Do not disassemble, crush, puncture, or short-circuit the power bank.
- Do not expose the power bank to high temperatures (above 60°C / 140°F) or fire.
- Do not expose the power bank to water or other liquids.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of it with household waste.

WARRANTY AND SUPPORT

Your Xiaomi Pocket Power Bank Pro comes with a standard manufacturer's warranty. Please refer to the warranty card included in the packaging for specific terms and conditions.

Customer Support:

For any assistance, technical support, or service inquiries, please contact Xiaomi Customer Care:

Helpline Number: 1800 103 6286

Email: Service.in@xiaomi.com

Operating Hours: 9 AM to 9 PM (IST)

You can also visit an authorized Xiaomi Service Centre for resolution. For more information on service centers, please visit the official Xiaomi India website.