

[Manuals.plus](#) /

› [URBN](#) /

› URBN 10000 mAh Stand Pro MagSafe Power Bank UPR119 User Manual

URBN UPR119

URBN 10000 mAh Stand Pro MagSafe Power Bank UPR119 User Manual

Model: UPR119

1. INTRODUCTION

Thank you for choosing the URBN 10000 mAh Stand Pro MagSafe Power Bank. This device is designed to provide portable and efficient charging for your mobile devices, featuring both wireless and wired charging capabilities, a strong magnetic hold, and a convenient foldable stand. Please read this manual carefully to ensure proper use and to maximize the lifespan of your power bank.

2. PRODUCT OVERVIEW

The URBN Stand Pro MagSafe Power Bank combines a high-capacity battery with versatile charging options and a practical design.

Key Features:

- **10,000 mAh Capacity:** Provides multiple charges for most smartphones.
- **15W Fast Wireless Charging:** Efficient MagSafe-compatible wireless power delivery.
- **20W Wired Charging:** Fast charging via Type-C port.
- **Foldable Metallic Stand:** Integrated stand for hands-free viewing during charging.
- **Strong Magnetic Hold:** Ensures secure attachment to MagSafe-compatible devices.
- **Type-C Input/Output:** Universal connectivity for charging and recharging.
- **Pass-Through Charging:** Charge your device while recharging the power bank simultaneously.
- **Smart LED Display:** Indicates battery percentage and charging status.
- **MagTag Ring Included:** For enhanced grip and compatibility.

Package Contents:

- URBN 10000 mAh Stand Pro MagSafe Power Bank
- USB Type-C Charging Cable
- MagTag Ring
- User Manual

Product Diagram:



Figure 2.1: Front view of the URBN Stand Pro Power Bank showing the MagSafe charging area and LED display.

Elevated Design, Unmatched Power

The 10,000mAh StandPro MagTag Power Bank offers a perfect blend of style and function, featuring a sleek aluminium stand, fast wireless charging, and superfast wired power on the go.

Mag-safe
Compatible

 MagTag Ring Included



Figure 2.2: The power bank with its foldable metallic stand extended, highlighting wireless and wired charging capabilities.

3. SETUP

3.1 Initial Charging of the Power Bank

1. Connect the provided USB Type-C cable to the power bank's Type-C port.
2. Connect the other end of the cable to a compatible USB wall adapter (not included).
3. The LED display will show the charging progress. Allow approximately 6 hours for a full charge.
4. The LED display will show "100%" when fully charged.

3.2 Attaching the MagTag Ring (Optional)

For non-MagSafe compatible phones or cases, the included MagTag Ring can be applied to enable magnetic attachment.

1. Clean the back surface of your phone or phone case thoroughly.
2. Carefully peel off the adhesive backing from the MagTag Ring.
3. Align the MagTag Ring centrally on the back of your device or case. Ensure it does not obstruct the camera or other essential functions.
4. Press firmly for a few seconds to secure the ring.




Figure 3.1: The MagTag Ring can be used to enable magnetic compatibility for various devices.

4. OPERATING INSTRUCTIONS

4.1 Wireless Charging

1. Ensure your power bank is sufficiently charged.
2. Align your MagSafe-compatible device (or a device with an attached MagTag Ring) with the magnetic charging area on the power bank.
3. The strong magnetic hold will secure your device, and wireless charging will begin automatically. The LED display will show a charging indicator.




Figure 4.1: Magnetic connection for secure wireless charging in portrait or landscape orientation.

4.2 Wired Charging

1. Connect your device's charging cable to the Type-C port on the power bank.
2. Connect the other end of the cable to your device.
3. Wired charging will begin automatically. The LED display will show a charging indicator.

4.3 Using the Foldable Metallic Stand

1. Gently pull out the metallic stand from the back of the power bank.
2. Adjust the stand to your desired viewing angle.
3. Place your wirelessly charging device onto the power bank, utilizing the stand for hands-free viewing.

Stand Tall, Power All

The StandPro MagTag features a sleek, premium design with a sturdy aluminium stand, combining fast wireless and wired charging in a slim, stylish profile that elevates form and function.



Aluminium Stand



Pass Through Charging



Figure 4.2: The power bank's stand supports your device for convenient viewing while charging.

4.4 Pass-Through Charging

The power bank supports pass-through charging, allowing you to charge your mobile device wirelessly or via cable while the power bank itself is being recharged.

1. Connect the power bank to a wall adapter for recharging (Section 3.1).
2. Attach your mobile device for wireless or wired charging (Sections 4.1 & 4.2).
3. Both devices will charge simultaneously.

4.5 LED Display

The integrated LED display shows the current battery percentage of the power bank and indicates when charging is active.

5. MAINTENANCE

5.1 Cleaning

- Disconnect the power bank from all devices and power sources before cleaning.
- Use a soft, dry, lint-free cloth to wipe the surface of the power bank.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

5.2 Storage

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in environments with high humidity.
- For long-term storage, charge the power bank to approximately 50-75% every three months to maintain

battery health.

5.3 Battery Care

- Avoid fully discharging the power bank frequently.
- Do not expose the power bank to water or other liquids.
- Do not attempt to disassemble, repair, or modify the power bank. This will void the warranty and may cause safety hazards.
- The power bank features multiple safety protections including Over Voltage Protection, Short Circuit Protection, Overcurrent Protection, Battery Temperature Protection, Overcharge Protection, and Chip Shutdown Thermal Protection.

6. TROUBLESHOOTING

6.1 Power Bank Not Charging

- Ensure the charging cable is securely connected to both the power bank and the wall adapter.
- Verify that the wall adapter is functioning correctly and the power outlet is active.
- Try using a different USB Type-C cable and wall adapter.

6.2 Device Not Charging Wirelessly

- Ensure your device is MagSafe compatible or has a MagTag Ring properly attached.
- Check that the device is correctly aligned with the magnetic charging area on the power bank.
- Remove any thick cases or metallic objects between the power bank and your device that might interfere with wireless charging.
- Ensure the power bank has sufficient charge.

6.3 Device Not Charging Via Cable

- Ensure the cable is securely connected to both the power bank and your device.
- Try using a different charging cable.
- Ensure the power bank has sufficient charge.

6.4 Slow Charging

- Ensure you are using a compatible fast-charging cable and wall adapter for optimal wired charging speeds.
- For wireless charging, ensure proper alignment and that no obstructions are present.
- Charging speed can be affected by the device's battery level and background activity.

7. SPECIFICATIONS

Feature	Detail
Model Name	Stand Pro
Model Number	UPR119
Brand	URBN

Feature	Detail
Battery Capacity	10000 mAh
Battery Cell Type	Lithium Polymer
Wireless Charging Output	Up to 15W
Wired Charging Output	Up to 20W (Type-C)
Connector Type	USB Type C (Input/Output)
Number of Ports	2 (1x Type-C, 1x Wireless)
Battery Charge Time	Approx. 6 Hours
Item Weight	250 Grams
Item Dimensions (L x W x Thickness)	9.5L x 6W x 3Th Centimeters
Special Features	Auto Shut-Off, Fast Charging, Pocket Size, Slim, Wireless Charging, Foldable Stand, Strong Magnetic Hold, Pass-Through Charging
Compatible Devices	Smartphones (MagSafe compatible or with MagTag Ring)
Country of Origin	India

8. WARRANTY INFORMATION

The URBN 10000 mAh Stand Pro MagSafe Power Bank (Model UPR119) comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures replacement for eligible issues. Please retain your purchase receipt as proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear. For detailed warranty terms and conditions, please refer to the official URBN website or contact customer support.

9. CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims regarding your URBN 10000 mAh Stand Pro MagSafe Power Bank, please contact our customer support team:

- **Manufacturer:** Veeflex Elektrikials Private Limited
- **Address:** Rajprabha Enclave, Building No. 6, Unit No. 209&210, 1st Floor, Bhoidapada, Sativali Road, Vasai (E) Pin code : - 401208
- **Website:** [Visit the URBN Store on Amazon](#) (for general inquiries and product information)

Please have your product model number (UPR119) and proof of purchase ready when contacting support.



