STORM
VERGE



USER MANUAL

boAt

STORM VERGE

Thank you for choosing Storm Verge as your fitness transformation companion. Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail.

You may refer to these instructions for later use as well.




Package Contains:

- Storm Verge x1
- USB Magnetic Charging Cable x1
- User Manual and Warranty QR Card x1
- 6 Stickers

CHARGING THE WATCH


Charge the smartwatch before initial use. The full charge takes about 1.5 hours.
- Use the provided USB magnetic charging cable and a 5V/2A adapter.
- Align the magnetic connector with the charging contacts on the back of the watch until it attaches securely.



TURNING THE WATCH ON/OFF

Press and hold the Power Button for 3–5 seconds to turn the watch on/off.
Swipe on the following options as displayed:

- **Slide to Restart:** Restarts the watch.
- **Slide to Power Off:** Turns the watch off.
- **Slide to Call (SOS):** Initiates an SOS call if set up in the app.



CONNECTING TO THE APP

1. DOWNLOAD THE CREST APP ON YOUR DEVICE

Use the QR code included in the package to download the boAt Crest App on your device. The app is available on both::

- App Store (for iOS 14.0 and above)
- Google Play Store (for Android 7.0 and above)

OR

- Scan the QR code of the app provided here to download the app.

2. PAIR YOUR SMARTWATCH WITH YOUR DEVICE

1. Open the Crest app on your device.
2. Ensure the phone's Bluetooth, Notifications and Location functionalities are turned on for best experience.
3. Search and select the Storm Verge on the app's home screen. It will also be available under the Storm series.
4. Select 'Pair with Bluetooth,' search for available devices, and choose the smartwatch named STORMVERGE_XXXX.
5. As the pairing process will begin, you will receive prompt confirming "Pairing Successful". A pop-up may appear requesting access to your contacts and call logs. Tap "Authorize" for a seamless experience.

GET IT ON Google Play Download on the App Store

Note: Ensure connectivity throughout your journey, make sure the app is allowed to always run in the background of your phone.


SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

• Open the app on your phone.
• Make sure your Storm Verge is connected to the app.
• Synchronization will start automatically once you enter the app interface.

NAVIGATING THROUGH THE FUNCTIONS

CROWN/POWER BUTTON FUNCTIONALITY



1. Short Press:

• Silent Incoming Calls: Short press the side button to silence the incoming calls.
• Main Menu: Short press the power button once to open the main menu.
• Back Navigation: Go back to previous screen by short pressing once. Keep pressing to reach the home screen.

2. Long Press:

• Power off, Restart and SOS: Long press the side button to select between power off, restart and initiate the SOS call on your smartwatch.

3. Rotate:

• Switch Default Watch Faces: Switch between the 5 default watch faces from the home screen.
• Scroll Main menu: Scroll through the main menu.

MAIN MENU

Access the core features of the smartwatch through the main menu. Open the main menu by short pressing the side button (crown). Rotate the same to scroll through the main menu.

Workout



Smartwatch offers multiple workout modes to help you track your workouts. You can choose from a variety of modes, including: Walking, Outdoor Running, Cycling, Jump rope, Badminton, Table Tennis, Tennis, Mountaineering, Basketball, Football, Baseball, Volleyball, Cricket, Rugby, Hockey, Dance, Yoga, Spinning Bike, and more.

Note: The activity will not be recorded if the total duration is less than 3 minutes.

Sleep




Storm Verge automatically detects your sleep when worn at night. Sleep tracking records are available on the watch and on the boAt Crest app.
Once the asleep criteria are met, your smartwatch will start recording from 8 pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes; it will start recording and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria are met. The sleep statistics include:

- Sleep Time
- Deep Sleep
- Light Sleep
- REM Sleep
- Awake Periods

Set Sleep Goals on Crest App: Sleep goals can be configured through the boAt Crest app. To set the sleep goals, go to Restore > Edit Sleep Goals, set Bedtime and Wake Time, and save the schedule. Once the schedule is set, the watch will monitor sleep.

Note: For accurate sleep data recording, the asleep criteria have to be met, which include limited movement, wrist positions and angles, and more. The awake criteria will be met only after it records some noticeable movement.

Activity



Open activity to view your daily step count, along with calories burned and distance covered.

Note: Sync your smartwatch with the app to access detailed activity records.

Heart Rate



Wear the smartwatch on your wrist, then click on the icon to start the heart rate measurements. You can use this feature to monitor your:

- Current Beats Per Minute (BPM)
- Max HR
- Min HR

Sync your smartwatch with its Crest app on your smartphone for deeper insights, trends, and historical data.

Note: Measurements are for reference only and not for medical purposes.

SpO2



SpO2 measures how much oxygen your blood is carrying as a percentage of the maximum it could carry. Wear the watch on your wrist, then click on the SpO2 icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.

Notifications



Check calls, SMS, and app notifications directly on your smartwatch. Steps to enable notifications using Crest app:

- Open Crest app.
- Go to “Settings” from the main menu and tap on “Watch Features”.
- Select the "Notification" feature.
- Turn on notifications for calls, SMS, and the apps of your choice.
- Click on “Save Changes” to apply the settings.

Call

• Contacts: Add maximum 70 contacts from the boAt Crest app.
• Call Logs: Find recently received, missed, and outgoing call logs in the Call Logs of the watch.
• Keypad: Use the dial pad to dial any phone number for Bluetooth calling.



Music

Go to the music control option to control music from your phone. During music playback, you can control play, pause, next track, previous track, volume up and down from the watch.

Note: Some apps with different protocols might not work.



Weather

Stay updated with daily and weekly weather updates directly on your smartwatch by connecting it to the boAt Crest app. Steps to set up the weather updates:
• Open the Crest App.
• Go to 'Settings' from the main menu and tap on 'Watch Features'.
• Toggle on the 'Weather Tracking' option. Also, grant 'Location' permissions as 'Allow all the time' in your phone settings.
• Also, select your preferred unit of measurement for weather (°C/°F).

Note: Your smartwatch will automatically refresh weather updates, keeping you informed throughout the day.



Breathing Exercise

Go to "Breathing Exercise" from the menu to start a guided session. Set the duration and select the breathing pace: slow, medium or fast, as per your preference. The watch will then guide your inhale-exhale rhythm to help you achieve a relaxed state.



Alarm

Open the “Alarm” option from the menu to set alarms directly on your smartwatch.



Timer

Access the “Timer” option from the main menu to set a countdown. Preset durations include 1 min, 2 min, 3 min, 5 min, 10 min, and 30 min. A custom duration can also be configured.

Note: The timer continues to run in the background even when screens are switched.



Stopwatch

Access the “Stopwatch” option from the main menu to measure elapsed time. Functions include start, pause, resume, and lap record. Select the lap record option to mark lap times while the total stopwatch time continues running. Short press the power button (crown) to start or pause the stopwatch.



Calendar

Access the Calendar option from the main menu to view the current date and monthly calendar.



Remote Shutter

Open the Crest app to use the remote shutter option. Tap on the remote shutter icon on your smartwatch to click a photo from your phone.


Note: Make sure to open the Crest app on your device to use this feature.



Voice Assistant

The Voice Assistant feature offers hands-free functionality by enabling you to interact with voice assistants. Tap on this to enable the voice assistant feature and give the command from the watch.

Note: Make sure the watch is connected to the Crest app.



Find Phone


Tap on the Find Phone icon to locate your paired device. Press ‘Start’ to activate the feature. Once activated, your device will start ringing. Short press the side button on the watch to stop the alert.

Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.



Settings

Open watch settings from here.



Calculator

Access the Calculator option from the main menu to perform basic arithmetic operations directly on the smartwatch.



SETTINGS

Change Watch Face

You can choose from 5 default watch faces here.



Brightness


Tap on this to adjust the brightness of the smartwatch.



Screen Sleep


The Screen Sleep duration can be customized. Options range from 5 seconds to 1 minute of screen-on time, along with an Always On setting.

Note: Longer screen durations may lead to increased battery consumption.



Raise to Wake


Enable raise to wake gesture to automatically light up the smartwatch screen when you lift your wrist.



Do Not Disturb


Avoid unwanted interruptions by enabling Do Not Disturb mode on your smartwatch. Select from All Day or Schedule options to activate DND as per your preferred duration.

Note: Once enabled, raise to wake gesture, notifications and reminders will not work.



Sound

The sound control provides options to switch between media volume and silent mode.



Themes

Select the preferred menu layout style for the watch. Options may include List, Grid, Honeycomb, Sphere, Chessboard, Halo, Round Sky and Square Earth, Grid, and Waterfall layouts.



Select Language

Choose your preferred language for the watch.

About

Displays device information including model number, device name, version, mac address information.




QR Code

Provides a QR code for downloading the Crest app.




Restart

Restarts the smartwatch to refresh its operation



Power Off


Turns off the smartwatch. Press and hold the power button to turn it back on.



Reset

Restores the smartwatch to factory settings.

Note: All data and customizations will be erased.



SWIPE RIGHT TO ACCESS WIDGETS

Swipe right from the home screen to access features like Activity, SpO2, Heart Rate, Sleep, Weather, Music, Workout and Call.



SWIPE LEFT TO ACCESS NOTIFICATIONS

Swipe left from the home screen to access all notifications.



SWIPE UP TO ACCESS THE SMART CARDS

Swipe up from the home screen to access smart cards for activity, sleep, music, timer, stopwatch, common applications, and recent applications. Smart cards offer quick info without opening the full menus.




SWIPE DOWN FOR THE SHORTCUT MENU

Swipe down on the home screen to open the Shortcut Menu to access essential functions such as Bluetooth Calling, Wake Gesture, Themes, Do Not Disturb (DND), Flashlight, Brightness controls, Silent Mode, Find My Phone, and Settings.



EMERGENCY SOS WITH POWER BUTTON


The Emergency SOS feature helps you instantly alert your emergency contact during a critical situation.



To activate Emergency SOS from your watch:

- Press and hold the Power Button for 5 seconds.
- Slide to SOS Call to your registered emergency contact.

To set up an emergency SOS contact on the Crest App:



- Open the boAt Crest App on your device.
- Go to Settings > Watch Features > Emergency SOS settings.
- Tap on 'Add Emergency Contact' and from the synced phonebook list select the contact.
- Once added, users can notify the selected contact that they have been added as an emergency contact.
- Finally, to initiate an SOS call: Press and hold the power button on your smartwatch for 5 seconds.

Note:
Only one emergency contact can be registered in the boAt Crest app. The smartwatch must remain connected to the Crest app with Bluetooth and calling enabled. The registered emergency contact is updated within the app.

PRODUCT PARAMETERS

Model	Storm Verge
Screen Size	1.72″ (4.37 cm)
Screen Type	HD Display
Battery Capacity	230 mAh
Net Weight	20 gm
Bluetooth Version	Bluetooth 5.3
Charging time	1.5 Hours
Working time	5 Days* (Battery life may vary depending on usage)
Water Resistance	IP68

Maintenance

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.
Do not wash the strap with a household cleanser. Please use soap-less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.
For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

Frequently Asked Questions (FAQs)

Search for the app to connect keeps failing.

1. Keep the boAt Crest app updated to the latest version.
2. Close all the programs on your device → Stop and restart Bluetooth and GPS → Connect again.
3. Check and enable the notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 7.0 and above and iOS 14.0 and above.

My watch is receiving no alerts, texts, or phone calls.

Make sure the notification centre of the connected device is displaying messages. Only then will your smartwatch also display those notifications. Also, ensure that the app is running in the background and the battery optimisation feature on the phone is disabled.

My Bluetooth keeps getting disconnected.

• Make sure there is not more than a 10m distance between the Bluetooth on the phone and the watch.
• There is no obstacle between the watch and the phone.
• Make sure the app is running in the background.

Which functions of Storm Verge need Bluetooth to work?

Bluetooth must be continuously enabled on both devices for these features to function reliably. Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, and Bluetooth calling require the proper Bluetooth connectivity to work.

Will it be okay to take a bath wearing Storm Verge?

The IP68 water resistance will only work under the following conditions:
(1) Maximum depth of water: 1.5 m
(2) Maximum time for exposure to water: 10 minutes
The watch isn't suitable for hot baths, hot springs, saunas, snorkelling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

SAFETY & PRODUCT INFORMATION

WEEE INFORMATION



This device and any electrical accessories are compliant with local applicable rules on the restriction of the use of certain hazardous substances in electrical and electronic equipment

Disclaimer:
Features may vary by product model. For detailed specifications, please refer to the product user guide. Due to ongoing improvements, specifications are subject to change without prior notice. We continuously enhance our products to ensure the highest quality.

Battery

• Do not disassemble, bore or damage the battery.
• Do not disassemble the built in batteries of non-replaceable battery devices.
• Do not use sharp objects to remove the battery.

Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We're not responsible for any deviation in data.
- Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Things to keep in mind

- Sync data everyday days to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer

This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.


AM
104
10340
AM
AM
104
10340
AM