

[Manuals.plus](#) /

› [Logitech](#) /

› Logitech Pebble Mouse 2 M350s Slim Bluetooth Wireless Mouse User Manual

Logitech M350s

Logitech Pebble Mouse 2 M350s User Manual

Model: M350s (910-007022) | Brand: Logitech

1. INTRODUCTION

The Logitech Pebble Mouse 2 M350s is a slim, portable Bluetooth wireless mouse designed for quiet operation and multi-device connectivity. It offers a minimalist design and customizable features to enhance your computing experience across various operating systems.

PEBBLE MOUSE 2 M350s

The Studio Series by Logitech



24M

Battery life¹
Autonomie¹

silent touch

Silent clicks
Clics silencieux

58%
RECYCLED
PLASTIC*



Multi-device
pairing
Couplage
multidispositif



logitech

Image: Logitech Pebble Mouse 2 M350s in Tonal White, highlighting its sleek design and model name.

Key Features:

- **Slim and Portable Design:** Lightweight and compact for easy transport.
- **Multi-Device Connectivity:** Connects to up to 3 wireless devices via Bluetooth, with easy switching.
- **Silent Touch Technology:** Reduces click noise by 90% for a quieter experience.
- **Customizable Middle Button:** Personalize shortcuts using the Logi Options+ app.
- **Long Battery Life:** Up to 2 years of battery life with auto-sleep power-saving mode.
- **Recycled Plastic Construction:** Plastic parts include a minimum of 58% certified post-consumer recycled plastic.

SLIM, SLEEK PORTABLE, AND MORE YOU.



Image: The Logitech Pebble Mouse 2 M350s positioned next to a keyboard, illustrating its slim, sleek, and portable design.

2. SETUP

2.1. Battery Installation

The Pebble Mouse 2 M350s requires one AA battery (included). To install or replace the battery:

1. Gently lift the top cover of the mouse. The cover is held by magnets.
2. Insert the AA battery into the compartment, ensuring correct polarity (+/-).
3. Replace the top cover, aligning it properly until it snaps into place magnetically.

IN THE BOX



Image: The Logitech Pebble Mouse 2 M350s with its top cover detached, revealing the internal battery compartment and an AA battery, illustrating what is included in the box.

2.2. Connecting Your Mouse

The Pebble Mouse 2 M350s supports Bluetooth connectivity and can pair with up to three devices. It also supports connection via a Logi Bolt USB receiver (not included).

Bluetooth Connection:

1. Turn on the mouse using the power switch located on the bottom.
2. Press and hold one of the Easy-Switch buttons (1, 2, or 3) on the bottom of the mouse until the LED light next to it starts blinking rapidly. This indicates pairing mode.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and select "Logitech Pebble 2 M350s" from the list of available devices.
4. Follow any on-screen prompts to complete the pairing process. The LED light on the mouse will turn solid for 5 seconds when connected.

Logi Bolt USB Receiver Connection (Optional):

1. If you have a Logi Bolt USB receiver, plug it into an available USB port on your computer.
2. The mouse should automatically connect to the receiver. If not, use the Logi Options+ app to establish the connection.

DEVICE-HOPPING MADE EASY



Image: A desk setup demonstrating the multi-device connectivity of the Logitech Pebble Mouse 2 M350s, showing it connected to a monitor and a tablet, enabling easy device switching.

3. OPERATING THE MOUSE

3.1. Basic Functions

- **Left Click:** Primary selection and activation.
- **Right Click:** Accesses context menus.
- **Scroll Wheel:** Scrolls vertically through documents and web pages.
- **Middle Button (Scroll Wheel Click):** Default action is often middle-click, but it is customizable.

MAKE A BIG IMPRESSION ON THE QUIET



WITH SILENT TOUCH TECHNOLOGY

Image: A hand demonstrating the use of the Logitech Pebble Mouse 2 M350s, emphasizing its Silent Touch Technology for quiet clicks.

3.2. Customizing the Middle Button

The middle button of your Pebble Mouse 2 M350s can be personalized to perform various shortcuts using the Logi Options+ app. This allows you to assign actions like sending emojis, shuffling music playlists, or performing system commands (e.g., show/hide desktop, screen capture).

1. Download and install the Logi Options+ app from the official Logitech website (www.logitech.com/optionsplus).
2. Open the Logi Options+ app and select your Pebble Mouse 2 M350s.
3. Navigate to the button customization settings.
4. Select the middle button and choose your desired shortcut or application-specific action.

CUSTOMIZABLE MIDDLE BUTTON



WITH LOGI OPTIONS+ APP^[2]

Image: A laptop screen showing the Logi Options+ app, illustrating how users can customize the middle button of the Logitech Pebble Mouse 2 M350s for various shortcuts.

3.3. Easy-Switch Between Devices

To switch between paired devices, simply press the Easy-Switch button (1, 2, or 3) on the bottom of the mouse corresponding to the device you wish to use. The mouse will instantly connect to the selected device.

4. MAINTENANCE

4.1. Battery Replacement

As mentioned in the setup section, the mouse uses one AA battery. When the battery is low, the LED indicator on the mouse may flash. Replace the battery by following the steps in Section 2.1.

4.2. Cleaning

To clean your mouse, use a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh

chemicals or abrasive materials, as these can damage the mouse's surface.

5. TROUBLESHOOTING

5.1. Connectivity Issues

- **Mouse not connecting:** Ensure the mouse is turned on and the battery has sufficient charge. Re-initiate pairing mode on the mouse and re-scan for Bluetooth devices on your computer.
- **Intermittent connection:** Move the mouse closer to your device. Ensure there are no large metal objects or other wireless devices causing interference.

5.2. Unresponsive Mouse

- **Cursor not moving:** Check the optical sensor on the bottom of the mouse for any obstructions. Ensure you are using the mouse on a suitable surface.
- **Buttons not responding:** Verify the battery is correctly installed and charged. If using Logi Options+ app, ensure no conflicting custom settings are applied.

6. SPECIFICATIONS

Feature	Detail
Model Number	910-007022
Connectivity	Bluetooth, USB (via Logi Bolt receiver, not included)
Movement Detection	Optical
Operating System Compatibility	Windows, macOS, iPadOS, Android, Chrome OS, Linux
Battery Type	1 x AA (included)
Estimated Battery Life	Up to 24 months (2 years)
Dimensions (LxWxH)	4.2 x 2.31 x 1.05 inches (106.7 x 58.7 x 26.62 mm)
Weight	2.68 ounces (76g including battery)
Color	Tonal White
Recycled Plastic Content	Minimum 58% certified post-consumer recycled plastic in plastic parts

DIMENSIONS



WEIGHT: 76G INCLUDING BATTERY

Image: A diagram illustrating the precise dimensions (length, width, height) and weight of the Logitech Pebble Mouse 2 M350s.



Image: An infographic detailing the broad operating system compatibility of the Logitech Pebble Mouse 2 M350s, including Windows, macOS, iPadOS, Android, and Chrome OS.

7. WARRANTY AND SUPPORT

7.1. Warranty Information

Logitech products typically come with a limited hardware warranty. For specific warranty terms and conditions applicable to your region and product, please refer to the official Logitech website or the warranty card included with your purchase.

7.2. Further Support

For detailed instructions, FAQs, and advanced troubleshooting, please refer to the official User Guide PDF or visit the Logitech support website:

- User Guide (PDF): [Download User Guide](#)
- Logitech Support: support.logi.com

