

Manuals.plus / > Logitech / > Logitech MX Keys S + MX Master 3S User Manual

Logitech MX Keys S + MX Master 3S

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Logitech MX Keys S + MX Master 3S User Manual

Performance Wireless Illuminated Keyboard and Mouse Combo

INTRODUCTION

Welcome to the user manual for your Logitech MX Keys S keyboard and MX Master 3S mouse combo. This powerful duo is engineered for speed, precision, and comfort, designed to enhance your productivity across multiple devices and operating systems. This manual provides essential information on setup, operation, maintenance, and troubleshooting to help you get the most out of your new devices.



Figure 1: Logitech MX Keys S Keyboard and MX Master 3S Mouse

Advertisements

The Logitech MX Keys S keyboard and MX Master 3S mouse, presented in a pale grey finish, showcasing their ergonomic design and compact form factor.

WHAT'S IN THE BOX

- Logitech MX Keys S Wireless Illuminated Keyboard
- Logitech MX Master 3S Wireless Mouse
- Logi Bolt USB Receiver
- USB-C Charging Cable (USB-A to USB-C)
- User Documentation

Advertisements



Figure 2: Package Contents

An illustration showing the Logitech MX Keys S keyboard, MX Master 3S mouse, and the included USB-C charging cable, representing the typical contents of the product package.

Advertisements

SETUP

1. Charging Your Devices

Before first use, it is recommended to fully charge both your MX Keys S keyboard and MX Master 3S mouse using the provided USB-C charging cable. Connect the USB-C end to the device and the USB-A end to a power source (e.g., computer USB port, USB wall adapter).

- The keyboard's charging port is located on the top edge.
- The mouse's charging port is located at the front.

2. Connecting Your Devices

Your MX Keys S and MX Master 3S can be connected via Bluetooth Low Energy or the included Logi Bolt USB receiver.

Advertisements

Using the Logi Bolt USB Receiver:

1. Plug the Logi Bolt USB receiver into an available USB port on your computer.
2. Turn on your keyboard and mouse. They should automatically connect to the receiver.

Using Bluetooth Low Energy:

1. Turn on your keyboard and mouse.
2. On the keyboard, press and hold one of the Easy-Switch keys (1, 2, or 3) until the LED indicator blinks rapidly.
3. On the mouse, press the Easy-Switch button on the bottom until the LED indicator blinks rapidly.
4. On your computer, go to Bluetooth settings and select "Logitech MX Keys S" or "Logitech MX Master 3S" from the list of available devices to pair.



Figure 3: MX Keys S Keyboard Features

Advertisements

A detailed diagram of the MX Keys S keyboard, highlighting programmable keys, Smart Keys layout, USB-C quick charging port, Easy-Switch buttons for multi-device pairing, smart illumination, and spherically dished keys.




Figure 4: MX Master 3S Mouse Features

An annotated view of the MX Master 3S mouse, pointing out its quiet clicks, MagSpeed scroll wheel, 8K DPI sensor for tracking on glass, programmable buttons, thumb wheel, Easy-Switch button, and 70-day battery life.

Advertisements

3. Installing Logi Options+ App

For full customization and advanced features, download and install the Logi Options+ app from the official Logitech website (www.logitech.com/optionsplus). This application allows you to:

- Customize keyboard function keys and mouse buttons.
- Adjust smart illumination settings.



Figure 5: Smart Actions in Logi Options+ App

Advertisements

A screenshot of the Logi Options+ application interface, demonstrating the Smart Actions feature where users can create shortcuts to automate multiple tasks with a single keystroke.

OPERATING INSTRUCTIONS

Keyboard Operation (MX Keys S)

- **Fluid Typing:** The spherically dished keys are designed for comfortable, precise, and quiet typing.
- **Smart Illumination:** Backlit keys automatically light up when your hands approach and adjust brightness based on ambient light. Customize duration and brightness in Logi Options+.
- **Programmable Keys:** Use the Logi Options+ app to assign custom functions to the F-keys and other programmable keys.
- **Easy-Switch:** Quickly switch between up to three connected devices by pressing the Easy-Switch keys (1, 2, or 3) on the keyboard.



Figure 6: Fluid Typing and Smart Backlighting

Advertisements

A close-up view of hands typing on the MX Keys S keyboard, demonstrating the comfortable key design and the intelligent backlighting feature that illuminates the keys for improved visibility.

Mouse Operation (MX Master 3S)

- **MagSpeed Scrolling:** Scroll 1000 lines per second with the electromagnetic MagSpeed scroll wheel. Switch between line-by-line precision and hyper-fast free spin modes.
- **8K DPI Sensor:** The 8K DPI optical sensor allows for precise tracking on virtually any surface, including glass (minimum 4mm thickness).

- **Easy-Switch:** Switch between up to three connected devices using the button on the bottom of the mouse.




Figure 7: MagSpeed Scrolling

Advertisements

A user's hand operating the MX Master 3S mouse, highlighting the MagSpeed scroll wheel designed for rapid and precise navigation through documents and web pages.



Works with macOS, iPadOS, iOS



Dual Connectivity



Figure 8: Tracking on Glass

The MX Master 3S mouse positioned on a glass surface, illustrating its advanced 8K DPI sensor's capability to track accurately on various challenging surfaces, including glass.

Advertisements

Multi-Device and Multi-OS Functionality (Logitech Flow)

With Logitech Flow (enabled via Logi Options+), you can seamlessly control multiple computers with a single MX Keys S and MX Master 3S combo. Move your cursor to the edge of one screen, and it automatically appears on the next, even across different operating systems (Windows, macOS, Linux, ChromeOS, iPadOS, iOS).



Figure 9: Logitech Flow in Action

Advertisements

A visual representation of the Logitech Flow feature, showing a file being seamlessly copied from one computer screen (macOS) and pasted onto another (Windows), illustrating the cross-device functionality.

MAINTENANCE

Cleaning

- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the surfaces of the keyboard and mouse.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.
- For the keyboard, use compressed air to remove debris from between the keys.

Battery Care

- To maximize battery life, avoid exposing the devices to extreme temperatures.
- Charge the devices when the battery indicator shows low power.
- The MX Master 3S mouse offers up to 70 days of power on a full charge, and the MX Keys S keyboard provides long-lasting battery life with smart illumination.

Advertisements

TROUBLESHOOTING

Connectivity Issues

- **Device not connecting:** Ensure both devices are turned on and fully charged. Check that the Logi Bolt receiver is

- **Re-pairing:** If connection is lost, try re-pairing the devices using the Easy-Switch buttons as described in the "Setup" section.

Keyboard Backlighting Not Working

- Ensure the keyboard is sufficiently charged. Low battery can disable backlighting.
- Check ambient light conditions. Smart illumination may turn off backlighting in bright environments.
- Adjust backlighting settings in the Logi Options+ app.

Mouse Tracking Issues

- Clean the mouse sensor on the bottom of the device.
- Ensure the surface you are using is not excessively reflective or uneven. While the mouse tracks on glass, extreme conditions may affect performance.
- Check DPI settings in the Logi Options+ app.

Advertisements

SPECIFICATIONS

Feature	Detail
Brand	Logitech
Model	MX Keys S + MX Master 3S
Color	Pale Grey
Connectivity Technology	Bluetooth Low Energy, Logi Bolt USB Receiver
Compatible Devices	Laptop, Personal Computer
Operating System Compatibility	Windows, Linux, macOS, iPadOS, iOS, ChromeOS
Power Source	Rechargeable (USB-C)
Mouse Sensor	8K DPI Darkfield (tracks on glass)
Mouse Scroll Wheel	MagSpeed Electromagnetic Scrolling
Keyboard Keys	Spherically dished, Smart Illumination
Recycled Plastic Content	MX Master 3S: 22%; MX Keys S: 11% (Pale Grey)

WARRANTY AND SUPPORT

Logitech products come with a limited hardware warranty. For detailed warranty information, product support, FAQs, and

You can also find additional resources and community forums to help with any questions or issues you may encounter.

Advertisements

© 2024 Logitech. All rights reserved.

Advertisements

Related Documents - MX Keys S + MX Master 3S

	Logitech MX Keys Advanced Wireless Keyboard Setup and Features Guide A comprehensive guide to setting up and using the Logitech MX Keys Advanced Wireless Illuminated Keyboard, covering quick setup, detailed setup, pairing, software installation, multi-OS compatibility, battery status, smart backlighting, and Logitech Flow.
	Logitech MX Anywhere 3 Mouse Setup and Features Guide Comprehensive guide to setting up and using the Logitech MX Anywhere 3 compact performance mouse, covering quick setup, detailed setup, connection methods, software features, gestures, and charging.
	Logitech MX Master 3S Getting Started Guide A comprehensive guide to setting up and using the Logitech MX Master 3S wireless mouse, covering detailed setup, pairing with multiple computers, button customization, gesture controls, and battery management.
	Logitech MX Master 3S Wireless Performance Mouse User Manual Learn how to set up, use, and customize your Logitech MX Master 3S wireless performance mouse with ultra-fast scrolling, 8K DPI sensor, and multi-device connectivity. This user manual provides detailed instructions on pairing, software installation, button customization, battery management, and cleaning, enhancing productivity across Windows, Linux, Chrome, and Mac

	Logitech Brio Stream Webcam & MX Master 3S Mouse User Manual Setup & Features Comprehensive user manual for Logitech Brio Stream 4K Webcam and MX Master 3S Wireless Performance Mouse. Learn about setup, features, MagSpeed scrolling, Darkfield 8000 DPI sensor, Logitech Flow, and more for enhanced productivity.
	Logitech MX Master 3S Wireless Performance Mouse User Manual Comprehensive user manual for the Logitech MX Master 3S wireless performance mouse, covering setup, connectivity, features like MagSpeed scroll wheel, thumb wheel, gesture button, Darkfield sensor, and battery information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

LOGITECH MX KEYS S + MX MASTER 3S

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Logitech MX Keys S + MX

Search Manuals+

[Deep Search](#)

[Upload](#)

[Login](#)

MANUALS+

[Home](#)

[About Us](#)

[Privacy Policy](#)

[Login](#)

GUIDES

[Amazon Manuals](#)

[AliExpress Manuals](#)

[Video Guides](#)

[Login](#)

FOLLOW

[@manualsplus](#)

[YouTube](#)

[LinkedIn](#)

[Facebook](#)

[Login](#)

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

[Open login options](#)