Logitech M196

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Logitech M196 Bluetooth Wireless Mouse User Manual

Model: M196

Introduction

This manual provides instructions for setting up, operating, and maintaining your Logitech M196 Bluetooth

Manuals+


logi

What's in the Box

Upon unboxing your Logitech M196 mouse, verify that all components are present:

- Logitech M196 Wireless Mouse
- 1 AA Battery (pre-installed)
- User Documentation

Advertisements



Image: The Logitech M196 mouse and a single AA battery, illustrating the contents included in the product packaging.

Setup

1. Powering On and Battery Check

The Logitech M196 mouse comes with one AA battery pre-installed. To activate the mouse:

Advertisements

1. Locate the ON/OFF switch on the bottom of the mouse.
2. Slide the switch to the 'ON' position.

2. Bluetooth Pairing

1. Ensure the mouse is powered on.
2. On the bottom of the mouse, locate the Bluetooth pairing button (often indicated by a Bluetooth symbol).
3. Press and hold the pairing button for a few seconds until the LED indicator on the mouse begins to blink, signifying it is in pairing mode.
4. On your computer, tablet, or smartphone, navigate to the Bluetooth settings.
5. Search for new devices. The mouse should appear as 'Logitech M196'.
6. Select 'Logitech M196' to complete the pairing process. The LED on the mouse will stop blinking and remain solid for a moment, then turn off, indicating a successful connection.

Advertisements




Image: The Logitech M196 mouse positioned on a wooden desk, highlighting its Bluetooth connectivity feature for easy pairing.

Advertisements



Image: An annotated diagram of the Logitech M196 mouse, pointing out key features such as the ON/OFF switch, long-press pairing mode button, and battery compartment.

Operating the Mouse

The Logitech M196 mouse offers standard three-button functionality with a scroll wheel for navigation.

Advertisements

- **Left Click:** Primary selection and interaction.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls vertically through documents and web pages. The scroll wheel also functions as a middle click button.

The optical tracking technology provides smooth and accurate cursor control on various surfaces.




Image: A hand operating the Logitech M196 mouse on a wooden desk, demonstrating its comfortable design and ease of use for navigation.

Advertisements

Maintenance

Battery Replacement

The Logitech M196 mouse is designed for a 12-month battery life under typical usage conditions. When the mouse performance degrades or it stops responding, it's time to replace the battery.

1. Turn the mouse OFF using the switch on the bottom.
2. Locate the battery compartment cover on the bottom of the mouse.
3. Slide or lift the cover to open the compartment.
4. Remove the old AA battery.
5. Insert a new AA battery, ensuring correct polarity (+/-).




Image: The Logitech M196 mouse positioned beside a laptop, highlighting its extended 12-month battery life for reliable use.

Advertisements

Cleaning

To maintain optimal performance and hygiene, clean your mouse periodically:

- Use a soft, lint-free cloth lightly dampened with water or an alcohol-based cleaner.
- Avoid harsh chemicals or abrasive materials.
- Gently wipe the exterior of the mouse.
- For the optical sensor, use a dry cotton swab to carefully remove any dust or debris.

Troubleshooting

Mouse Not Connecting or Responding

- **Re-pair Bluetooth:** Go to your device's Bluetooth settings, remove the 'Logitech M196' if listed, and then re-initiate the pairing process as described in the Setup section.
- **Device Bluetooth:** Ensure Bluetooth is enabled on your computer or device.
- **Interference:** Move the mouse closer to your device and away from other wireless devices that might cause interference.

Advertisements

Erratic Cursor Movement

- **Clean Sensor:** Clean the optical sensor on the bottom of the mouse.
- **Surface:** Use the mouse on a clean, non-reflective, and uniform surface. Avoid glass or highly reflective surfaces.
- **Battery Level:** A low battery can sometimes cause erratic behavior. Replace the battery.

Specifications

Model Name	M196
Connectivity Technology	Bluetooth
Movement Detection	Optical
Product Dimensions	3.9 x 2.36 x 0.1 inches (100 x 60 x 38 mm)
Item Weight	2.65 ounces (76 g) with battery
Batteries Required	1 AA battery
Battery Life	Up to 12 months (may vary based on usage)
Special Features	Lightweight, Portable, Wireless, Ambidextrous Design



Image: A technical diagram illustrating the dimensions of the Logitech M196 mouse in both millimeters and inches, along with its weight.

Warranty Information

Logitech products are manufactured to high quality standards. For detailed warranty information regarding your Logitech M196 Bluetooth Wireless Mouse, please refer to the warranty card included in your product packaging or visit the official Logitech support website.

Advertisements

Support

For further assistance, technical support, or to access drivers and software, please visit the official Logitech support page:

Logitech Support Website

© 2025 Logitech. All rights reserved.

Advertisements

Advertisements

Related Documents - M196

	Logitech Marathon Mouse M705: Getting Started Guide & Features Comprehensive guide to setting up and using the Logitech Marathon Mouse M705, including features, troubleshooting, and Unifying receiver setup.
	Logitech M535 Bluetooth Mouse: Features, Setup, and Compatibility Guide Discover the Logitech M535 Bluetooth Mouse. This guide covers its features, Bluetooth connection steps, customization with Logitech Options software, and compatibility with Windows, Mac OS, Chrome OS, and Android devices.
	Logitech LIFT Vertical Ergonomic Mouse: Getting Started Guide Comprehensive guide to setting up and using the Logitech LIFT Vertical Ergonomic Mouse. Learn about Bluetooth and Logi Bolt connections, features like SmartWheel and Logitech Flow, hand size fitting, and software customization with Logitech Options+.
	Logitech Signature M750/M750L Wireless Mouse: Features, Setup, and Customization Guide Explore the features, connectivity options, and customization capabilities of the Logitech Signature M750 and M750L wireless mice. Learn how to set up, pair, and optimize your mouse with Logi Options+ software.
	Logitech MX Master 4 Wireless Mouse Setup Guide Comprehensive setup guide for the Logitech MX Master 4 wireless mouse, covering Bluetooth and USB-C receiver connections, software installation, and product features.
	Logitech MX Anywhere 2S Wireless Mouse Quick Start Guide Get started with your Logitech MX Anywhere 2S wireless mouse. This guide covers initial setup, features like hyper-fast scrolling, horizontal scrolling, gesture controls, and battery charging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

LOGITECH M196

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Logitech M196 manuals, g

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

Save manuals, notes, uploads, and questions

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

Privacy Policy · DMCA