

Manuals.plus / > Samsung / > Samsung Galaxy Book3 360 2-in-1 Laptop User Manual

Samsung Galaxy Book3 360

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Samsung Galaxy Book3 360 2-in-1 Laptop User Manual

Model: Galaxy Book3 360

Advertisements

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Samsung Galaxy Book3 360 2-in-1 Laptop. Please read this guide thoroughly to ensure proper use and to maximize the performance and longevity of your device.



Manuals+




Image: The Samsung Galaxy Book3 360 laptop displayed open, showcasing its screen and keyboard from a front perspective.

The Samsung Galaxy Book3 360 is a versatile 2-in-1 laptop featuring a 13.3-inch Full HD AMOLED touchscreen. Powered by a 13th Gen Intel 12-Core i7-1360P Processor, 16GB RAM, and a 512GB SSD, it offers robust performance for various

tasks. Its convertible design allows it to function as both a laptop and a tablet, adapting to your needs.

SETUP

1. Unboxing and Initial Inspection

Carefully remove your Galaxy Book3 360 and its accessories from the packaging. Ensure all components are present and undamaged. The package typically includes the laptop, power adapter, and documentation.

Advertisements

2. Charging the Device

Before first use, connect the power adapter to the laptop's USB-C port and plug it into a power outlet. Allow the device to charge until the battery indicator shows a full charge. This ensures stable power for the initial setup process.

3. Initial Power On and Windows 11 Setup

Press the power button located on the side of the laptop. Follow the on-screen instructions to complete the Windows 11 Home setup. This includes selecting your region, connecting to a Wi-Fi network, creating a user account, and configuring privacy settings.

Advertisements



Image: The Samsung Galaxy Book3 360 laptop shown open at an angle, highlighting its slim profile and display.

4. Fingerprint Reader Setup

During or after the Windows 11 setup, you will have the option to set up the integrated fingerprint reader for secure and convenient login. Follow the prompts to register your fingerprints.

5. Exploring 2-in-1 Functionality

The Galaxy Book3 360 can be used in various modes. Gently fold the screen backward to transition between laptop, tent, stand, and tablet modes. The operating system will automatically adjust the display orientation.

Advertisements



Image: The Samsung Galaxy Book3 360 laptop folded into tablet mode, with the keyboard hidden behind the screen.

Advertisements

OPERATING INSTRUCTIONS

1. Basic Navigation

- **Keyboard and Touchpad:** Use the backlit keyboard for typing and the precision touchpad for cursor control and gestures.
- **Touchscreen:** Interact directly with the display using touch gestures for navigation, scrolling, and selecting items.



Image: A top-down view of the Samsung Galaxy Book3 360's keyboard and touchpad, showing the layout.

Advertisements

2. Connecting Peripherals

Your laptop features various ports for connectivity:

- **USB-A 3.2:** For standard USB devices like mice, keyboards, or external drives.
- **Thunderbolt 4 / USB-C 3.2:** For high-speed data transfer, external displays, and charging.
- **HDMI:** Connect to external monitors or projectors.
- **MicroSD Card Reader:** Insert a MicroSD card to access photos, videos, and other files.



Image: A side profile of the Samsung Galaxy Book3 360, illustrating the various input/output ports available.

Advertisements

3. Audio and Camera

- **Dolby Atmos:** Experience enhanced audio quality. Adjust settings through Windows Sound settings.
- **1080p FHD Camera:** Use the integrated camera for video calls and conferences. Access it through applications like Camera, Microsoft Teams, or Zoom.

4. Battery Management

To optimize battery life:

- Adjust screen brightness.
- Close unused applications.
- Utilize Windows battery saver mode.
- Avoid extreme temperatures.

Advertisements

MAINTENANCE

1. Cleaning Your Device

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Body and Keyboard:** Wipe with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth. Ensure no liquid enters ports.

2. Software Updates

Regularly update your operating system and drivers:

- **Windows Update:** Go to *Settings > Windows Update* to check for and install the latest Windows 11 updates.
- **Samsung Update:** Use the pre-installed Samsung Update application to ensure all device drivers and Samsung software are current.

Advertisements

3. Storage Management

Periodically review and manage your 512GB SSD storage. Delete unnecessary files, uninstall unused applications, and consider cloud storage for large files to maintain optimal performance.

TROUBLESHOOTING

If you encounter issues with your Galaxy Book3 360, refer to the following common solutions:

Issue	Possible Solution
Device does not power on	Ensure the power adapter is securely connected and the battery is charged. Try holding the power button for 10-15 seconds.
Screen is blank or unresponsive	Restart the device. If in tablet mode, ensure the screen is clean and free of obstructions. Check display settings if an external monitor is connected.
Wi-Fi connectivity problems	Restart your router and the laptop. Check Wi-Fi settings in Windows to ensure the correct network is selected and drivers are updated.
Slow performance	Close unnecessary applications. Check Task Manager for resource-intensive processes. Ensure Windows and drivers are up to date. Consider freeing up storage space.
Fingerprint reader not working	Ensure your finger is clean and dry. Re-register your fingerprints in Windows Settings if the issue persists.

For more complex issues or persistent problems, please refer to the Samsung support website or contact customer service.

SPECIFICATIONS

Below are the key technical specifications for the Samsung Galaxy Book3 360 (Model: GALAXY-BOOK3-360-):

- **Display:** 13.3-inch FHD (1920 x 1080) AMOLED Touchscreen, HDR500, 120% DCI-P3
- **Processor:** 13th Gen Intel 12-Core i7-1360P (up to 3.7 GHz)
- **Graphics:** Integrated Intel Iris Xe Graphics eligible
- **RAM:** 16GB DDR4 SDRAM
- **Storage:** 512GB SSD
- **Operating System:** Windows 11 Home
- **Ports:**
 - 1 x USB-A 3.2
 - 1 x Thunderbolt 4
 - 1 x USB-C 3.2
 - 1 x HDMI
 - 1 x Multi-media MicroSD Card Reader
- **Wireless Connectivity:** 802.11bgn, Bluetooth 5.1
- **Camera:** 1080p FHD Camera
- **Audio:** Dolby Atmos
- **Security:** Fingerprint Reader
- **Keyboard:** Backlit Qwerty Keyboard
- **Dimensions (LxWxH):** 7.95 x 11.98 x 0.51 inches
- **Color:** Gray

Advertisements

WARRANTY AND SUPPORT

Warranty Information

Your Samsung Galaxy Book3 360 is covered by a limited manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Samsung support website. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, service, or further inquiries, please contact Samsung Customer Support. You can find contact information, FAQs, and additional resources on the official Samsung website:

[Visit Samsung Support](#)

Advertisements

When contacting support, please have your product model number (GALAXY-BOOK3-360-) and serial number ready.

Advertisements

Related Documents - Galaxy Book3 360

	Samsung Galaxy Book User Manual: Setup, Features, and Troubleshooting Comprehensive user manual for Samsung Galaxy Book laptops, covering setup, basic operations, applications, settings, and troubleshooting. Learn to use your device effectively.
	Guide de Réparation Samsung NP960XHA Manuel de réparation détaillé pour le Samsung NP960XHA, incluant les procédures de démontage, remontage, et conseils de sécurité.
	Samsung NP960XHA Laptop Repair Guide and Service Manual This repair guide for the Samsung NP960XHA laptop provides detailed instructions for disassembly, reassembly, parts identification, software management, and hardware diagnostics, aimed at technicians and advanced users.
	Samsung NP960QGK Repair Guide This official repair guide for the Samsung NP960QGK, also known as the Galaxy Book4 Pro 360, provides detailed instructions for disassembly, assembly, parts identification, and software recovery. It is essential for technicians and users performing self-repairs on this laptop model.
	Samsung Galaxy Book User Guide Comprehensive user guide for Samsung Galaxy Book laptops, covering getting started, basic operations, app usage, settings, troubleshooting, and safety precautions.
	Promozione Samsung Galaxy Now!: Termini e Condizioni per il Trade-in Termini e condizioni dettagliati per la promozione Samsung Galaxy Now!, che descrive il processo di permuta di dispositivi usati all'acquisto di nuovi modelli Galaxy Foldable 7, inclusi idoneità, categorie di dispositivi e valutazione.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

SAMSUNG GALAXY BOOK3 360

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Samsung Galaxy Book3 360

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

[Privacy Policy](#) · [DMCA](#)