

[Manuals.plus](#) /

› [Acer](#) /

› Acer Swift Lite 14 (SFL14-54M) Laptop User Manual

Acer SFL14-54M

Acer Swift Lite 14 (SFL14-54M) Laptop User Manual

Model: SFL14-54M

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Acer Swift Lite 14 (SFL14-54M) laptop. This device features an Intel Core Ultra 5 115U processor, a 14-inch WUXGA OLED display, 16 GB of RAM, and a 512 GB SSD, running on Windows 11 Home. Please read this manual thoroughly to ensure proper use and longevity of your laptop.

2. SETUP

2.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the box contents are present and undamaged. If any items are missing or damaged, contact your retailer immediately.

- Laptop (1N)
- Power cord (1N)
- Adapter (1N)
- User Manual (1N)

2.2 Connecting the Power Adapter

Before first use, ensure the laptop is fully charged. Connect the power adapter to the laptop's power input port and then to a power outlet. The charging indicator light will illuminate.

Brilliance You Can See

OLED 

35.56 cm (14-inch)
OLED display

100%

DCI-P3



1920x1200
resolution



87% screen
to body ratio



Image: Side view of the Acer Swift Lite 14 laptop, illustrating the various ports including the power input.

2.3 First Power On and Windows Setup

Press the power button to turn on the laptop. Follow the on-screen instructions to complete the initial Windows 11 Home setup, including language selection, network connection, and user account creation.

3. OPERATING YOUR LAPTOP

3.1 Power Management

- **Power On:** Press the power button located on the keyboard.
- **Sleep Mode:** Close the lid or press the power button briefly.
- **Shut Down:** Go to Start > Power > Shut down in Windows.

3.2 Keyboard and Touchpad

The laptop features an 80-/81-/84-key Acer backlit keyboard with international language support. The touchpad supports multi-touch gestures for navigation.

- **Backlit Keyboard:** The keyboard backlight can be adjusted or toggled using function keys.
- **Copilot Key:** A dedicated Copilot key provides quick access to AI-powered assistance in Windows 11.



Image: Close-up of the laptop keyboard highlighting the dedicated Copilot key.

3.3 Display

The 14.0-inch WUXGA (1920 x 1200) OLED display offers high brightness (400 nits typical) and vibrant colors. The 16:10 aspect ratio is suitable for productivity and entertainment.



Image: The Acer Swift Lite 14 laptop showcasing its OLED display with vivid imagery.

3.4 Ports and Connectivity

The laptop provides various ports for connecting external devices:

- 1 x USB 3.2 port
- 2 x USB Type-C ports with DC-in (for charging and data)
- HDMI 1.4 port
- Audio jack
- Kensington lock slot

Wireless connectivity includes Wi-Fi 6 and Bluetooth 5.1 or above.



Image: A visual representation of the laptop's ports, including USB, USB-C, HDMI, audio jack, and Kensington lock.

3.5 Webcam

The integrated FHD camera includes a privacy shutter for enhanced security. Utilize Windows Studio Effects for improved video calls with features like auto framing, noise reduction, and lighting adjustments.



Image: The laptop's webcam with its privacy shutter, demonstrating enhanced video call features.

4. MAINTENANCE

4.1 Cleaning Your Laptop

- Use a soft, lint-free cloth dampened with a small amount of water or a specialized screen cleaner for the display.
- For the keyboard and chassis, use a soft cloth. Avoid harsh chemicals or abrasive materials.
- Regularly clean the ventilation openings to prevent dust buildup.

4.2 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- Do not expose the battery to extreme temperatures.

4.3 Software Updates

Regularly update your Windows operating system and device drivers to ensure optimal performance and security. You can check for updates through Windows Settings.

5. TROUBLESHOOTING

If you encounter issues with your Acer Swift Lite 14, refer to the following common troubleshooting steps:

Problem	Possible Solution
Laptop does not power on	Ensure the power adapter is securely connected and the battery is charged. Try a different power outlet.
Display is blank or flickering	Restart the laptop. Check display settings. Ensure graphics drivers are updated.
Wi-Fi or Bluetooth not connecting	Check if Wi-Fi/Bluetooth is enabled in Windows settings. Restart your router or Bluetooth device. Update wireless drivers.
System performance is slow or hangs	Close unnecessary applications. Check for malware. Ensure Windows and drivers are up to date. Consider checking disk space.
Keyboard backlight not working	Use the designated function keys to adjust or toggle the backlight. Check keyboard settings in Windows.

If the issue persists after attempting these solutions, please contact Acer customer support for further assistance.

6. SPECIFICATIONS

Detailed technical specifications for the Acer Swift Lite 14 (SFL14-54M) laptop:

Feature	Detail
Model Name	Swift Lite 14
Model Number	SFL14-54M
Processor	Intel Core Ultra 5 115U (1.5 GHz base, up to 4.2 GHz max boost, 10 MB L3 cache, 8 cores)
RAM	16 GB LPDDR5
Storage	512 GB SSD (M.2 PCIe Gen 4 NVMe)
Display	14.0-inch WUXGA (1920 x 1200) OLED, 400 nits, AcerCineCrystal
Graphics	Integrated Intel Graphics
Operating System	Windows 11 Home
Ports	1x USB 3.2, 2x USB Type-C (with DC-in), 1x HDMI 1.4, Audio Jack
Wireless Connectivity	Wi-Fi 6, Bluetooth 5.1+
Webcam	FHD Camera with privacy shutter

Feature	Detail
Keyboard	Backlit, with Copilot key
Weight	1.1 Kilograms
Dimensions (L x W x Thickness)	31.4L x 1.5W x 21.9Th Centimeters
Battery Energy Content	50 Watt Hours (Lithium Ion)

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Acer Swift Lite 14 (SFL14-54M) comes with a **1 Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims.

7.2 Manufacturer and Importer Contact

For technical support, service, or warranty inquiries, please contact Acer directly:

- **Manufacturer:** Acer India PVT LTD, R.S. No: 38/2, Sedarapet Main Road, Sedarapet, Villianur Commune, Puducherry-605111
- **Importer:** ACER INDIA PRIVATE LIMITED Embassy Heights, 6th Floor, No. 13, Magrath Road, Next to HOSMAT Hospital, Bangalore, INDIA – 560025

You can also visit the official Acer support website for drivers, FAQs, and additional assistance.

