

Manuals.plus / > **Lenovo** / > Lenovo IdeaPad Slim 3 15IRU9 15.6" FHD IPS Touchscreen Anti-Glare Display Laptop User Manual

Lenovo IdeaPad Slim 3 15IRU9

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Lenovo IdeaPad Slim 3 15IRU9 User Manual

Model: IdeaPad Slim 3 15IRU9

1. INTRODUCTION

The Lenovo IdeaPad Slim 3 is a dynamic and robust laptop designed for efficiency and portability. Featuring an Intel Core 5 120U processor, 8GB DDR5-5200 RAM, and a 512GB NVMe M.2 SSD, it delivers fast performance for both work and entertainment. Its 15.6-inch FHD IPS Touchscreen Anti-Glare Display provides exceptional visuals, complemented by a variety of AI-powered productivity features. This manual will guide you through the essential steps to get the most out of your new device.

2. SETUP

2.1 Unboxing and Initial Inspection

Carefully remove your Lenovo IdeaPad Slim 3 laptop and all accessories from the packaging. Verify that all components are present:

- Lenovo IdeaPad Slim 3 Laptop
- Power Adapter and Power Cord

- Quick Start Guide (if included)

Inspect the laptop for any physical damage before proceeding.

2.2 Connecting to Power

Before first use, it is recommended to fully charge the laptop battery. Connect the power adapter to the charging port on the laptop and then plug the power cord into a wall outlet. The charging indicator light will illuminate.

2.3 First Boot and Windows Setup

Press the power button located on the side or top right of the keyboard to turn on the laptop. The system will guide you through the initial Windows 11 Home setup process. Follow the on-screen prompts to configure language, region, network connection, and user accounts.

Advertisements



Figure 2.1: The Lenovo IdeaPad Slim 3 laptop, ready for initial setup.

3. OPERATING YOUR LAPTOP

3.1 Keyboard and Touchpad

The laptop features a full-sized keyboard and a precision touchpad. Use the touchpad for navigation, clicking, and multi-touch gestures. Refer to Windows settings for customizing touchpad sensitivity and gestures.



Figure 3.1: Top-down view of the keyboard and touchpad layout.

Advertisements

3.2 Ports and Connectors

Familiarize yourself with the various ports on your laptop for connecting external devices:

- **USB Ports:** For connecting USB devices like external drives, mice, or keyboards.
- **HDMI Port:** For connecting to external displays or projectors.
- **Audio Jack:** For headphones or external speakers.
- **SD Card Reader:** For reading data from SD memory cards.
- **Power Connector:** For connecting the AC adapter.



Figure 3.2: Left side view, showing power, USB, and HDMI ports.

Advertisements



Figure 3.3: Right side view, showing USB, audio jack, and SD card reader.

3.3 Touchscreen Functionality

Your IdeaPad Slim 3 features a responsive touchscreen display. You can interact with the operating system and applications directly using touch gestures, similar to a tablet. Ensure the screen is clean for optimal touch response.

4. MAINTENANCE

4.1 Cleaning Your Laptop

To maintain the appearance and functionality of your laptop:

Advertisements

- **Screen:** Use a soft, lint-free cloth specifically designed for electronics. Dampen slightly with water or a screen cleaner, never spray directly onto the screen.
- **Keyboard and Chassis:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap solution can be used, ensuring no liquid enters openings.
- **Vents:** Periodically use compressed air to clear dust from the cooling vents to ensure proper airflow.

4.2 Software Updates

Regularly update your operating system (Windows 11 Home) and device drivers to ensure optimal performance, security, and compatibility. Windows Update typically handles this automatically, but you can manually check for updates via Settings > Windows Update.

4.3 Battery Care

To prolong the life of your laptop battery:

Advertisements

- Avoid extreme temperatures.
- Do not leave the laptop plugged in at 100% charge for extended periods if not in use.
- For long-term storage, charge the battery to about 50-60% and store in a cool, dry place.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your laptop.

5.1 No Power / Laptop Not Turning On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Check if the power outlet is functional by plugging in another device.
- If the battery is completely drained, it may take a few minutes of charging before the laptop can power on.

Advertisements

5.2 Display Issues

- **Blank Screen:** Try pressing **Fn + F7** (or the key with a display icon) to toggle display output.
- **Flickering/Distorted Display:** Update your graphics drivers. If using an external monitor, check the cable connection.

5.3 Wi-Fi Connectivity Problems

- Ensure Wi-Fi is enabled (check the Wi-Fi icon in the taskbar or Settings > Network & Internet > Wi-Fi).
- Restart your router and modem.
- Forget the network and reconnect.
- Update your wireless network adapter drivers.

5.4 System Slowdown

- Close unnecessary applications running in the background.
- Check Task Manager (Ctrl+Shift+Esc) for resource-intensive processes.
- Ensure your system has enough free storage space.
- Run a virus scan.

Advertisements

6. SPECIFICATIONS

Below are the key technical specifications for the Lenovo IdeaPad Slim 3 15IRU9:

Feature	Specification
Brand	Lenovo

Feature	Specification
Model Name	IdeaPad Slim 3 15IRU9
Screen Size	15.6 Inches
Screen Resolution	1920 x 1080 pixels (FHD)
Processor	Intel Core 5 120U
RAM Memory Installed Size	8 GB DDR5-5200
Hard Disk Size	512 GB NVMe M.2 SSD
Graphics Coprocessor	Intel HD Graphics 520 (Integrated)
Operating System	Windows 11 Home
Wireless Type	802.11ax (WiFi 6)
Color	Abyss Blue

7. WARRANTY AND SUPPORT

Your Lenovo IdeaPad Slim 3 15IRU9 laptop comes with a standard manufacturer's warranty. The duration and terms of the warranty may vary by region and purchase location. Please refer to the warranty card included with your product or visit the official Lenovo support website for detailed information.

For technical assistance, driver downloads, or service requests, please visit the official Lenovo Support website:

Advertisements

<https://support.lenovo.com/>

When contacting support, please have your laptop's serial number readily available. The serial number is typically located on a sticker on the bottom of the laptop or can be found in the system information within Windows.

Advertisements

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

LENOVO IDEAPAD SLIM 3 15IRU9

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Lenovo IdeaPad Slim 3 15

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options