

[Manuals.plus](#) /

› [Samsung](#) /

› Samsung Galaxy Tab S10 Ultra User Manual

## Samsung SM-X926B

# Samsung Galaxy Tab S10 Ultra User Manual

Model: SM-X926B

## INTRODUCTION

---

This user manual provides detailed instructions for the Samsung Galaxy Tab S10 Ultra. It covers essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure proper use and to maximize the features of your tablet.



Image: Samsung Galaxy Tab S10 Ultra tablet in Moonstone Gray with S Pen.

## WHAT'S IN THE BOX

---

Verify that all items are present in your product package:

- Samsung Galaxy Tab S10 Ultra Tablet
- S Pen
- USB Type-C Cable
- Quick Start Guide
- Ejection Pin



Image: The Samsung Galaxy Tab S10 Ultra tablet and S Pen, representing the core components included in the package.

## SETUP

### 1. Initial Power On

1. Press and hold the Power button located on the side of the tablet until the Samsung logo appears.
2. Follow the on-screen prompts to select your language, region, and agree to the terms and conditions.

### 2. S Pen Setup

The S Pen is included in the box and is ready for use. Simply remove it from its magnetic slot on the tablet's back. The S Pen connects automatically.

# Galaxy Tab S10 Series

“ This tablet will make you realize why Samsung has some of the best Android tablets, and the Galaxy Tab S10 Ultra is no exception.”

**HT TECH**  
MAKE LIFE SIMPLE



Image simulated for representational purposes. Actual UI/UX may vary. All third party logos, marks, images are trademarks of respective third party brand/owner. All views expressed are independent. Please check the specifics before buying.

Image: A close-up of the S Pen docked in the Samsung Galaxy Tab S10 Ultra, highlighting its zero latency feature.

## 3. Network Connection

Connect your tablet to a Wi-Fi network or insert a 5G SIM card for cellular data.

- **Wi-Fi:** Go to **Settings > Connections > Wi-Fi**, then select your network and enter the password.
- **5G:** Use the provided ejection pin to open the SIM card tray. Insert your 5G nano-SIM card and close the tray.

## 4. Account Setup

Sign in with your Google account to access the Play Store and other Google services. You can also sign in with your Samsung account for additional features and cloud services.

## OPERATING YOUR TABLET

### 1. Basic Navigation

- **Touchscreen:** Tap, swipe, pinch-to-zoom, and long-press to interact with the display.
- **Gestures:** Use intuitive gestures for navigation, such as swiping up from the bottom for the home screen or swiping from the sides for back.

## 2. S Pen Usage

The S Pen offers enhanced precision and functionality:

- **Note-taking:** Use the S Pen to write notes directly on the screen with the Samsung Notes app.
- **Drawing:** Utilize various drawing applications for creative tasks.
- **Air Actions:** Perform actions by gesturing with the S Pen while holding its button. Customize these actions in **Settings > Advanced features > S Pen > Air actions**.

## 3. Galaxy AI Features

The Galaxy Tab S10 Ultra integrates advanced AI capabilities:

- **Note Assist:** Automatically formats, summarizes, and translates notes. Access this feature within the Samsung Notes app.
- **Sketch to Image:** Convert rough sketches into refined images.
- **Circle to Search with Google:** Circle an object on your screen to instantly search for information about it.
- **PDF Translate:** Translate entire PDF documents in real-time.

### Launch AI with a single tap

Press the Galaxy AI Key<sup>6</sup> to unleash Galaxy AI to search what you want<sup>5</sup>.  
Your keyboard<sup>4</sup> is now highkey amazing.



Image: A visual representation of Galaxy AI features including Note Assist, Sketch to Image, and the Galaxy AI Key.

## 4. Multi-tasking and Productivity

- **Split View:** Run two apps side-by-side. Drag an app from the Edge panel to the desired side of the screen.
- **DeX Mode:** Connect a keyboard and mouse to transform your tablet into a desktop-like experience for enhanced productivity.

## 5. Camera Usage

The tablet features a 13 MP rear camera and a 12 MP front camera.

- Open the **Camera** app.
- Tap the shutter button to take photos or the record button for videos.
- Switch between front and rear cameras using the camera icon.

## 6. Charging

Connect the USB Type-C cable to the tablet's charging port and the other end to a compatible power adapter. The tablet supports fast charging.

## MAINTENANCE

---

### 1. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials. For the S Pen, gently wipe it with a dry cloth.

### 2. Water and Dust Resistance

The Galaxy Tab S10 Ultra and S Pen are rated IP68 for water and dust resistance. This means they can withstand submersion in up to 1.5 meters of fresh water for up to 30 minutes. Avoid exposure to saltwater, chlorinated water, or other liquids. Ensure the charging port is dry before charging.




Image: The Samsung Galaxy Tab S10 Ultra with water droplets on its surface, demonstrating its water and dust resistance.

### 3. Software Updates

Regularly check for software updates to ensure optimal performance and security. Go to **Settings > Software update > Download and install**.

### 4. Storage Management

To manage your 512 GB internal storage, go to **Settings > Battery and device care > Storage**. You can also expand storage using a microSD card (sold separately).

## TROUBLESHOOTING

---

### Common Issues and Solutions:

| Issue                  | Solution                                                                                                                                                                                                                                        |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Device not powering on | Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, press and hold the Power button and Volume Down button simultaneously for more than 7 seconds to force restart. |

| Issue                        | Solution                                                                                                                                                                              |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S Pen not responding         | Ensure the S Pen is properly charged by docking it in its slot. Check S Pen settings in <b>Settings &gt; Advanced features &gt; S Pen</b> . Restart the tablet if the issue persists. |
| Wi-Fi/5G connectivity issues | Restart your router/modem. On the tablet, toggle Wi-Fi/Mobile data off and on. Forget the network and reconnect. Ensure your SIM card is correctly inserted for 5G.                   |
| Apps crashing or freezing    | Close the app and reopen it. Clear the app's cache ( <b>Settings &gt; Apps &gt; select app &gt; Storage &gt; Clear cache</b> ). Update the app from the Play Store.                   |

## Factory Reset (Last Resort)

If problems persist, you may need to perform a factory reset. This will erase all data on your tablet. Back up important data before proceeding. Go to **Settings > General management > Reset > Factory data reset**.

## SPECIFICATIONS

| Feature                        | Detail                                                                                        |
|--------------------------------|-----------------------------------------------------------------------------------------------|
| Model Name                     | Samsung Galaxy Tab S10 Ultra                                                                  |
| Model Number                   | SM-X926B                                                                                      |
| Display                        | 14.6-inch Dynamic AMOLED 2X, 2960 x 1848 Pixels, 120Hz Refresh Rate                           |
| Processor                      | MediaTek Dimensity 9300 (up to 3.4 GHz)                                                       |
| RAM                            | 12 GB                                                                                         |
| Storage                        | 512 GB (expandable via microSD)                                                               |
| Operating System               | Android 14                                                                                    |
| Rear Camera                    | 13 MP (Main) + 8 MP (Ultra-Wide)                                                              |
| Front Camera                   | 12 MP (Ultra-Wide)                                                                            |
| Battery Capacity               | 11200 mAh                                                                                     |
| Connectivity                   | Wi-Fi, 5G Cellular, USB 3.2 Gen 1                                                             |
| Sensors                        | Accelerometer, Fingerprint Sensor, Gyro Sensor, Geomagnetic Sensor, Hall Sensor, Light Sensor |
| Dimensions (L x W x Thickness) | 20.9L x 32.6W x 0.5Th Centimeters                                                             |
| Weight                         | 723 Grams                                                                                     |
| Color                          | Moonstone Gray                                                                                |

## WARRANTY AND SUPPORT

### Warranty Information

The Samsung Galaxy Tab S10 Ultra comes with a **1 Year Manufacturer Warranty** for the device and **6 Months** for in-box accessories from the date of purchase.

## Customer Support

For technical assistance, warranty claims, or service inquiries, please contact Samsung Customer Service. You can find contact details on the official Samsung India website or through the Samsung Members app on your device.

**Manufacturer:** Dixon Technologies (India) Ltd., Plot no.6, Sector 90, Noida, Gautam Buddha Nagar, U.P. India – 201305, Samsung

**Importer:** Samsung India Electronics Pvt. Ltd. having its Registered Office at: 6th Floor, DLF Centre, Sansad Marg, New Delhi-110001

## IMPORTANT SAFETY INFORMATION

---

Always follow basic safety precautions when using your tablet to reduce the risk of injury, electric shock, fire, or damage to the device. Refer to the Quick Start Guide for additional safety warnings.