

Manuals.plus / > Apple / > Apple iPad (2025, A16 Chip, 11-inch, Wi-Fi + Cellular, 128GB) User Manual

Apple A3355

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Apple iPad (2025, A16 Chip, 11-inch, Wi-Fi + Cellular, 128GB) User Manual

Model: A3355

Advertisements

1. INTRODUCTION

Welcome to the user manual for your Apple iPad (2025 model A3355). This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Your iPad is a renewed product, professionally inspected, tested, and cleaned by Amazon-qualified suppliers to function and appear like new. Please note that while the device is fully functional, accessories may not be original but are compatible.

2. PRODUCT OVERVIEW

The Apple iPad (2025) features an 11-inch Liquid Retina display, powered by the A16 Bionic chip, offering robust performance for various tasks. This model includes Wi-Fi and Cellular connectivity, along with 128GB of storage. Familiarize yourself with the physical components of your device.

Advertisements

2.1 Device Components

- **Front Display:** 11-inch Liquid Retina display.
- **Front Camera:** For video calls and selfies.
- **Top Button:** Power/Sleep/Wake button, often integrated with Touch ID.
- **Volume Buttons:** Adjust audio levels.
- **USB-C Port:** For charging and connecting accessories.
- **Speakers:** Audio output.
- **Microphones:** For audio input.
- **Rear Camera:** For high-quality photos and videos.
- **SIM Card Tray:** For cellular models (requires a nano-SIM card).

2.2 Product Images



Figure 2.1: Front view of the Apple iPad (2025) in blue, showcasing its 11-inch display.

Advertisements




Figure 2.2: Side view of the Apple iPad (2025), highlighting its slim design and button placement.

Advertisements



Figure 2.3: Back view of the Apple iPad (2025) in blue, featuring the Apple logo and rear camera module.

Advertisements

3. SETUP

3.1 What's in the Box

Your renewed Apple iPad package includes:

- Apple iPad (2025, A16 Chip, 11-inch, Wi-Fi + Cellular, 128GB)
- Compatible Charger

Note: Additional accessories such as a USB-C cable may be included but are not guaranteed to be original Apple products.

Advertisements

3.2 Initial Charging

Before first use, fully charge your iPad. Connect the provided charger to the USB-C port on your iPad and plug it into a power outlet. The battery icon on the screen will indicate charging status.

3.3 Powering On and Off

- **To Power On:** Press and hold the Top button until the Apple logo appears.
- **To Power Off:** Press and hold the Top button and either volume button simultaneously until the power off slider appears. Drag the slider to shut down your iPad.

3.4 Initial Setup

Upon first power-on, follow the on-screen instructions to complete the initial setup:

Advertisements

1. Select your language and region.
2. Connect to a Wi-Fi network.
3. Set up Touch ID (if applicable) and create a passcode.
4. Restore from a backup or set up as a new iPad.
5. Sign in with your Apple ID or create a new one.
6. Enable location services and set up Siri.

3.5 Cellular Activation (Wi-Fi + Cellular Models)

If you have a cellular model, you can activate cellular data by inserting a nano-SIM card into the SIM card tray or by setting up an eSIM through your carrier. Refer to your cellular carrier's instructions for activation.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

Your iPad uses intuitive multi-touch gestures:

Advertisements

- **Tap:** Select an item or activate a button.
- **Swipe:** Scroll through content or navigate between screens.
- **Pinch:** Zoom in or out on photos and web pages.
- **Home Gesture:** Swipe up from the bottom edge of the screen to return to the Home screen.
- **App Switcher:** Swipe up from the bottom edge and pause in the middle of the screen to view open apps.

4.2 Connecting to Wi-Fi

1. Go to **Settings > Wi-Fi**.
2. Turn on Wi-Fi.
3. Select your desired network from the list.
4. Enter the password if prompted.

4.3 Using Cellular Data

If your cellular plan is active, your iPad will automatically use cellular data when Wi-Fi is unavailable. You can manage cellular data settings in **Settings > Cellular Data**.

Advertisements

4.4 Camera Usage

Open the **Camera** app to take photos and videos. Tap the shutter button to capture an image or start/stop video recording. Swipe left or right to switch between camera modes (Photo, Video, Panorama, etc.).

4.5 Security with Touch ID

If configured, use Touch ID to unlock your iPad, make purchases, and sign in to apps. Place your registered finger on the Top button to use Touch ID.

5. MAINTENANCE AND CARE

5.1 Cleaning Your iPad

Use a soft, lint-free cloth to clean your iPad. Avoid abrasive materials, aerosols, solvents, or ammonia-based cleaners. Do not spray cleaners directly onto the screen.

Advertisements

5.2 Battery Care

Your renewed iPad's battery is guaranteed to exceed 80% capacity relative to a new battery. To maximize battery lifespan:

- Avoid extreme temperatures.
- Keep software updated.
- Optimize settings like screen brightness and background app refresh.

5.3 Software Updates

Regularly check for and install software updates to ensure your iPad has the latest features and security enhancements. Go to **Settings > General > Software Update**.

Advertisements

5.4 Storage Management

To check and manage your iPad's storage, go to **Settings > General > iPad Storage**. You can offload unused apps or delete large files to free up space.

6. TROUBLESHOOTING

If you encounter issues with your iPad, try the following steps:

6.1 Common Issues and Solutions

- **iPad Not Responding:** Force restart your iPad by quickly pressing and releasing the Volume Up button, then quickly pressing and releasing the Volume Down button, then press and hold the Top button until the Apple logo appears.

- **Wi-Fi Connectivity Issues:** Turn Wi-Fi off and on in Settings. Restart your Wi-Fi router. Forget the network and reconnect.
- **Apps Crashing:** Close and reopen the app. Check for app updates in the App Store. Restart your iPad.
- **Battery Draining Quickly:** Review battery usage in Settings > Battery. Reduce screen brightness, disable unnecessary background app refresh, and limit location services.

Advertisements

6.2 Factory Reset

As a last resort, if your iPad is experiencing persistent issues, you may need to perform a factory reset. This will erase all data and settings. Before proceeding, ensure you have backed up your data to iCloud or a computer. Go to **Settings > General > Transfer or Reset iPad > Erase All Content and Settings**.

7. SPECIFICATIONS

Feature	Specification
Brand	Apple
Model Name	iPad (A16)
Item Model Number	A3355
Operating System	iPadOS 18
Screen Size	11 Inches
Display Resolution	2360 x 1640 Pixels
Processor	3.46 GHz (Apple A16 chip)
Graphics Coprocessor	Apple A16 chip (Integrated)
Memory Storage Capacity	128 GB
Connectivity	Wi-Fi + Cellular
Average Battery Life	9 Hours
Item Weight	1.06 pounds
Product Dimensions	9.79 x 7.07 x 0.28 inches
Color	Blue

8. WARRANTY AND SUPPORT

Your renewed Apple iPad is backed by the Amazon Renewed Guarantee. This product is eligible for a replacement or refund within 90 days of receipt if you are not satisfied. For any issues or support inquiries, please contact Amazon Renewed customer service.

For additional information and support resources, visit the official Apple support website or the Amazon Renewed store page.

Advertisements

Related Documents - A3355

 Apple Recycler Guide Model A1842 (11-inch) (M4) - iCubator Model A1843 (13-inch) (M4) - iCubator Model A1844 (11-inch) (M4) - iCubator Model A1845 (13-inch) (M4) - iCubator	Apple Recycler Guide for iPad Air (M4) - Disassembly and Safety Comprehensive guide for electronics recyclers on the safe disassembly of Apple iPad Air 11-inch and 13-inch (M4) models, detailing component identification, safety protocols, and compliance with EU directives.
 Apple Recycler Guide Model A1842 (11-inch) (M4) - iCubator Model A1843 (13-inch) (M4) - iCubator Model A1844 (11-inch) (M4) - iCubator Model A1845 (13-inch) (M4) - iCubator	Apple iPad Pro (M4) Recycling Guide A comprehensive guide for recycling Apple iPad Pro models with M4 chip, detailing disassembly procedures, safety precautions, and component identification for responsible electronic waste management.
 Apple Recycler Guide Model A1842 (11-inch) (M4) - iCubator Model A1843 (13-inch) (M4) - iCubator Model A1844 (11-inch) (M4) - iCubator Model A1845 (13-inch) (M4) - iCubator	Apple Recycler Guide for iPad Pro (M4) A comprehensive guide for electronics recyclers on the safe and efficient disassembly of iPad Pro 11-inch (M4) and iPad Pro 13-inch (M4) models, focusing on resource recovery and compliance with environmental regulations.
 Apple Recycler Guide Model A1842 (11-inch) (M3) - iCubator Model A1843 (13-inch) (M3) - iCubator Model A1844 (11-inch) (M3) - iCubator Model A1845 (13-inch) (M3) - iCubator	Apple iPad Air (M3) Recycling Guide A comprehensive guide for recycling Apple iPad Air models with M3 chips, including disassembly procedures, safety precautions, and component identification. This guide is intended for electronics recyclers.
 Apple Recycler Guide Model A1842 (11-inch) (M3) - iCubator Model A1843 (13-inch) (M3) - iCubator Model A1844 (11-inch) (M3) - iCubator Model A1845 (13-inch) (M3) - iCubator	Apple Recycler Guide for iPad Air (M3) A guide for electronics recyclers on how to disassemble iPad Air 11-inch (M3) and iPad Air 13-inch (M3) models to maximize resource recovery, including safety considerations and component identification.
 	Introducing iPad: Features and Sales Guide An overview of the latest iPad features, including the A16 chip, Liquid Retina display, advanced camera systems, and compatibility with Apple Pencil and Magic Keyboard Folio.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?



Details

Model number, symptoms, what you tried, or the section of the manual you are using.



Submit question

APPLE A3355

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Apple A3355 manuals, gui

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

[Privacy Policy](#) · [DMCA](#)