

Redmi Redmi Pad Pro 5G

Redmi Pad Pro 5G User Manual

Model: Redmi Pad Pro 5G

INTRODUCTION

Welcome to the Redmi Pad Pro 5G user manual. This document provides essential information to help you set up, operate, and maintain your new tablet. The Redmi Pad Pro 5G features a 12.1-inch display, Snapdragon 7s Gen 2 processor, 10000mAh battery, and runs on HyperOS, offering a powerful and versatile user experience.

WHAT'S IN THE BOX

Upon unboxing your Redmi Pad Pro 5G, verify that all the following items are included:

- Tablet Computer
- Adapter
- USB Type-C Cable
- Quick Start Guide
- SIM Ejector Tool



Image: The Redmi Pad Pro 5G tablet with its included accessories, including the adapter, USB-C cable, and SIM ejector tool.

SETUP

1. Initial Charging

Before first use, fully charge your Redmi Pad Pro 5G using the provided adapter and USB Type-C cable. Connect the USB Type-C cable to the tablet's charging port and the adapter to a power outlet. The tablet supports 33W fast charging.

2. Power On/Off

- **To Power On:** Press and hold the Power button until the Redmi logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options.

3. SIM Card Installation (for 5G models)

For 5G connectivity, insert a nano-SIM card into the SIM card tray. Use the provided SIM ejector tool to open the tray. Ensure the SIM card is correctly oriented before reinserting the tray.



Image: Side view of the Redmi Pad Pro 5G, illustrating the location of the SIM tray and other external components.

4. Initial Configuration

Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, Google account login, and security settings.

OPERATING INSTRUCTIONS

Display Features

The Redmi Pad Pro 5G features a 12.1-inch XL display with a 2.5K resolution (2560x1600 pixels) and a 120Hz AdaptiveSync refresh rate. This adaptive refresh rate adjusts automatically to optimize battery efficiency based on content. The display also includes triple eye-care technology for reduced eye strain.

12.1 XL Display

Redmi Pad Pro features the most balanced sized display at 30.7cm(12.1-inches). Perfectly spaced between an 11-inch and 13-inch tablet enabling the perfect entertainment and



33% larger display area compared with Redmi Pad



*Redmi Pad Pro's screen size is about 12.1 inches when measured diagonally. Viewable area is smaller due to the curved corners. Measurements between individual products may vary.
*Data obtained from Xiaomi Internal Labs. Actual results may vary.

Image: The 12.1-inch XL display of the Redmi Pad Pro 5G, highlighting its large viewing area.

120HZ AdaptiveSync Screen

6-stage AdaptiveSync refresh rate on Redmi Pad Pro ensures a smooth experience in everything you do. Be it gaming, scrolling through web pages or even taking notes, the display is able to understand what you're doing and calibrate the refresh rate to achieve higher battery efficiency.



Image: Visual representation of the 120Hz AdaptiveSync screen technology on the Redmi Pad Pro 5G.

Audio Features

Experience immersive sound with the tablet's quad speakers and Dolby Atmos support. Adjust volume using the physical volume buttons located on the side of the device.

Big Display EVEN BIGGER SPEAKERS

Redmi Pad Pro features quad speakers so that you can hear every note and every dialogue with utmost clarity.



Image: Diagram showing the quad speaker placement and Dolby Atmos branding on the Redmi Pad Pro 5G.

Battery Management

The Redmi Pad Pro 5G is equipped with a 10000mAh (typical) battery, providing extended usage times. For optimal battery life, use the included 33W fast charger. Avoid extreme temperatures and fully discharging the battery frequently.

33+ DAYS STANDBY

With the 10000mAh (typ) battery, dare to venture anywhere and everywhere with Redmi Pad Pro.



33+ days
Ultra-long standby



16 hours
HD video playback



17 hours
Reading duration



10000mAh

*Data obtained from Xiaomi Internal Labs. Actual results may vary.
*The typical battery capacity is 10,000mAh and the rated battery capacity is 9,500mAh.

Image: Illustration of the 10000mAh battery inside the Redmi Pad Pro 5G, emphasizing its large capacity.

HyperOS Interconnectivity

HyperOS enables seamless interaction between your Redmi Pad Pro 5G and compatible Xiaomi smartphones.

- **Network Sync:** Connect to your phone's hotspot with a single click when Wi-Fi signals are unavailable.
- **Home Screen+:** Receive messages, answer calls, and access phone apps directly on the tablet.
- **Shared Clipboard:** Copy and paste text and images between devices.
- **Cross-device Notes:** Access your smartphone camera from the Notes app on the tablet to take photos and insert them.



Image: Overview of Xiaomi HyperOS features, including Network Sync and Home Screen+.

Network Sync



When no Wi-Fi signals are available nearby, the tablet can connect to your phone's hotspot with one click instead of turning on a hotspot or entering a password.

*Sign into the same Xiaomi account on both the tablet and smartphone

*Bluetooth® must be activated on both devices.

*WLAN must be activated on the tablet, and mobile data must be activated on the smartphone.

*Xiaomi Interconnectivity must be activated on both devices in Settings - Interconnectivity.

Image: A visual demonstrating the Network Sync feature, allowing the tablet to connect to a phone's hotspot.

Accessories (Sold Separately)

Enhance your Redmi Pad Pro 5G experience with optional accessories:

- **Redmi Smart Pen:** For handwritten notes, drawing, and painting. Features handwriting recognition.
- **Redmi Pad Pro Keyboard:** Transforms your tablet into a productivity device for typing and presentations.

Take Notes

PAINT & DRAW

With Redmi Smart Pen, you can take notes anytime, anywhere. With the all new Mi Canvas app, you have a much more refined control over your canvas with multiple options for each pen allowing you a granular control over your art.



Image: A user taking notes on the Redmi Pad Pro 5G with the Redmi Smart Pen.



Redmi Pad Pro KEYBOARD

Create, edit and present your ideas with the help of Redmi Pad Pro Keyboard which has been engineered to support your workflows across multiple work applications. Know more about the Redmi Pad Pro Keyboard [here](#).

Image: The Redmi Pad Pro 5G attached to its dedicated keyboard, illustrating its use for productivity tasks.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Protection:** Consider using a protective case and screen protector to prevent scratches and damage.
- **Environmental Conditions:** Avoid exposing the tablet to extreme temperatures, direct sunlight, or high humidity.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security.



Image: Rear view of the Redmi Pad Pro 5G, showing its camera module and sleek design.

TROUBLESHOOTING

Common Issues and Solutions

- **Tablet not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a force restart by holding the power button for

approximately 10-15 seconds.

- **Screen unresponsive:** Try restarting the tablet. If the issue persists, ensure the screen is clean and free of debris.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Forget the network and reconnect.
- **Slow performance:** Close unnecessary background applications. Clear cache and temporary files. Ensure sufficient storage space is available. Consider a factory reset as a last resort (back up data first).
- **Battery draining quickly:** Reduce screen brightness. Disable unused features like GPS, Bluetooth, and Wi-Fi when not needed. Limit background app refresh. Check for apps consuming excessive power in battery settings.

SPECIFICATIONS

Feature	Detail
Brand	Redmi
Model Name	Redmi Pad Pro 5G
Memory Storage Capacity	256 GB
Screen Size	12.1 Inches (30.7cm)
Display Resolution Maximum	2560x1600 (2.5K)
Display Type	OLED
Display Refresh Rate	120 Hz AdaptiveSync
RAM Memory Installed	8 GB
Processor	Snapdragon 7s Gen 2
Operating System	HyperOS
Cellular Technology	5G
Wireless Technology Type	Wi-Fi 6 (802.11ax)
Battery Capacity	10000 mAh
Fast Charging	33W
Rear Camera Resolution	8 MP
Front Camera Resolution	8 MP
Item Dimensions (L x W x Thickness)	18.2L x 28W x 0.8Th Centimeters
Human Interface Types	Touchscreen with Stylus Support

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included in your product packaging or visit the

official Redmi/Xiaomi website.

If you encounter issues not covered in this manual or require further assistance, please contact Redmi customer support. Support contact details can typically be found on the manufacturer's website or in the Quick Start Guide.

Online Resources:

- [Visit the Redmi Store on Amazon](#)
- [Xiaomi Global Support](#)