

Redmi Redmi Pad 2 Wi-Fi + Cellular

Redmi Pad 2 Wi-Fi + Cellular User Manual

Model: Redmi Pad 2 Wi-Fi + Cellular

1. INTRODUCTION

Welcome to the Redmi Pad 2 Wi-Fi + Cellular user manual. This guide provides essential information to help you get started with your new tablet, understand its features, and ensure optimal performance. Please read this manual thoroughly before using your device.

The Redmi Pad 2 offers a vibrant 2.5K display, powerful MediaTek Helio G100-Ultra processor, long-lasting 9000mAh battery, and supports an Active Pen for enhanced productivity and creativity. With HyperOS 2 and AI-powered features, your tablet experience is designed to be intuitive and efficient.



Image: An overview of the Redmi Pad 2's key features, including its 2.5K display, cellular connectivity, immersive audio, 9000mAh battery, HyperOS 2, AI-Powered capabilities, and MediaTek Helio G100-Ultra processor.

2. INITIAL SETUP

2.1 Unboxing and Package Contents

Your Redmi Pad 2 package should contain the following items:

- Redmi Pad 2 Tablet Computer
- Power Adapter
- USB Type-C Cable
- SIM Ejector Tool

2.2 Charging the Device

Before first use, fully charge your Redmi Pad 2. Connect the USB Type-C cable to the tablet's charging port and the power adapter, then plug the adapter into a wall outlet. The tablet supports 18W fast charging.

2.3 Powering On/Off

- **To Power On:** Press and hold the Power button until the Redmi logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options on the screen.

2.4 Inserting a SIM Card (Cellular Models)

For cellular connectivity, insert a nano-SIM card using the provided SIM ejector tool.

1. Locate the SIM card tray on the side of the tablet.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your nano-SIM card into the tray with the gold contacts facing down.
4. Carefully push the tray back into the tablet until it clicks into place.

Active Pen Support


Create Without Limits



Find Answers Instantly



Take Notes Effortlessly



Handwriting Recognition



Image: Side view of the Redmi Pad 2, illustrating the location of the SIM card tray and physical buttons.

2.5 Connecting to Wi-Fi

1. Go to **Settings > Wi-Fi**.
2. Toggle Wi-Fi on.
3. Select your desired network from the list.
4. Enter the password if prompted and tap **Connect**.

2.6 Google Account Setup

Follow the on-screen prompts to set up your Google account. This is necessary to access the Google Play Store, synchronize data, and use various Google services.

3. OPERATING YOUR REDMI PAD 2

3.1 Navigation and User Interface (HyperOS 2)

Your Redmi Pad 2 runs on HyperOS 2, based on Android, providing a smooth and intuitive user experience. Swipe gestures and on-screen buttons allow for easy navigation between apps and settings.

3.2 Display Features

Experience crystal-clear visuals on the 11-inch 2.5K (2560x1600 pixels) display with a 90Hz refresh rate for smooth scrolling and animations. The display offers up to 600 nits of brightness for clear visibility in various lighting conditions.



Image: The Redmi Pad 2's 2.5K Crystal Clear Display, highlighting its sharp resolution and vibrant color reproduction.

3.3 Audio Experience

The tablet features quad speakers with Dolby Atmos support, delivering an immersive audio experience for movies, music, and games.




Image: The Redmi Pad 2 demonstrating its immersive audio capabilities with quad speakers and Dolby Atmos technology.

3.4 Active Pen Support

The Redmi Pad 2 supports an Active Pen (sold separately) for precise input. Use it for note-taking, sketching, marking up documents, and navigating the interface with ultra-low latency and 4096 pressure sensitivity levels.

REDMI Smart Pen



Image: The Redmi Pad 2 demonstrating Active Pen support for creative tasks, instant answers, effortless note-taking, and handwriting recognition.

Xiaomi Interconnectivity

Call Sync

Take calls easily



across devices

Effortless Copy



**Shared
Clipboard**

Paste Across Devices

Image: A close-up of the Redmi Smart Pen in use, detailing its features such as seamless writing, millisecond-level latency, 4096 pressure sensitivity, 10g activation force, and 12 hours of continuous writing.

3.5 AI-Powered Features

Leverage AI capabilities like **Circle to Search** for instant information retrieval and **Gemini AI** for personalized assistance, enhancing productivity and entertainment.




Image: The Redmi Pad 2 demonstrating AI-powered features, specifically 'Circle to Search' for instant answers.

3.6 Camera Usage

The tablet is equipped with an 8MP rear camera and a 5MP front camera, suitable for video calls and casual photography. Video capture resolutions include FHD 1080p and HD 720p.

3.7 Storage and Performance

The Redmi Pad 2 comes with 8GB RAM and 256GB internal storage (UFS 2.2 for fast loads). Storage can be expanded up to 2TB using a microSD card (sold separately).




2

Xiaomi HyperOS

Clean UI Experience

Image: The Redmi Pad 2 highlighting its storage and RAM capabilities, including up to 16GB RAM, 256GB UFS 2.2 storage, and 2TB expandable storage.

Powered by the MediaTek Helio G100-Ultra processor, the tablet delivers efficient performance for multitasking, gaming, and media consumption.



Up to 16GB RAM*

LPDDR4X RAM at its Core. Smoothness at Your Fingertips.



Up to 256GB Storage

UFS 2.2: Fast Loads. Smooth Switches.



Expand Your World with

2TB Expandable Storage

Room to Power Through Work and Unwind with Entertainment

Image: A visual representation of the advanced MediaTek Helio G100-Ultra processor, emphasizing its performance capabilities.

3.8 Connectivity

Stay connected with Wi-Fi (802.11a/b/g/n/ac) and cellular connectivity. The tablet also features Bluetooth for connecting accessories and a USB 2.0 Type-C port for charging and data transfer.

Advanced Helio G100-Ultra



MediaTek
helio G100
ULTRA



80% Faster GPU Performance*

*Compared to Redmi Pad SE, Data tested by Xiaomi Internal Labs, actual results may vary

Image: The Redmi Pad 2 demonstrating its cellular connectivity, allowing users to stay connected anytime, anywhere.

4. MAINTENANCE AND CARE

4.1 Cleaning Your Tablet

Use a soft, lint-free cloth to clean the screen and body of your Redmi Pad 2. Avoid using harsh chemicals or abrasive materials that could damage the display or finish.

4.2 Battery Care

The 9000mAh battery provides extended usage. To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery drain completely before recharging frequently.
- Use the original charger and cable for optimal charging.

Tired of Chasing Answers across Apps?
Get Instant Answers.

AI[★]-Powered.



Image: The Redmi Pad 2 highlighting its XL 9000mAh battery, capable of providing up to 19 hours of binge-watching, 22 hours of discoveries, and 10 hours of gaming.

4.3 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings > About tablet > System update**.

4.4 Storage Optimization

Periodically review and delete unnecessary files, apps, and media to maintain optimal performance. Utilize cloud storage or the expandable storage option for large files.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Redmi Pad 2.

5.1 Device Not Powering On

- Ensure the battery is charged. Connect the tablet to the charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to perform a forced restart.

5.2 Connectivity Issues (Wi-Fi/Cellular)

- **Wi-Fi:** Check if Wi-Fi is enabled in settings. Restart your router. Forget the network and reconnect.
- **Cellular:** Ensure the SIM card is correctly inserted and activated. Check your mobile data settings. Restart the tablet.

5.3 Slow Performance

- Close unused applications running in the background.
- Clear cache data for apps.
- Ensure sufficient free storage space.
- Restart the tablet regularly.

5.4 Active Pen Not Responding

- Ensure the Active Pen is charged (if applicable).
- Check Bluetooth connection for the pen in tablet settings.
- Restart the tablet.

6. SPECIFICATIONS

Feature	Detail
Brand	Redmi
Model Name	Redmi Pad 2 Wi-Fi + Cellular
Operating System	Android, HyperOS 2
Processor	MediaTek Helio G100-Ultra (2.2 GHz)
Graphics Coprocessor	Mali-G57 MC2
RAM	8 GB
Internal Storage	256 GB
Expandable Storage	Yes (up to 2TB)
Screen Size	11 Inches (27.94cm)
Display Resolution	2560x1600 Pixels (2.5K)
Display Type	LCD

Feature	Detail
Refresh Rate	90 Hz
Maximum Brightness	600 Nits
Rear Camera	8 MP
Front Camera	5 MP
Battery Capacity	9000 mAh
Battery Average Life	10 Hours
Connectivity	Wi-Fi (802.11a/b/g/n/ac), Cellular
Human Interface	Touchscreen with Stylus Support
Audio Jack	3.5 mm
Dimensions (L x W x T)	25.5L x 16.6W x 0.7Th Centimeters
Item Weight	519 Grams
Color	Sky Blue

7. WARRANTY INFORMATION

The Redmi Pad 2 Wi-Fi + Cellular comes with a**1-year manufacturer warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included in your product packaging or visit the official Redmi website.

8. CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries, please contact Redmi customer support. You can find contact information on the official Redmi website or through the support section within your device's settings.

Manufacturer: BYD (India) Private Limited, Xiaomi

Manufacturer Contact Information: BYD (India) Private Limited, Developed Plot No. OZ 7, Sipcot, Oragadam, Sriperambudur, Kancheepuram, Tamil Nadu 602105, India

For online support, visit the official [Redmi India Support Page](#).

