

AUX

Connect with AUX Cable through AUX port into your phone and enjoy your favourite music with WH-83 Headphones.

SD CARD

Insert SD card into the card slot and music will start playing automatically.

TECHNICAL SPECIFICATIONS

- Bluetooth Version: V5.0+EDR
- Working Distance: Upto 10 meter
- Play/Talk time: Up to 6 hours
- Battery capacity: 130mAh
- Charging time: 2 hours
- Driver Unit: Ø40mm
- Impedance: 32Ω
- Frequency response: 2.4GHz~2.4835GHz
- FM Frequency: 87.5-108MHz

WARRANTY CARD & TERM & CONDITIONS

NOTE: For your warranty to be valid, all information on the warranty certificate has to be completed including with the original invoice.

All warranty information, product features and specifications are subject to change without prior notice. all matters are subject to Delhi Jurisdiction.

Customer's Name		Contact Number	
Customer's Address			
Model No.			
Name of Distributors/Dealers		Contact Number	
Address			
Purchase Date		Invoice Number	
Dealer's Stamp			

- WH-83 Wireless Headphones comes with 365 days warranty from date of purchase.
- In case the product is damaged by wrong operation or force majeure the warranty will be null and void.
- The warranty does not include accessories supplied with WH-83 Headphones.

Address: Plot No. 331, Sector-56, Phase V, EHTP, HSIIDC, Industrial Estate Kundli, Sonipat, Haryana-131028, India.
In case of complaint contact customer service for sales/ service support:

Contact No.: 011-45911111, +91-9599030613,

Web: www.ambraneindia.com,

E-mail: care@ambraneindia.com



"Listening at a high volume for a long time may damage your hearing."

AMBRANE



WIRELESS
FM RADIO



AUX CABLE
SUPPORT



SD CARD
SUPPORT



BUILT-IN
MIC

WH-83
WIRELESS HEADPHONES

USER MANUAL

WELCOME

Thank you for choosing AMBRANE WH-83 Wireless Headphones. Before using the product, please read the manual carefully and follow the instructions to operate properly.

PACKAGE CONTAINS

- 1x WH-83 Wireless Headphone
- 1x USB Charging Cable
- 1x User Manual+Warranty Card



WH-83
Wireless Headphones



User Manual



USB Charging
Cable

PRODUCT OVERVIEW



OPERATING INSTRUCTIONS

	Long press to turn ON/OFF the device. Short press to change the mode: Bluetooth/FM Radio/SD Card.
	Short press to Play/Pause the music. In bluetooth mode, short press to answer the call and long press to reject.
	Short press to change to next track/station, long press to increase the volume
	Short press to change to previous track/station, long press to decrease the volume

	Insert SD Card, Play music files
	Audio input via AUX to Headphone
	Connect the charger for charging

HOW TO PAIR

STEP 1:



Press & Hold the Power Button until LED flashes Green & Blue alternately.

STEP 2:



Search "WH-83" on Bluetooth and click it.

FM MODE

Press The "⏻" (Power Button) repeatedly until it shifts to FM Mode, Long press & release The "▶|◀" (Play/PauseButton) to set FM Station Frequencies. Use "+" and "-" Buttons to switch between the FM stations. Short press the "▶|◀" (Play/Pause Button) to mute and resume.

LED INDICATOR

- **Bluetooth Mode:** Blue light blinks at the time of pairing. On successful connection blue light flashes constantly
- **SD Card:** Blue light flashes while playing via SD Card
- **FM Mode:** Blue light flashes while playing on radio mode
- **Charging mode:** Red light flashes while charging and turns off automatically on full charge.