

Manuals.plus / > boAt / > boAt Airdopes 213 TWS Earbuds User Manual

boAt Airdopes 213

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

boAt Airdopes 213 TWS Earbuds User Manual

Model: Airdopes 213 (PA0028)

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your boAt Airdopes 213 True Wireless Stereo (TWS) Earbuds. Please read this guide thoroughly before using the product.



Image: The boAt Airdopes 213 TWS Earbuds in Berry Blue, showcasing their compact design.

SETUP

1. Unboxing and Initial Charge

Carefully remove the earbuds and charging case from the packaging. Inside the box, you will find the Airdopes 213 earbuds, the charging case, and a charging cable.




Image: The boAt Airdopes 213 charging case in a closed position.

Before first use, fully charge the earbuds and the charging case. Connect the charging cable to the case and a power source. The LED indicator on the case will show charging status. A full charge provides up to 50 hours of total playback time. For quick power, 5 minutes of ASAP Fast Charging provides approximately 140 minutes of playtime.

 boAt Airdopes 213 charging case with 50 hours playtime text

Image: The boAt Airdopes 213 charging case highlighting its 50 hours total playtime and ASAP charging capability.

2. Pairing with a Device

1. Open the lid of the charging case. The earbuds will automatically enter pairing mode (IWP™ Technology).
2. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings.
3. Search for "Airdopes 213" in the list of available devices and select it to connect.
4. Once connected, you will hear an audio prompt, and the LED indicator on the earbuds will change.

 Smartphone screen showing boAt Airdopes 213 connected via Bluetooth

Image: A smartphone displaying the boAt Airdopes 213 as a connected Bluetooth device, illustrating IWP Technology.

3. boAt Hearables App

Enhance your experience by downloading the boAt Hearables App. The app provides additional features and a user help guide.

Advertisements

 [QR code to download boAt Hearables App](#)

Image: A smartphone screen displaying a QR code for the boAt Hearables App. Scan this QR code to download the app.

Link: [Download boAt Hearables App](#)

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Open the charging case lid. The earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Advertisements

2. Touch Controls

The Airdopes 213 feature intuitive touch controls on each earbud.

 Close-up of an earbud showing the touch control area

Image: A close-up view of an earbud, indicating the touch-sensitive control area.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Long press on either earbud during an incoming call.

- **Activate Voice Assistant:** Triple tap on either earbud.
- **Toggle Beast Mode:** Long press on the right earbud for 2 seconds.

Advertisements

3. Calling with ENx™ Technology

The Airdopes 213 are equipped with ENx™ Technology and dual microphones for clear voice calls, reducing environmental noise.

 Woman wearing boAt Airdopes 213 earbuds, illustrating ENx Technology

Image: A woman wearing boAt Airdopes 213 earbuds, demonstrating the use of ENx Technology for clear calls.

4. Beast Mode™ for Low Latency

Activate Beast Mode™ for an ultra-low latency experience (45ms), ideal for gaming and video streaming to ensure synchronized audio and visuals.

Advertisements

 Gaming scene with a robot, representing Beast Mode low latency

Image: A dynamic gaming scene featuring a robot, symbolizing the low-latency Beast Mode for an enhanced gaming experience.

MAINTENANCE

1. Cleaning

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts are clean and free of debris.

2. Water and Sweat Resistance (IPX4)

The Airdopes 213 are IPX4 rated, meaning they are resistant to splashes and sweat. This makes them suitable for workouts and light rain. However, they are not waterproof and should not be submerged in water.

Advertisements

boAt Airdopes 213 earbuds with water droplets, indicating IPX4 rating

Image: boAt Airdopes 213 earbuds with visible water droplets, demonstrating their IPX4 splash and sweat resistance.

3. Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid to activate pairing mode. Check your device's Bluetooth settings and try reconnecting.
- **Only one earbud working:** Place both earbuds back in the case, close the lid, wait a few seconds, then open it again. This often re-syncs them.
- **No sound:** Check the volume on your connected device. Ensure the earbuds are properly paired and selected as the audio output.
- **Charging issues:** Verify the charging cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and inside the case.
- **Resetting the Airdopes 213:** If you encounter persistent issues, perform a factory reset. Consult the boAt Hearables App or the official boAt support website for specific reset instructions for your model.

Advertisements

SPECIFICATIONS

Model Name	Airdopes 213
Model Number	PA0028
Brand	boAt
Ear Placement	In Ear
Form Factor	In Ear

Connectivity	Bluetooth (Wireless Technology Type)
Audio Driver Type	Dynamic Driver (10 MM Drivers)
Control Method	Touch
Battery Life	Up to 50 Hours (Total Playback)
Fast Charging	ASAP Charge (5 mins = 140 mins playtime)
Low Latency	Beast Mode (45ms)
Call Technology	ENx™ Technology (Dual Mics)
Water Resistance	IPX4 (Splash & Sweat Resistant)
Weight	60 Grams
Box Contents	Earbuds, Charging Case, Cable

Diagram of boAt Signature Sound 10mm driver

Image: An exploded view diagram illustrating the components of the boAt Signature Sound 10mm dynamic driver.

WARRANTY INFORMATION

The boAt Airdopes 213 comes with a **1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the official boAt website or contact customer support.

CUSTOMER SUPPORT

For any queries, technical assistance, or warranty claims, please contact boAt customer support:

Advertisements

- **Email:** info@imaginemarketingindia.com
- **Manufacturer:** Imagine Marketing Ltd
- **Online Support:** Refer to the boAt Hearables App for a user help guide or visit the official boAt website.