ROCKERZ PLUS 550 ANC
SMART GUIDE

PACKAGE CONTENTS



PRODUCT LABELLING



Volume +/ Next Track Button
Volume -/ Previous Track Button
ANC Button
LED Indicator
Microphone
USB Type-C Charging Port
AUX Port
Power Button/MFB (Multifunction Button)

POWER ON/OFF

- Press & Hold (2 Sec)
- Press & Hold (4 Sec)



BLUETOOTH PAIRING



Choose "Rockerz Plus 550 ANC" to Connect

MODES OF NOISE CONTROL

● Press 1 Time



Short press the ANC button to activate ANC mode. Short press the ANC button again to deactivate ANC mode and switch to Normal (ANC OFF) mode.

Note:
1. By default, the Normal (ANC Off) mode is active.
2. The operational cycle is Ambient Mode → ANC Mode → Normal Mode (ANC OFF).
3. Your headphones will remember the mode you last used & will enable the respective noise cancellation mode when they are powered on next time.
4. When you activate ANC or Ambient modes, the headphones will consume more power which will reduce the playtime.

FUNCTIONS (CALL/MUSIC/VOLUME)

- ● Short Press
- ●● Double Press
- Press & Hold (1s)
- Press in Steps



Note: The headphones may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the headphones.

FUNCTIONS (BEAST™ MODE / VOICE ASSISTANT)

- ●● Press 2 Times
- ●●● Press 3 Times



R
ACTIVATE/DEACTIVATE GAMING BEAST™ MODE
●●
ACTIVATE GOOGLE VOICE ASSISTANT/SIRI
●●●

BEAST™ Mode: Press the MFB 2 times to activate low-latency BEAST™ Mode. Press the MFB 2 times again to switch to boAt Signature Sound.

Voice Assistant: Press the MFB 3 times to activate the default smart voice assistant (Google Voice Assistant/Siri).

Note:
boAt Signature Sound remains on by default.
- If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.
- The headphones may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the headphones.

HEARABLES APP COMPATIBILITY

Discover the following features of your Rockerz only on the Hearables App-

- ✓ Activate/Deactivate Noise Cancellation Modes
- ✓ Battery and Connectivity Status
- ✓ Smart Diagnostics Mode



RESET ROCKERZ

Long Press (4 sec)

FORGET DEVICE



PRESS AND HOLD THE VOLUME (+) AND VOLUME (-) BUTTONS SIMULTANEOUSLY FOR 4 SECONDS TO CLEAR THE LIST OF PAIRED DEVICES.



PERFORM FRESH CONNECTION



Congratulations! Your Rockerz Plus 550 ANC has been reset.

Note: Pink LED blinks 3 times on the headphones to indicate successful reset.

LED STATUS GUIDE

✹	<20%: RED LED FLASHES	▯	LOW BATTERY
✹	SOLID RED LED	▯	CHARGING
☼	100%: SOLID WHITE LED	🟩	FULLY CHARGED

SPECIFICATIONS

Headphone Type	ANC Bluetooth Headphones
Driver Size	40 mm*2
Bluetooth Version	5.4
Active Noise Cancellation	Up to 40dB (Hybrid ANC)
THD	≦3% at 1kHz
Music Playtime	Up to 80 hours (Non-ANC Mode); Up to 57 hours (ANC Mode); (at 60% volume)
ENx™ Technology	Yes
BEAST™ Mode	Yes; 40 ms Low Latency
Transmission Range	10 m
Signal-to-Noise Ratio	≧90dB
Frequency	20 Hz-20 kHz
Battery	800 mAh
Charging Time	Up to 2.5 hours
Charging Interface	Type-C
Charging Voltage	5V

CHARGING GUIDELINES

Charging norms & Precautionary Guidelines: -	
1) Charger/Brick/Adapter	: 5V/2A
Any other accessory can be used to charge the product as long as the above-mentioned norms are followed.	

Note: (1) Before using the headphones for the first time, it is recommended to fully charge them.
(2) Please note that the headphones cannot be used / switched on while charging.

LEARN MORE ABOUT YOUR PRODUCT

Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information