

[Skip to content](#)

[Manuals+](#)

User Manuals Simplified.



iGear iG-1021 Camo Portable Wireless Speaker User Manual

May 25, 2022 May 25, 2022 [Leave a comment on iGear iG-1021 Camo Portable Wireless Speaker User Manual](#)

[Home](#) » [iGear](#) » iGear iG-1021 Camo Portable Wireless Speaker User Manual 

iGear iG-1021 Camo Portable Wireless

Speaker User Manual

Camo

Playing the mood

iG
iGear
innovation. delight



Model No.: iG-102

Contents [hide](#)

[1 SPECIFICATIONS](#)

[2 ACCESSORIES](#)

[3 CONNECT TO BLUETOOTH DEVICE](#)

[4 BLUETOOTH](#)

[5 TWS OPERATION:](#)

[6 AUX-IN](#)

[7 USB / TF CARD](#)

[8 FM RADIO](#)

[9 CHARGING](#)

[10 Documents / Resources](#)

SPECIFICATIONS

Wireless version: 5.0
Speaker driver unit size: 4 INCH
Output power: 5W
Frequency response: 100Hz-20KHz
Signal to noise ratio: >=85dB
FM scan range: 87.5-108.0Mhz
Wireless range: 10 meter
Max memory USB/SD: 32GB
USB charging: DC 5V
Battery capacity: 1200mAh
Backup time via wireless mode: Approx 1.5-2 hours at max volume
Backup time via USB mode: Approx 1.5-2 hours at max volume
Charging via USB port (PC): 2-3 hours charging time

ACCESSORIES

Charging cable: 1 piece;
Belt: 1 piece;

CONNECT TO BLUETOOTH DEVICE

Turn on the unit and switch on your mobile Bluetooth, then search for the name 'iGear Camo' and pair the device. Once device is paired, Bluetooth will automatically connect when unit is turned on subsequently.



1. POWER OFF/ON: To turn ON/OFF the speaker.
2. DC 5V: Plug the Micro USB cable to the speaker and connect other end USB port to the power source. (DC 5V) – AUX: Aux-in jack.
3. USB slot: Used to read the MP3 files in USB drive, maximum size supported is 32GB.
4. TF slot: Used to read the MP3 file in TF/SD card, maximum size supported is 32GB.
5. Play/Pause: Under USB/TF/Bluetooth mode, short press for play and pause.
6. M: To change mode during USB/TF, Bluetooth, FM and Aux-in mode.
7. PREV: USB/TF/Bluetooth/FM mode: Press to change to previous FM channel/Track long press to decrease the volume.
8. NEXT: USB/TF/Bluetooth/FM mode: Press to change to next FM channel / track. long press to increase the volume.
9. Torch

NOTE: If FM mode reception is not good, connect a Micro USB cable for better FM reception.

BLUETOOTH

Turn on the speaker, it come into the Bluetooth mode directly. After pairing, the device can play music. Short press to Play/Pause, Short press or to surf through Prev or Next track. Long press or to increase or decrease the volume.

TWS OPERATION:

1. Turn on both the speakers at the same time.
2. Choose one of them, on one of the speaker press and hold the "M" button for a few seconds, then a notification sound will indicate of pairing.

Note: TWS works in Bluetooth Mode only

AUX-IN

Insert the AUX cable into AUX jack, and press 'M' to switch to AUX-IN mode. Long press or to increase or decrease the volume. In AUX mode, track cannot be changed using the speaker buttons.

USB / TF CARD

Insert the USB / TF card into the USB / TF slot. It will read the MP3 format music automatically. Press to Play/Pause. Short Press or to switch to Prev or Next Song. Long press or to increase or decrease the volume.

FM RADIO

Long press the Play/Pause button, it will search for the available stations and save them automatically. Once the search is completed, Short press the or button to switch between the saved stations. Long press or to increase or decrease the volume. NOTE: AUX Port connection can receive FM signal clearly as it has the same function as the antenna.

CHARGING

Please use the original charging cable to charge. Red LED display when on charging.

Imported and Marketed By:
iGear Tech Pvt. Ltd.
204, Sai Corporate Park,
Laxmi Nagar, Off Link Road,
Goregaon West, Mumbai – 400104.
In case of consumer complaints:
Toll free number – 1800 22 8495
Email: sales@igear.asia
(Between 10am to 5pm, Mon- Fri)

Documents / Resources



[iGear iG-1021 Camo Portable Wireless Speaker \[pdf\] User Manual](#)
iG-1021, Camo Portable Wireless Speaker

Related Manuals / Resources

[iGear iG-1063 Be Dazzle Flame Atmosphere Speaker User Manual](#)

iG-1063 Be Dazzle Flame Atmosphere Speaker BeDazzle Flame Atmosphere Speaker Model No.: iG-1063 Brand: iGear Model No.: iG-1063...

[iGear iG-1118 Elite Wireless Charger with Power Bank User Manual](#)

iG-1118 Elite Wireless Charger with Power Bank Elite Wireless Charger with Power Bank Model No.: iG-1118



[SVS Prime Wireless Speaker Manual](#)

SVS Prime Wireless Speaker Manual - Download [optimized] SVS Prime Wireless Speaker Manual - Download

[iGear iG-A1C Night Ingale Flame Light Speaker User Manual](#)

iG-A1C Night Ingale Flame Light Speaker Night Ingale Flame Light Speaker Model No.: iG-A1C Technical parameters Version V4.2...

Leave a comment

Your email address will not be published.

Comment

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

[Manuals+](#)

- [home](#)
- [privacy](#)