


MEET YOUR FIRE TV STICK 4K PLUS



Also included:




Tip: we recommend using 1.5 V AAA alkaline batteries in your Alexa Voice Remote for a steady performance.

MEET YOUR ALEXA VOICE REMOTE




CONNECT YOUR FIRE TV STICK 4K PLUS



- 1 Plug your Fire TV Stick 4K Plus into your TV's HDMI port and connect one end of the power cable to your stick.
- 2 Connect the other end of the power cable to the power adaptor, then plug the adaptor into an electrical socket.

SET UP YOUR REMOTE



- 1 Press and hold your thumb on the arrow to release the latch.
- 2 Make sure you **a** press the arrow firmly to release the latch as you **b** slide the cover off.
- 3 Insert included AAA alkaline batteries.

Note: If it didn't pair, press and hold Home **c** for 10 seconds.

HELPFUL TIPS



If your new remote does not connect, remove and reinsert the AAA alkaline batteries.

Caution: always replace dead batteries with new 1.5 V alkaline or 1.2 V NiMH rechargeable AAA batteries.



Use your Alexa Voice Remote with your Fire TV Stick 4K Plus to search for and enjoy thousands of films, TV shows, apps and games.

Optional: use the included HDMI extender if it's difficult to plug your Fire TV Stick 4K Plus into your TV's HDMI port.

- 3 Turn on your TV and switch to the appropriate HDMI input.

Tip: use the remote that came with your TV to select the HDMI source or input.



Scan for more help

Scan the QR code or visit:
amazon.com/setup/firetvstick4kplus
