

manuals.plus › Nikon

› Instruction Manual: Nikon Z 24-120mm f/4 S Lens Grip Rubber Repair Part

Nikon Z 24-120mm f/4 S

Sign in to save this manual

Sign in to bookmark this manual and keep private notes.

Instruction Manual: Nikon Z 24-120mm f/4 S Lens Grip Rubber Repair Part

Model: Z 24-120mm f/4 S

1. INTRODUCTION

This manual provides instructions for the installation and maintenance of the grip rubber repair part for the Nikon Z 24-120mm f/4 S lens. This high-quality replacement part is designed to restore the original feel and functionality of your lens's grip.

RepairMan



For Nikon Z 24-120 LENS

Figure 1: Nikon Z 24-120mm f/4 S Lens Grip Rubber Repair Parts (Small and Large)

2. PRODUCT COMPONENTS

The grip rubber repair part is available in different configurations:

- **A Only small rubber:** The smaller grip rubber for a specific section of the lens.
- **B Only big rubber:** The larger grip rubber for another section of the lens.
- **A and B:** A complete set including both the small and big rubber grips.



Figure 2: Available Grip Rubber Options (A: Small, B: Large)

3. INSTALLATION INSTRUCTIONS

Replacing the lens grip rubber requires careful handling. It is recommended that this procedure be performed by individuals with experience in camera equipment repair or by a professional technician.

1. **Preparation:** Ensure your workspace is clean, well-lit, and free of dust. Gather necessary tools such as a small screwdriver set (if required for removing old adhesive), a spudger, and a cleaning solution (e.g., isopropyl alcohol) for residue removal.

2. **Remove Old Grip:** Carefully peel off the old, damaged grip rubber from the lens barrel. If it's adhered strongly, gently use a spudger to lift the edges.
3. **Clean Surface:** Thoroughly clean the lens barrel surface where the new grip will be applied. Remove any remaining adhesive residue, dirt, or oils using isopropyl alcohol and a lint-free cloth. Allow the surface to dry completely.
4. **Position New Grip:** Take the new grip rubber (either 'A Only small rubber', 'B Only big rubber', or both from the 'A and B' set) and carefully align it with the corresponding section on the lens barrel.
5. **Apply Grip:** Starting from one end, gently press the new grip rubber onto the lens barrel, ensuring even adhesion and no air bubbles. Work your way around the circumference of the lens.
6. **Secure (if applicable):** If the new grip has an adhesive backing, ensure firm and even pressure is applied across its entire surface.
7. **Final Check:** Inspect the newly installed grip to ensure it is securely attached, properly aligned, and feels comfortable.





Figure 3: Individual Grip Rubber Parts for Installation

4. OPERATING THE LENS WITH NEW GRIP

Once installed, the new grip rubber functions identically to the original. It provides enhanced tactile feedback and a secure hold when adjusting the lens's focus or zoom rings. No special operating procedures are required.

5. CARE AND MAINTENANCE

- **Cleaning:** To clean the grip rubber, use a soft, damp cloth. For stubborn dirt, a small amount of mild soap or a lens cleaning solution can be

applied to the cloth, then wipe the grip. Avoid harsh chemicals or abrasive materials.

- **Storage:** When not in use, store your lens in a clean, dry environment, away from direct sunlight and extreme temperatures, to prolong the life of the rubber grip.
- **Avoid Damage:** Prevent sharp objects from coming into contact with the grip rubber to avoid cuts or tears.

6. TROUBLESHOOTING

If you encounter any issues after installing the grip rubber, consider the following:

- **Grip feels loose:** Ensure the lens surface was thoroughly cleaned before installation. Re-apply pressure evenly across the grip. If the issue persists, the adhesive may not have bonded correctly, or the grip might be slightly misaligned.
- **Grip does not fit:** Double-check that you have purchased the correct grip rubber model for your Nikon Z 24-120mm f/4 S lens.

For further assistance, please contact customer support or a professional repair team.

7. SPECIFICATIONS

Feature	Detail
Model Number	Z 24-120mm f/4 S
Compatible Brand	Nikon
Compatible Camera Style	Nikon Z-mount Lenses / Mirrorless Cameras
Material	Rubber
Condition	99.99% New, Tested and Working

Feature	Detail
Package Included	Yes
High-concerned chemical	None
Origin	Mainland China
Package Dimensions (L x W x H)	15 cm x 14 cm x 13 cm
Package Weight	0.05 kg

8. WARRANTY AND SUPPORT

- **Warranty Period:** This product comes with a 3-month warranty from the date of purchase.
- **Support:** A professional repair team is available to answer your questions regarding this product. For technical assistance or warranty claims, please refer to the seller's contact information.

Attention:

- This Rubber is **original**.
- Function working perfectly.
- Condition 99.9999% NEW!

Why Choose us?

1. High quality product (We will check and test the item before sending)
2. The appearance of the item: What you see is what you get.
3. Fast delivery (The product will be sent within 1 working day)
4. Warranty Period: 3 Months
5. Return: If you are not satisfied with the item, you can return it.
6. Answer: A professional repair team is available to answer your questions.

Figure 4: Important Product Information

9. USER TIPS

- **Model Verification:** Always ensure you select the correct grip rubber model for your specific lens to guarantee a perfect fit and optimal performance.

Related Documents - Z 24-120mm f/4 S

	Nikon NIKKOR Z 24-120mm f/4 S Lens Reference Guide This reference guide provides essential information for the Nikon NIKKOR Z 24-120mm f/4 S lens, covering safety precautions, usage instructions, maintenance, specifications, and accessories. Learn how to attach, remove, and care for your lens to ensure optimal performance.
	Wade Logan Brisna Bed Frame Assembly Instructions Comprehensive assembly guide for the Wade Logan Brisna Bed frame, featuring a detailed parts list, accessory breakdown, and step-by-step visual instructions for easy setup. This manual provides all necessary information for assembling the furniture safely and correctly.
	Latitude Run® Adriel Makeup Vanity with Lights and 11 Drawers Assembly Instructions Comprehensive assembly instructions for the Latitude Run® Adriel Makeup Vanity, featuring lights and 11 drawers. Includes parts list, accessories, and step-by-step guidance for building your vanity.
	Vello BG-N22 Battery Grip User Manual for Nikon Z 6II/Z 7II Cameras Comprehensive user manual for the Vello BG-N22 Battery Grip, designed for Nikon Z 6II and Z 7II mirrorless cameras. Provides detailed instructions on attachment, battery insertion and removal, hot-swapping, in-grip charging, technical specifications, and warranty information.
	Vello BG-N23 Battery Grip User Manual for Nikon Z8 Mirrorless Camera Comprehensive user manual for the Vello BG-N23 Battery Grip, designed specifically for the Nikon Z8 mirrorless camera. Learn how to attach, insert batteries, charge, and use the grip's features. Includes detailed specifications and a one-year limited warranty.
	Lens Safety Precautions and Handling Guide Essential safety guidelines for handling and storing lenses to prevent damage and ensure user safety. Covers direct sunlight exposure, moisture, cleaning, and disassembly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

NIKON Z 24-120MM F/4 S

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Nikon Z 24-120mm f/4 S r

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

Privacy Policy · DMCA