

Fujifilm FUJI INSTAX MINI SE LAVENDER

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Fujifilm Instax Mini SE Instant Camera User Manual

Model: FUJI INSTAX MINI SE LAVENDER | Brand: Fujifilm

Advertisements

INTRODUCTION

The Fujifilm INSTAX Mini SE Camera is designed for capturing and instantly printing memorable moments. This compact and stylish instant camera is perfect for both travel and everyday use, delivering good quality photos, especially in natural light. This manual provides essential information for setting up, operating, and maintaining your camera.



Figure 1: Front angled view of the Fujifilm Instax Mini SE camera, showcasing its compact design.

Advertisements

WHAT'S IN THE BOX

- Fujifilm INSTAX Mini SE Instant Camera Body
- Camera Case
- Photo Album
- INSTAX Mini Instant Film Pack (10 sheets)
- Sticker Frames (20 pieces)
- AA Batteries (4 included)

SETUP

1. Battery Installation

Locate the battery compartment on the side of the camera. Open the cover and insert four AA batteries, ensuring correct polarity (+/-). Close the battery compartment cover securely.



Figure 2: Side view of the camera, indicating the battery compartment.

2. Film Loading

Open the film compartment door on the back of the camera. Align the yellow mark on the film pack with the yellow mark on the camera. Insert the film pack straight into the compartment. Close the film compartment door. The film counter will display 'S' (Start) and then '10' after the first dark slide is ejected upon turning on the camera.



Figure 3: Rear view of the camera, showing the film compartment.

OPERATING THE CAMERA

1. Turning On/Off

To turn on the camera, press the power button located next to the lens. The lens will extend. To turn off, gently push the lens back into the camera body.

2. Taking Photos



Figure 4: Front view of the camera, showing the lens and shutter button

After taking a photo, the film will automatically eject from the top slot of the camera. Allow the photo to develop for a few minutes in a warm, dark place for optimal results.

MAINTENANCE

Cleaning

Gently wipe the camera body with a soft, dry cloth. For the lens, use a lens cleaning cloth. Avoid using abrasive cleaners or solvents. Keep the film ejection slot clear of debris.

Advertisements

Storage

Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Camera not turning on:** Check if the batteries are inserted correctly and are not depleted. Replace with new AA batteries if necessary.
- **Film not ejecting:** Ensure there is film loaded in the camera and that the film compartment door is securely closed. Check the film counter to see if it indicates film remaining.
- **Photos are too dark/light:** The camera has automatic exposure. Ensure the flash is not covered and that you are shooting in appropriate lighting conditions. Natural light often yields the best results.
- **Blank photos:** This may indicate an issue with the film pack or the camera's internal mechanism. Try a new film pack.

If problems persist, please contact Fujifilm customer support.

Advertisements

SPECIFICATIONS

Feature	Detail
Brand	Fujifilm
Model Name	Instax Mini SE
Item Model Number	FUJI INSTAX MINI SE LAVENDER
Film Format Type	Instax Mini

Shutter Type	Mechanical
Batteries	4 AA batteries (included)
Item Weight	1.23 pounds (0.56 Kilograms)
Package Dimensions	6.34 x 5.59 x 3.9 inches

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Fujifilm website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.
Official Fujifilm Website: www.fujifilm.com

Advertisements

© 2024 Fujifilm. All rights reserved.

Advertisements

Advertisements

Related Documents - FUJI INSTAX MINI SE LAVENDER

	Fujifilm Instax Mini LiPlay Hybrid Instant Camera User's Guide This user's guide provides comprehensive instructions for operating the Fujifilm Instax Mini LiPlay Hybrid Instant Camera, covering setup, shooting, playback, printing, and troubleshooting.
	FUJIFILM instax SQUARE SQ 40 Instant Camera User Guide and Safety Precautions User guide and safety precautions for the FUJIFILM instax SQUARE SQ 40 instant camera. Learn about setup, operation, taking photos, selfie mode, and essential safety advice.
	Fujifilm instax SQUARE Link Smartphone Printer User's Guide