

Whirlpool IFPRO BM INV CNV 340

Whirlpool IFPRO BM INV CNV 340 Refrigerator User Manual

Model: IFPRO BM INV CNV 340

1. IMPORTANT SAFETY INFORMATION

Read all instructions before using the appliance. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury.

- Ensure the refrigerator is properly grounded.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Disconnect the appliance from the power supply before performing any maintenance or cleaning.

2. SETUP AND INSTALLATION

2.1 Unpacking

Carefully remove all packaging materials, including tape and protective films. Dispose of packaging responsibly. Check for any damage during transit. If damage is found, contact your retailer immediately.

2.2 Placement

Place the refrigerator on a firm, level surface away from direct sunlight, heat sources (like stoves, radiators), and moisture. Ensure adequate air circulation around the appliance. Maintain a minimum clearance of 10 cm from the back and sides for proper ventilation.



Image: Whirlpool refrigerator in a kitchen environment, demonstrating suitable placement.

2.3 Dimensions

Refer to the diagram below for product dimensions to ensure proper fit in your space.



Image: Front view of the Whirlpool refrigerator with labeled dimensions (Height: 169.1 cm, Width: 63.2 cm, Depth: 71.1 cm).

Product Dimensions (D x W x H): 63.2D x 71.7W x 169.1H Centimeters

2.4 Leveling

Adjust the leveling feet at the bottom of the refrigerator to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.

2.5 Electrical Connection

Connect the refrigerator to a dedicated 230 Volt AC power outlet. This appliance features stabilizer-free operation within a voltage range of 115V-305V, protecting it from voltage fluctuations. Do not use extension cords or adapters.

2.6 Initial Startup

After plugging in, allow the refrigerator to run for at least 2-4 hours before placing food inside. This allows the internal temperature to stabilize.

3. OPERATING INSTRUCTIONS

3.1 External UI Touch Panel

Your refrigerator is equipped with an external user interface touch panel for easy control of settings without opening the door.



Image: Detail of the external UI touch panel on the refrigerator door.

3.2 Temperature Control (Adaptive Intelligence Technology)

The Adaptive Intelligence Technology continuously monitors and adjusts the internal temperature based on external weather conditions, the amount of food stored, and your usage patterns. This ensures optimal cooling and freshness.

3.3 Key Features

- **Uniform Cooling with 3D Airflow Technology:** Ensures consistent temperature distribution throughout the refrigerator compartments.
- **15 Days of Extended Freshness:** Designed to keep fruits and vegetables fresh for longer periods.
- **7 Days of Dairy Freshness:** Specific zone for dairy products to maintain their freshness.

- **Cooling Retention:** Maintains cooling for extended periods during power outages.
- **Portable Ice Tray:** Convenient for making and serving ice.
- **Convertible Freezer:** Allows flexibility to convert the freezer compartment for additional refrigeration space when needed.
- **Frost Free Defrost System:** Eliminates the need for manual defrosting.
- **Super Silent Operation:** Operates at a low noise level of 36dB.



**UNIFORM COOLING WITH
3D AIRFLOW TECHNOLOGY**



**UP TO 15 DAYS OF
EXTENDED FRESHNESS**



**UP TO 99%
BACTERIA PREVENTION**



**UP TO 7 DAYS OF
DAIRY FRESHNESS**

Image: Visual representation of key features including uniform cooling, extended freshness for produce and dairy, and bacteria prevention.



Image: Interior view of the refrigerator, showcasing the layout of shelves, door bins, and the 'Garden Fresh' drawer.



Image: Close-up of the 'Garden Fresh' drawer, designed for optimal storage of fruits and vegetables.

4. MAINTENANCE AND CLEANING

4.1 General Cleaning

Always unplug the refrigerator before cleaning. Clean the interior and exterior surfaces regularly with a mild detergent and warm water. Wipe dry with a soft cloth. Avoid abrasive cleaners or harsh chemicals.



Image: Interior view of the refrigerator with shelves and drawers, illustrating components that require regular cleaning.

4.2 Cleaning Condenser Coils

Periodically clean the condenser coils located at the back or bottom of the refrigerator. Dust and debris can accumulate, reducing efficiency. Use a vacuum cleaner or a soft brush to remove buildup.

4.3 Door Gaskets

Clean door gaskets regularly to ensure a tight seal. A dirty or damaged gasket can lead to inefficient cooling and increased energy consumption.

5. TROUBLESHOOTING

Before contacting customer service, review the following common issues and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Refrigerator does not operate	No power supply; power cord unplugged; circuit breaker tripped.	Check power connection; reset circuit breaker.
Temperature is not cold enough	Door left open; excessive food load; poor ventilation; temperature setting too high.	Ensure door is closed; reduce food load; check ventilation; adjust temperature setting.
Unusual noises	Appliance not level; items vibrating inside; normal compressor operation.	Level the appliance; rearrange items; some operational noises are normal.
Water on floor	Drain tube clogged; excessive humidity.	Clear drain tube; ensure proper door sealing.

6. SPECIFICATIONS

Feature	Detail
Brand	Whirlpool
Model Name	IFPRO BM INV CNV 340
Capacity	285 Liters
Fresh Food Capacity	215.2 Liters
Freezer Capacity	65.7 Liters
Energy Rating	2 Star (as per BEE 2023 guidelines)
Annual Energy Consumption	257 Kilowatt Hours
Defrost System Type	Frost Free
Configuration	Standard Double Door, Freezer Top
Product Dimensions (D x W x H)	63.2D x 71.7W x 169.1H Centimeters
Item Weight	64000 Grams
Voltage	230 Volts
Stabilizer Free Operation	Yes (115V-305V)
Inverter Type	Has Inverter
Number of Doors	2
Number of Shelves	3
Refrigerant	R-600A
Product Finish Type	Steel
Lock Type	Electronic
Smart Home Compatibility	Not Smart Home Compatible

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This Whirlpool refrigerator comes with a **1 Year Comprehensive Warranty** on the entire appliance and an additional **9 Years Warranty on the Compressor** from the date of purchase.

7.2 Customer Support

For any service, support, or warranty claims, please contact Whirlpool customer service:

Manufacturer: Whirlpool of India Limited

Address: Plot No. A-4, MIDC Ranjangaon, Taluka Shirur, Dist: Pune, Maharashtra 412220, India

Email: helpdeskindia@whirlpool.com

Toll Free: 1800 208 1800

7.3 Included Components

Upon purchase, the package includes:

- 1 Refrigerator Unit
- 1 Instruction Manual (this document)
- 1 Warranty Card