



Manuals.plus / > IFB / > IFB 6 Kg 5 Star Fully-Automatic Front Loading Washing Machine (EVA ZX) User Manual

IFB EVA ZX

Sign in to save this manual

Sign in to bookmark this manual and keep private notes.

IFB 6 Kg 5 Star Fully-Automatic Front Loading Washing Machine (EVA ZX) User Manual

Model: EVA ZX

Advertisements

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your IFB 6 Kg 5 Star Fully-Automatic Front Loading Washing Machine, model EVA ZX. Please read these instructions carefully before using the appliance and retain them for future reference.



Image 1.1: Front view of the IFB EVA ZX Washing Machine.



2. SAFETY INSTRUCTIONS

Observe the following safety precautions to prevent damage to the appliance or injury to yourself and others:

- Ensure the washing machine is installed on a stable, level surface.
- Do not allow children to play with or operate the appliance.
- Keep packaging materials out of reach of children.
- Do not overload the machine beyond its 6 kg capacity.
- Always unplug the appliance before cleaning or performing maintenance.
- Do not operate the machine if the power cord or plug is damaged.
- Ensure proper water supply and drainage connections are made according to installation guidelines.

Advertisements



3. WHAT'S IN THE BOX

Upon unpacking, verify that all the following components are present:

- 1 Washing Machine
- User Manual
- Water Inlet Pipe

- Drain Hose
- Protective Rat Mesh

Advertisements

4. INSTALLATION

The IFB EVA ZX washing machine is designed for freestanding installation. Proper installation is crucial for optimal performance and safety.

4.1 Unpacking and Placement

Carefully remove all packaging materials. Position the machine on a firm, level floor. Ensure there is adequate space around the machine for ventilation and access.

4.2 Water Connection

Connect the provided water inlet pipe to a cold water tap and to the designated inlet on the back of the washing machine. Ensure all connections are tight to prevent leaks.

Advertisements

4.3 Drain Connection

Attach the drain hose to the machine's drain outlet and route it to a suitable drain point, ensuring it is securely fixed and allows for proper water flow without kinks.

4.4 Leveling

Adjust the machine's feet to ensure it is perfectly level. This minimizes vibration and noise during operation.

4.5 Protective Rat Mesh

Install the protective rat mesh at the bottom of the machine to prevent rodents from entering and damaging internal components.

Advertisements



Image 4.1: Side view of the washing machine showing dimensions and energy efficiency guide.

Advertisements



Image 4.2: Detailed dimensions of the washing machine (51.3 cm D x 59.8 cm W x 87.5 cm H).

5. OPERATING INSTRUCTIONS

Your IFB EVA ZX washing machine features a fully automatic control console and a variety of wash programs for different fabric types and soil levels.

Advertisements



5.1 Control Panel Overview




Image 5.1: Close-up of the control panel, highlighting the program knob and LED display.

The control panel includes an encoder multi-position knob for program selection and an LED display for cycle information. Buttons for Spin, Temp, Delay, and Start/Pause are also present.

5.2 Loading Laundry

Open the front loading door and place laundry inside the drum. Do not exceed the 6 kg capacity. Close the door firmly.

Advertisements



5.3 Adding Detergent

Add appropriate detergent and fabric softener to the dispenser drawer. Refer to your detergent packaging for recommended amounts.

5.4 Selecting a Wash Program

Turn the encoder knob to select one of the 10 available wash programs. Common programs include:

- **Express Wash:** For lightly soiled clothes or quick washes.
- **Mixed Soiled:** For everyday mixed laundry.
- **Synthetic/Daily:** For synthetic fabrics.
- **Cotton Normal:** Standard wash for cotton items.
- **Cotton Eco Plus:** Energy-efficient cotton wash.
- **Baby Wear:** Gentle wash for baby clothes.
- **Cradle Wash:** Ultra-gentle wash for delicate items.
- **Rinse+Spin:** For rinsing and spinning only.
- **Spin Dry/Drain:** For draining water and spinning clothes.

Advertisements



5.5 Special Features and Technologies

6 kg capacity suitable for bachelors and couples




**Stainless
Steel Built**



**Germ Free Hot
Water Wash**



**1000 Rpm
Motor**



**Aqua Energie
Water Softener**



**Child
Lock**



**Baby Wear
Wash**

Image 5.2: Overview of key features including Stainless Steel Built, 1000 RPM Motor, and Aqua Energie.

Advertisements





Image 5.3: Visual representation of Crescent Moon Drum, 2D Wash, Auto Tub Clean, and Cradle Wash features.

- **Aqua Energie:** This feature energizes water, dissolving detergent better for a softer wash.
- **2D Wash System:** A dynamic water system that ensures thorough soaking and rinsing.
- **Cradle Wash:** A gentle wash motion designed for delicate fabrics.
- **Crescent Moon Drum:** Smooth crescent moon shaped drum surface prevents damage to clothes during washing.
- **Inbuilt Heater:** Allows for hot water washes, effective for germ-free cleaning and tough stains.
- **1000 RPM Spin Speed:** Higher spin speed for faster drying times.
- **Pre Wash:** An initial wash cycle for heavily soiled items.
- **Rinse Hold:** Holds clothes in the final rinse water to prevent creasing if not removed immediately.

- **Time Delay / Delay Start:** Allows you to set a delayed start time for the wash cycle.
- **Child Lock:** Locks the control panel to prevent accidental changes during operation.

Advertisements

5.6 Starting the Wash Cycle

After selecting the program and any desired options, press the Start/Pause button to begin the wash cycle.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your washing machine.

6.1 Cleaning the Detergent Dispenser

Periodically remove and clean the detergent dispenser drawer to prevent residue buildup.

Advertisements

6.2 Cleaning the Drum

Utilize the **Auto Tub Clean** feature regularly to clean the washing machine drum and prevent odor buildup. Consult the detailed user manual for instructions on activating this program.

6.3 Cleaning the Filter

Locate and clean the drain pump filter periodically to remove lint and small objects that may obstruct drainage.

6.4 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Avoid abrasive cleaners.

Advertisements

7. TROUBLESHOOTING

Before contacting customer service, refer to the following common issues and their potential solutions:

Problem	Possible Cause / Solution
Machine does not start	Check if the power cord is plugged in, the door is closed properly, and the Start/Pause button has been pressed. Ensure there is water supply.
Excessive vibration/noise	Ensure the machine is level and all transit bolts (if any) have been removed. Distribute laundry evenly in the drum.
Water not draining	Check if the drain hose is kinked or blocked. Clean the drain pump filter.
Detergent residue on clothes	Ensure correct detergent dosage and that the detergent dispenser is clean. Use the Aqua Energie feature for better dissolution.
Door not opening	The door remains locked during operation and for a short period after the cycle ends. Wait for the lock indicator to turn off.

For more detailed troubleshooting, refer to the comprehensive user manual included with your appliance.



8. SPECIFICATIONS

Feature	Detail
Brand	IFB

Feature	Detail
Model	EVA ZX
Capacity	6 Kilograms
Maximum Rotational Speed	1000 RPM
Noise Level (Washing)	54 Decibels
Noise Level (Spinning)	68 dB
Installation Type	Freestanding
Form Factor	Front-Loading
Special Features	Inbuilt Heater, Aqua Energie, 2D Wash, Protective Rat Mesh, Express Wash, Cradle Wash, Crescent Moon Drum, Pre Wash, Rinse Hold, Time Delay
Colour	White
Control Console	Fully Automatic
Number of Wash Programs	10
Access Location	Front Load
Voltage	230 Volts
Certification	Energy Star (5 Star Rating)
Material	Stainless Steel (Drum)
Item Weight	60 kg
Item Dimensions (LxWxH)	51.3 x 59.8 x 87.5 Centimeters
Country of Origin	India

9. WARRANTY AND SUPPORT

Your IFB EVA ZX washing machine comes with comprehensive warranty coverage to ensure peace of mind.



Image 9.1: Visual representation of the Tri Shield Protection warranty.

9.1 Tri Shield Protection

- **4 Years Complete Machine Warranty:** Covers the entire washing machine for four years from the date of purchase.

- **10 Years Motor Warranty:** The motor is covered for a period of ten years. For washers installed from June 15, 2021, this motor warranty is applicable.
- **10 Years Spare Part Support:** Availability of spare parts is assured for ten years.

Please refer to the warranty card included with your product for specific terms and conditions.

Advertisements



9.2 Customer Support

For service requests, technical assistance, or any queries regarding your IFB washing machine, please refer to the contact information provided in the detailed user manual or visit the official IFB website.

Advertisements



ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?



Details

Model number, symptoms, what you tried, or the section of the manual you are using.



Submit question



IFB EVA ZX

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

IFB EVA ZX manuals, guides

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

[Privacy Policy](#)

[Login](#)

GUIDES

[Amazon Manuals](#)

[AliExpress Manuals](#)

[Video Guides](#)

[Login](#)

FOLLOW

[@manualsplus](#)

[YouTube](#)

[LinkedIn](#)

[Facebook](#)

[Login](#)

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

[Open login options](#)

[Privacy Policy](#) · [DMCA](#)