



Manuals.plus / > IFB /

> IFB 6.5 Kg 5 Star Fully-Automatic Front Loading Washing Machine ELENA ZXS User Manual

IFB ELENA ZXS

Sign in to save this manual

Sign in to bookmark this manual and keep private notes.

IFB 6.5 Kg 5 Star Fully-Automatic Front Loading Washing Machine ELENA ZXS User Manual

Model: ELENA ZXS

1. PRODUCT OVERVIEW

The IFB ELENA ZXS is a 6.5 Kg 5 Star fully-automatic front loading washing machine designed for efficient and high-quality laundry care. It features an in-built heater and 3D Wash Technology, ensuring thorough cleaning and hygiene.

- **Capacity:** 6.5 kg, suitable for bachelors and couples.
- **Energy Efficiency:** 5 Star rating for best-in-class efficiency.
- **Spin Speed:** 1000 RPM for faster drying.
- **Wash Programs:** 10 diverse wash programs to suit various fabric types and soil levels.
- **Drum Type:** Crescent Moon Drum for gentle yet effective washing.

- **Key Technologies:** Aqua Energie, 3D Wash, 7 Swirl Wash, Cradle Wash, Pre Wash, Express Wash.



Image 1.1: Front view of the IFB ELENA ZXS washing machine.

2. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and longevity of your washing machine. It is recommended to have the appliance installed by a qualified technician.

2.1 Unpacking

- Carefully remove all packaging materials.
- Remove the transit bolts from the rear of the machine. Retain these bolts for future transport.

- Ensure all included components are present: Drain Hose, Protective Rat Mesh, User Manual, Water Inlet Pipe, and the Washing Machine unit.

2.2 Positioning

- Place the washing machine on a firm, level surface.
- Adjust the leveling feet to ensure the machine is stable and does not wobble.
- Install the protective rat mesh at the bottom of the machine to prevent rodent entry.

2.3 Water and Drain Connections

- Connect the water inlet pipe to a cold water tap and to the inlet valve on the back of the machine. Ensure connections are tight to prevent leaks.
- Position the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fixed and at the correct height to prevent siphoning.

2.4 Electrical Connection

- Plug the power cord into a grounded electrical outlet.
- Ensure the voltage supply matches the requirements specified on the machine's rating label.

3. OPERATING INSTRUCTIONS

This section provides general guidance on operating your IFB ELENA ZXS washing machine. Refer to the detailed user manual for specific program descriptions and advanced features.

3.1 Loading Laundry

- Sort laundry by fabric type, color, and soil level.
- Open the door and load clothes loosely into the drum, ensuring not to overload.
- Close the door firmly until it clicks.



Image 3.1: The Laundry Add option allows adding forgotten garments during a cycle.

3.2 Adding Detergent and Additives

- Pull out the detergent dispenser drawer.
- Add the appropriate amount of detergent to the main wash compartment.
- Add fabric softener or other additives to their designated compartments.
- Push the dispenser drawer back in completely.

3.3 Selecting a Wash Program

- Turn the program selector knob to choose one of the 10 available wash programs (e.g., Cotton, Synthetics, Delicates, Express Wash, Cradle Wash).
- The display will show the default settings for the selected program.



Image 3.2: The multi-position program encoder for selecting wash cycles.

3.4 Adjusting Settings and Starting the Wash

- Use the option buttons to adjust temperature, spin speed (up to 1000 RPM), or add special functions like Pre Wash, Extra Rinse, or Steam Cycle.
- Press the Start/Pause button to begin the wash cycle.



Image 3.3: Visual representation of Aqua Energie and 3D Wash technologies for superior cleaning.



Image 3.4: Cradle Wash feature and Crescent Moon Drum design for delicate fabric care.

4. MAINTENANCE

Regular maintenance ensures the efficiency and longevity of your washing machine.

4.1 Cleaning the Detergent Dispenser

- Remove the detergent dispenser drawer and rinse it under running water to remove any detergent residue.
- Clean the housing of the dispenser drawer with a brush.

4.2 Cleaning the Drum

- Run a 'Tub Clean' or 'Drum Clean' program periodically (if available) or a hot wash cycle with no laundry and a descaling agent.

- Wipe the inside of the drum and the door seal with a damp cloth after each wash to prevent mold and odors.

4.3 Cleaning the Drain Filter

- Locate the drain filter, usually at the bottom front of the machine.
- Place a shallow container beneath it to catch any residual water.
- Carefully unscrew and remove the filter, clean out any lint, coins, or debris.
- Rinse the filter under running water and reinsert it securely.



Image 4.1: Illustration of Ball Valve Technology, which helps prevent detergent wastage and improves wash quality.

5. TROUBLESHOOTING

Before contacting customer service, refer to these common troubleshooting tips.

5.1 Machine Not Starting

- Check if the power cord is securely plugged in.
- Ensure the door is fully closed.
- Verify that the water supply tap is open.
- Check for any error codes on the display and consult the full manual for their meaning.

5.2 Excessive Vibration or Noise

- Ensure the machine is level and all four feet are firmly on the floor.

- Check if the transit bolts were removed during installation.
- Redistribute the laundry inside the drum if it's unbalanced. The machine features **Auto Imbalance Vibration Control** to mitigate this.

5.3 Water Not Draining

- Clean the drain filter as described in the Maintenance section.
- Check if the drain hose is kinked or blocked.

5.4 Power Fluctuations

- The machine is equipped with **Voltage Protection** to safeguard against power surges.
- In case of a power cut, the **Auto Restart** feature will resume the cycle from where it left off once power is restored.



Image 5.1: Overview of key features including Auto Diagnosis and protective functions.

6. SPECIFICATIONS

Feature	Specification
Brand	IFB
Model	ELENA ZXS
Capacity	6.5 Kilograms
Energy Efficiency Rating	5 Star
Maximum Rotational Speed	1000 RPM
Noise Level (Washing)	54 Decibels
Noise Level (Spinning)	68 dB
Installation Type	Freestanding
Form Factor	Front-Loading
Special Features	Inbuilt Heater, Aqua Energie, 3D Wash, 7 Swirl Wash, Protective Rat Mesh, Express Wash, Cradle Wash, Crescent Moon Drum, Prewash
Control Console	Fully Automatic
Number of Wash Programs	10
Material (Drum)	Stainless Steel
Item Dimensions (LxWxH)	59.8 x 51.8 x 87.5 Centimeters
Item Weight	6 kg 500 g
Included Components	Drain Hose, Protective Rat Mesh, User Manual, Water Inlet Pipe, 1 Washing Machine

7. WARRANTY INFORMATION

Your IFB ELENA ZXS washing machine comes with comprehensive Tri-Shield Protection:

- **4 Years Complete Machine Warranty:** Covers the entire washing machine for four years from the date of purchase.
- **10 Years Motor Warranty:** The motor is covered for a period of ten years.
- **10 Years Spare Part Support:** Assurance of spare part availability for ten years.

Terms and Conditions apply. Please refer to the warranty card provided with your product for full details.



Image 7.1: Visual representation of the Tri-Shield Protection warranty.

8. CUSTOMER SUPPORT

For any assistance, service requests, or queries regarding your IFB washing machine, please contact IFB Customer Care.

- **24x7 Help:** Available via call or AI chat.
- **On-site Repairs:** Qualified technicians available for home service.
- **Service Network:** Over 6100 service experts across 1250+ service centers, covering 19000+ pin codes.

Contact Information:

Phone: 08045845678

WhatsApp: 9231004321

Email: customerservice@ifbglobal.com

IFB CARE

Best in class Service and Support
at your DOORSTEP

 24x7 help on call or AI chat

 On-site repairs

 6100+ service experts

1250+
Service
Centers

19000+
Pin-codes



 9231004321

 08045845678

 customerservice@ifbglobal.com

Image 8.1: IFB Customer Care details for support and service.

© 2026 IFB Industries Ltd. All rights reserved.

Related Documents - ELENA ZXS

	IFB Senator 6kg / Senator 6kg Aqua Energie Washing Machine Operating Manual Comprehensive operating manual for the IFB Senator 6kg and Senator 6kg Aqua Energie washing machines, covering installation, operation, maintenance, and troubleshooting.
	IFB Washing Machine User Manual: DIVA, ELENA, SENORITA Series Comprehensive user manual for IFB washing machines, covering installation, operation, maintenance, troubleshooting, and safety guidelines for DIVA VXN/GXN/SXN/SBN/MSN/MXN/MBN 6010, ELENA SXN/GXN/MSN 6510, and SENORITA SXN/MSN/GXN/BXN 6512 models.
	IFB Executive Washer Dryer ZXB ZXS User Manual - Installation & Operation Guide Comprehensive user manual for IFB Executive ZXB and ZXS Washer Dryer models. Includes installation instructions, safety guidelines, program details, operation, maintenance, and troubleshooting tips for optimal laundry care.
	IFB DeepClean Washing Machine User Manual (TL-REW, TL-RES, TL-REG 6.5 KG Aqua) Comprehensive user manual for IFB DeepClean 6.5 KG Aqua top-load washing machines. Includes installation instructions, safety guidelines, operating procedures, maintenance tips, and troubleshooting for models TL-REW, TL-RES, and TL-REG.
	IFB Washing Machine User Manual: Diva, Elena, and Senorita Series Comprehensive user manual for IFB front-load washing machines, including Diva, Elena, and Senorita series. Covers installation, operation, maintenance, and troubleshooting.
	IFB Washing Machine User Manual: Comprehensive Guide for Elena, Elite, and Senator Models Explore the IFB Washing Machine User Manual for detailed instructions on operating your Elena, Elite, and Senator models. Learn about installation, programs, wash options, maintenance, and troubleshooting for optimal performance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

IFB ELENA ZXS

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

IFB ELENA ZXS manuals, g

Search Manuals+

EXPLORE[Deep Search](#)[Upload](#)[Login](#)**MANUALS+**[Home](#)[About Us](#)[Privacy Policy](#)[Login](#)**GUIDES**[Amazon Manuals](#)[AliExpress Manuals](#)[Video Guides](#)[Login](#)**FOLLOW**[@manualsplus](#)[YouTube](#)[LinkedIn](#)[Facebook](#)[Login](#)**Manuals+**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

[Open login options](#)

[Privacy Policy](#) · **[DMCA](#)**