



Manuals.plus / > Panasonic /

> Panasonic NA-F70AH10MB 7 Kg Wifi Fully-Automatic Top Loading Smart Washing Machine User Manual

Panasonic NA-F70AH10MB

Sign in to save this manual

Sign in to bookmark this manual and keep private notes.

Panasonic NA-F70AH10MB 7 Kg Wifi Fully-Automatic Top Loading Smart Washing Machine User Manual

Model: NA-F70AH10MB

1. PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient operation of your Panasonic NA-F70AH10MB 7 Kg Wifi Fully-Automatic Top Loading Smart Washing Machine. Please read it thoroughly before use and retain it for future reference.



Front view of the Panasonic NA-F70AH10MB Smart Washing Machine, highlighting its Wi-Fi connectivity and compatibility with Alexa and Google Assistant.

Advertisements



2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the washing machine is properly grounded.
- Do not operate the machine with a damaged power cord or plug.
- Keep children and pets away from the appliance during operation.
- Do not wash items that are soiled with flammable substances.
- Always unplug the machine before cleaning or performing maintenance.
- The appliance is designed for household use only.

Advertisements



3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials. Inspect the machine for any damage incurred during transit. Report any damage to your retailer immediately.

3.2 Placement

The Panasonic NA-F70AH10MB is a free-standing appliance. Place it on a firm, level surface to minimize vibration and noise during operation. Ensure adequate space around the machine for ventilation and access.

Advertisements





Illustration showing the dimensions of the washing machine: 60.4 cm (width) x 52.5 cm (depth) x 99.5 cm (height). It also indicates a 7 Kg capacity and 5-star energy rating.

3.3 Connections

- **Water Supply:** Connect the inlet hoses to appropriate hot and cold water taps. Ensure connections are tight to prevent leaks.
- **Drainage:** Position the drain hose securely into a standpipe or laundry tub, ensuring it is not kinked.
- **Power Supply:** Plug the power cord into a grounded 230 Volt electrical outlet.

3.4 Smart Features Setup (MirAle App)

To utilize the smart features, download the Panasonic MirAle app on your smartphone. Follow the in-app instructions to connect your washing machine to your home Wi-Fi network. This enables remote control, monitoring, and access to advanced functions.

Advertisements



4. OPERATING INSTRUCTIONS

4.1 Control Panel Overview

The control panel provides access to various wash programs and settings.



Close-up of the washing machine's control panel, illustrating features like ECONAVI, ActiveFoam System, Smart Built-in Heater, Child Lock, Anti-Tangling, and Soft Closing Lid.

4.2 Loading Laundry

- Sort laundry by fabric type, color, and soil level.
- Do not overload the machine. The maximum capacity is 7 Kg.
- Distribute clothes evenly in the drum.

Advertisements

4.3 Adding Detergent and Additives

Add appropriate amounts of detergent, fabric softener, and other additives to their designated compartments before starting a wash cycle.

4.4 Selecting a Wash Program

Turn the program selector knob or press the program buttons to choose the desired wash cycle. Common programs include:

- **Normal:** For daily laundry.
- **Delicate:** For fragile items.
- **Heavy Duty:** For heavily soiled items.
- **Quick:** For lightly soiled items needing a fast wash.
- **Tub Hygiene:** For cleaning the washing machine drum.

Advertisements

Adjust additional settings such as water level, wash temperature (utilizing the built-in heater), and spin speed as needed.

4.5 Smart Features in Detail (MirAle App)



MirAle app features for Panasonic washing machine

An illustration detailing the various benefits of the MirAle app, including Weather Alerts, Energy & Water Tracking, Wash Wizard, Smart Scheduling, One Touch Service, Stain Genius, Voice Commands, and Maintenance Alerts.

- **Wash Wizard:** The app suggests the most suitable wash cycle from over 600 programs based on your input regarding fabric type, soil level, and load size.
- **Stain Genius:** Provides pre-treatment recommendations for over 50 types of stains to ensure effective removal.
- **Remote Control:** Start, pause, or end wash cycles remotely via the app. You can also schedule washes for convenience.
- **Energy & Water Tracking:** Monitor your washing machine's real-time performance and consumption of energy and water.
- **Weather Alerts:** Receive notifications about weather conditions to help plan your laundry schedule.
- **Voice Commands:** Control your washing machine using voice commands through compatible smart assistants like Alexa and Google Assistant.

Advertisements

4.6 Key Washing Technologies

- **Smart Built-in Heater:** Provides hot water for superior cleaning, aiding in stain dissolution and ensuring a more hygienic wash.

- **ActiveFoam System:** Generates fine, dense foam that lifts, separates, and removes impurities from deep within fabric fibers for an effortless washing experience.
- **Anti-Tangling System:** Reduces tangles and prevents damage to clothes during the wash cycle.
- **ECONAVI:** Optimizes water and energy consumption based on the load size and water temperature.
- **Water Reuse:** Recycles water from the final rinse cycle, contributing to energy and water efficiency.
- **Soft Closing Lid:** Ensures quiet and safe closing of the machine lid.
- **Child Lock:** Prevents accidental operation by children.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your washing machine.

5.1 Cleaning the Lint Filter

The large lint filter effectively captures lint and debris. Clean it regularly to maintain washing efficiency and prevent lint transfer to clothes.

Advertisements



An image illustrating the effectiveness of the lint filter in removing lint from clothes, showing a 'before' and 'after' comparison and a close-up of the filter.

5.2 Drum Cleaning

Use the 'Tub Hygiene' program periodically to clean the washing machine drum and prevent odor buildup.

5.3 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Avoid using abrasive cleaners or solvents.

Advertisements

5.4 Maintenance Alerts

The MirAle app provides timely maintenance alerts, reminding you when your washing machine may need servicing.

6. TROUBLESHOOTING

If you encounter issues with your washing machine, refer to the following common troubleshooting steps. For more complex problems, contact customer support.

- **Machine does not start:** Check if the power cord is securely plugged in, the water supply is turned on, and the lid is properly closed. Ensure a wash program has been selected and the 'Start' button pressed.
- **Excessive vibration/noise:** Verify that the machine is on a level surface and all transit bolts (if applicable) have been removed. Ensure the laundry load is balanced.
- **Water leakage:** Check all hose connections for tightness. Inspect hoses for damage. Ensure the drain hose is correctly positioned.
- **Poor washing results:** Ensure you are using the correct amount and type of detergent. Do not overload the machine. Select an appropriate wash program for the load. Clean the lint filter.
- **Smart features not connecting:** Check your home Wi-Fi network status. Ensure the MirAle app is updated to the latest version. Re-pair the device if necessary.

Advertisements



7. SPECIFICATIONS

Brand	Panasonic
Model	NA-F70AH10MB
Capacity	7 Kilograms
Energy Efficiency	5 Star
Maximum Rotational Speed	702 RPM
Installation Type	Free Standing
Access Location	Top Load
Colour	Middle Free Silver
Voltage	230 Volts
Item Weight	32 kg
Item Dimensions (LxWxH)	60.4 x 52.5 x 99.5 Centimeters
Included Components	Washing Machine, Warranty Card

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Panasonic NA-F70AH10MB washing machine comes with:

- **2 Years Comprehensive Warranty** on the entire appliance.
- **12 Years Warranty** on the motor.

Please refer to the warranty card included with your product for detailed terms and conditions.

Advertisements





An image highlighting the 2-year comprehensive warranty, 12-year motor warranty, heavy-duty motor, and durable body construction of the washing machine.

8.2 Customer Support

For service requests, technical assistance, or any inquiries, you can:

- Utilize the 'One Touch Service' feature within the Panasonic MirAle app to schedule service visits.
- Visit the official Panasonic India website for support resources and contact details.
- Contact Panasonic customer service directly using the information provided in your warranty card.

Advertisements





Advertisements



Related Documents - NA-F70AH10MB

	Panasonic Fully Automatic Washing Machine Operating & Installation Instructions Comprehensive guide for Panasonic Fully Automatic Washing Machines (Models NA-F75S7, NA-F70S7, NA-F65S7, NA-F75V7, NA-F70V7, NA-F65V7, NA-F62V7, NA-F70X7, NA-F65X7, NA-F62X7). Includes safety, installation, operation, maintenance, and troubleshooting instructions.
	Panasonic Fully Automatic Washing Machine Service Manual (NA-FS16X3, NA-FS15X3, NA-FS14X3, NA-F150A3) Comprehensive service manual for Panasonic fully automatic washing machines, models NA-FS16X3, NA-FS15X3, NA-FS14X3, and NA-F150A3, covering parts diagrams and technical information.
	Panasonic Fully Automatic Washing Machine Operating and Installation Instructions Comprehensive guide for Panasonic fully automatic washing machines (models NA-FD13XR1, NA-FD13AR1, NA-FD12XR1, NA-FD11AR1), covering safe operation, installation, maintenance, and troubleshooting.
	Panasonic Fully Automatic Washing Machine Operating & Installation Instructions Comprehensive operating and installation instructions for Panasonic Fully Automatic Washing Machines, including model numbers NA-F80VB7, NA-F75S7, and NA-F70S7. This guide covers safety precautions, part names, operation panel details, program varieties, detergent usage, washing options, convenient functions, maintenance, installation steps, troubleshooting, error displays, and specifications.

	Panasonic Fully Automatic Washing Machine Operating & Installation Instructions Comprehensive operating and installation guide for Panasonic Fully Automatic Washing Machines, covering models NA-F80VB7, NA-F75S7, and NA-F70S7. Includes safety precautions, part names, operation panel details, program descriptions, maintenance, troubleshooting, and specifications.
	Panasonic NA-FD95X1 Fully Automatic Washing Machine: Operating & Installation Guide Get detailed operating and installation instructions for the Panasonic NA-FD95X1 Fully Automatic Washing Machine. Learn about safety precautions, programs, maintenance, and troubleshooting for household use.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Advertisements



PANASONIC NA-F70AH10MB**KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.**

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Panasonic NA-F70AH10M

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

[Open login options](#)

[Privacy Policy](#) · [DMCA](#)